

**TECHNICAL MANUAL
ORGANIZATIONAL MAINTENANCE REPAIR
PARTS AND SPECIAL TOOLS LISTS**

**TRUCK, LIFT, FORK, GASOLINE,
PNEUMATIC-TIRED WHEELS,
4000 LBS. CAPACITY
ARMY MODEL MHE 211
NSN 3930-00-935-7963**

BAKER MODEL FJF-040

HEADQUARTERS, DEPARTMENT OF THE ARMY

JUNE 1984

TECHNICAL MANUAL }
TM 10-3930-623-20P }

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, DC, 1 June 1984

ORGANIZATIONAL MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LISTS

TRUCK, LIFT, FORK, GASOLINE,
PNEUMATIC-TIRED WHEELS,
4000-POUND CAPACITY
ARMY MODEL MHE 211
NSN 3930-00-935-7963
BAKER MODEL FJF-040

Current as of 5 March 1984

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in back of this manual direct to: U.S. Army Tank-Automotive Command, ATTN: DRSTA-MB, Warren, MI 48090. A reply will be furnished to you.

TABLE OF CONTENTS

		Page	Illus Fig
SECTION I.	INTRODUCTION	1	
SECTION II.	REPAIR PARTS LIST	7	
GROUP 01	ENGINE		
	0101- CRANKCASE, BLOCK, CYLINDER HEAD	7	
	CYLINDER HEAD, CRANKCASE AND FILLER BLOCK	7	1
	0103- FLYWHEEL ASSEMBLY	9	
	FLYWHEEL HOUSING	9	2

*This manual supersedes TM 10-3930-623-20P, 6 April 1971, including all changes.

TABLE OF CONTENTS

	Page	Illus Fig
0105- VALVES, CAMSHAFTS, AND TIMING SYSTEM	11	
VALVE COVER	11	3
TIMING GEAR COVER.....	13	4
0106- ENGINE LUBRICATION SYSTEM	15	
OIL PRESSURE RELIEF VALVES, PCV VALVE, DIPSTICK, LINES AND FITTINGS	15	5
OIL PAN.....	17	6
OIL FILTER.....	19	7
0108- MANIFOLDS	21	
INTAKE AND EXHAUST MANIFOLD	21	8
GROUP 03		
FUEL SYSTEM		
0301- CARBURETOR	23	
CARBURETOR.....	23	9
0302- FUEL PUMPS.....	25	
FUEL PUMP	25	10
0304- AIR CLEANER.....	27	
AIR CLEANER.....	27	11
0306- TANKS, LINES, FITTINGS, HEADERS	29	
FUEL TANK, LINES AND FITTINGS.....	29	12
0308- ENGINE SPEED GOVERNOR AND CONTROLS	31	
GOVERNOR	31	13
GOVERNOR CONTROLS	33	14
0309- FUEL FILTERS	35	
FUEL FILTER.....	35	15
0312- ACCELERATOR, THROTTLE OR CHOKE CONTROL	37	
ACCELERATOR PEDAL, LINKAGE, AND CHOKE CONTROL	37	16
GROUP 04		
EXHAUST SYSTEM		
0401- MUFFLER AND PIPES	39	
MUFFLER AND PIPES	39	17
GROUP 05		
COOLING SYSTEM		
0501- RADIATOR.....	41	
RADIATOR	41	18
0503- WATER MANIFOLD, HEADERS, THERMOSTATS AND HOUSING GASKET.....	43	
RADIATOR HOSES.....	43	19
THERMOSTAT, WATER OUTLET HOSE AND RELATED PARTS	45	20
0504- WATER PUMP	47	
WATER PUMP	47	21
0505- FAN ASSEMBLY	49	
FAN ASSEMBLY	49	22
GROUP 06		
ELECTRICAL SYSTEM		
0601- ALTERNATOR		51
ALTERNATOR	51	23
ALTERNATOR BELT AND MOUNTING PARTS	53	24
0602- VOLTAGE REGULATOR	55	
VOLTAGE REGULATOR	55	25

TABLE OF CONTENTS

	Page	Illus Fig
0603- STARTING MOTOR.....	57	
STARTER	57	26
STARTER RELAY AND ELECTROMAGNET RELAY.....	59	27
0605- IGNITION COMPONENTS	61	
DISTRIBUTOR	61	28
COIL, SPARK PLUGS, AND WIRING	63	29
0606- ENGINE SAFETY CONTROLS.....	65	
NEUTRAL SAFETY SWITCH	65	30
0607- INSTRUMENT PANEL.....	67	
INSTRUMENT PANEL.....	67	31
0608- MISCELLANEOUS ITEMS	69	
FUSES AND REGULATOR.....	69	32
0609- LIGHTS	71	
LIGHTS.....	71	33
0610- SENDING UNITS AND WARNING SWITCHES	73	
SENDING UNITS AND WARNING SWITCHES	73	34
0611- HORN, SIREN.....	75	
HORN.....	75	35
0612- BATTERIES, STORAGE	77	
BATTERY AND CABLES	77	36
0613- CHASSIS WIRING HARNESS.....	79	
ELECTRICAL WIRING.....	79	37
0615- RADIO INTERFERENCE SUPPRESSION	81	
INTERFERENCE SUPPRESSION.....	81	38
GROUP 07		
TRANSMISSION		
0705- TRANSMISSION SHIFTING COMPONENTS	83	
DIRECTIONAL CONTROL.....	83	39
0721- COOLERS, PUMPS, MOTORS	85	
TRANSMISSION COOLING LINES.....	85	40
GROUP 10		
FRONT AXLE		
1002- DIFFERENTIAL.....	87	
DIFFERENTIAL	87	41
1003- FINAL DRIVE	89	
FINAL DRIVE	89	42
GROUP 11		
REAR AXLE		
1104- STEERING, SIDESHIFT AND WHEEL LEANING		
MECHANISM	91	
STEERING AXLE	91	43
GROUP 12		
BRAKES		
1201- HAND BRAKES.....	93	
HAND BRAKE AND RELATED PARTS	93	44
1202- SERVICE BRAKES.....	97	
BRAKES	97	45
1204- HYDRAULIC BRAKE SYSTEM.....	99	
MASTER CYLINDER AND RELATED PARTS	99	46
WHEEL CYLINDER.....	101	47
BRAKE LINES AND FITTINGS.....	103	48

TABLE OF CONTENTS

		Page	Illus Fig
	1206- MECHANICAL BRAKE SYSTEM	105	
	BRAKE PEDAL AND ATTACHING PARTS	105	49
GROUP 13	WHEELS AND TRACKS		
	1311- WHEEL ASSEMBLY	107	
	FRONT WHEEL ASSEMBLY	107	50
	REAR WHEEL ASSEMBLY	109	51
	1313- TIRES, TUBES, TIRE CHAINS	111	
	FRONT TIRES.....	111	52
	REAR TIRES.....	113	53
GROUP 14	STEERING		
	1401- MECHANICAL STEERING GEAR ASSEMBLY	115	
	STEERING GEAR.....	115	54
GROUP 15	FRAME, TOWING ATTACHMENTS, AND DRAWBARS AND ARTICULATION SYSTEMS		
	1501- FRAME ASSEMBLY	117	
	FRAME ATTACHING PARTS	117	55
	1502- COUNTERWEIGHTS	119	
	COUNTERWEIGHT.....	119	56
GROUP 18	BODY, CAB, HOOD AND HULL		
	1801- BODY, CAB, HOOD AND HULL ASSEMBLIES	121	
	INSTRUMENT PANEL COVERS	121	57
	OVERHEAD GUARD.....	123	58
	ENGINE COMPARTMENT COVER AND ATTACHING PARTS	125	59
	1805- FLOORS, SUBFLOORS, AND RELATED COMPONENTS.....	127	
	FLOOR PLATES.....	127	60
	1806- UPHOLSTERY SEATS AND CARPETS.....	129	
	SEAT	129	61
GROUP 22	BODY CHASSIS AND HULL ACCESSORY ITEMS		
	2210- DATA PLATES AND INSTRUCTION HOLDERS.....	131	
	DECAL.....	131	62
GROUP 24	HYDRAULIC AND FLUID SYSTEMS		
	2402- MANIFOLD AND/OR CONTROL VALVE.....	133	
	CONTROL VALVE RIGHT HALF	133	63
	CONTROL VALVE LEFT HALF	135	64
	2403- HYDRAULIC CONTROL	137	
	CONTROL LEVERS	137	65
	2404- TILT CYLINDERS AND TILT CRANK.....	139	
	TILT CYLINDER.....	139	66
	2405- MAST COLUMN.....	141	
	BACKREST AND FORKS	141	67
	MAST ASSEMBLY AND CARRIAGE	143	68
	2406- STRAINERS, FILTERS, LINES AND FITTINGS.....	145	
	HYDRAULIC LINES AND FILTER.....	145	69
	HYDRAULIC TANK LINES	149	70
	2408- LIQUID TANKS OR RESERVOIRS	151	

TABLE OF CONTENTS

		Page	Illus Fig
	HYDRAULIC TANK	151	71
GROUP 47	GAGES (NON ELECTRICAL), WEIGHING AND MEASURING DEVICES		
	4702- GAGES, MOUNTINGS, LINES AND FITTINGS	153	
	HYDRAULIC GAGE	153	72
GROUP 95	GENERAL USE STANDARDIZED PARTS		
	9501- BULK MATERIEL.....	155	
	BULK MATERIEL.....	155	BULK
SECTION III.	SPECIAL TOOLS LIST (NOT APPLICABLE)		
SECTION IV.	NATIONAL STOCK NUMBER AND	157	
	PART NUMBER INDEX		

ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS

SECTION I. INTRODUCTION

1. Scope.

This manual lists and authorizes spares and repair parts; special tools; special Test, Measurement, and Diagnostic Equipment (TMDE) ; and other special support equipment required for performance of organizational support maintenance of the Truck, Lift, Fork. It authorizes the requisitioning, issue, and disposition of spares, repair parts and special tools as indicated by the Source, Maintenance and Recoverability (SMR) codes.

2. General.

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence. Bulk materials are listed in NSN sequence.

b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized by this RPSTL for the performance of maintenance.

c. Section IV. National Stock Number and Part Number Index. A list, in National Item Identification Number (NIIN) sequence, of all National Stock Numbers (NSN) appearing in the listings, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.


3. Explanation of Columns.

a. Illustration (Column (1)). This column is divided as follows:

(1) ((a) FIG NO.) Figure Number. Indicates the figure number illustrating an exploded view of a functional group.

(2) ((b) ITEM NO.). Indicates the number used to identify items called out in the illustration.

b. SMR CODE (Column (2)). The Source, Maintenance, and Recoverability (SMR) code is a 5-position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instructions, as shown in the following breakout:



*Complete Repair: Maintenance capacity, capability, and authority to perform all the corrective maintenance tasks of the "Repair" function in a use/user environment in order to restore serviceability to a failed item.