

**TECHNICAL MANUAL**

**UNIT, DIRECT SUPPORT, AND  
GENERAL SUPPORT MAINTENANCE  
REPAIR PARTS AND SPECIAL TOOLS LISTS**

**TAMPER, BACKFILL: GASOLINE ENGINE  
DRIVEN, HAND-OPERATED, RAM-TYPE**

**MODEL VR11C (NSN 3895-01-151-2749)  
MODEL VR11 (NSN 3895-01-013-4328)**

This manual supersedes TM 5-3895-360-24P, dated 14 June 1985; and,  
this manual and TM 5-3895-360-14 supersede TM 5-3895-345-14&P,  
dated 30 January 1981, and all changes.

Approved for public release; distribution is unlimited.

---

HEADQUARTERS, DEPARTMENT OF THE ARMY

**20 APRIL 1993**

TECHNICAL MANUAL  
TM 5-3895-360-24P\*

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
Washington D.C, 20 April 1993

**UNIT, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE  
REPAIR PARTS AND SPECIAL TOOLS LISTS**

**TAMPER, BACKFILL: GASOLINE ENGINE DRIVEN,  
HAND-OPERATED, RAM-TYPE**

**MODEL VR11C (NSN 3895-01-151-2749)**

**MODEL VR11 (NSN 3895-01-013-4328)**

Current as of 22 January 1993

**REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS**

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2, located in the back of this manual, direct to: Commander, U.S. Army Tank-Automotive Command, ATTN: AMSTA-MB, Warren, MI 48397-5000. A reply will be furnished to you.

Approved for public release; distribution is unlimited.

**TABLE OF CONTENTS**

|             |                                              | Page | Illus<br>Fig |
|-------------|----------------------------------------------|------|--------------|
| SECTION I.  | INTRODUCTION .....                           | 1    |              |
| SECTION II. | REPAIR PARTS LIST .....                      | 1-1  |              |
| GROUP 01    | ENGINE                                       |      |              |
|             | 0100 - ENGINE ASSEMBLY .....                 | 1-1  |              |
|             | ENGINE ASSEMBLY .....                        | 1-1  | 1            |
|             | 0101 - CRANKCASE, BLOCK, CYLINDER HEAD ..... | 2-1  |              |
|             | CRANKCASE, BLOCK, CYLINDER HEAD .....        | 2-1  | 2            |
|             | 0102 - CRANKSHAFT .....                      | 3-1  |              |
|             | CRANKSHAFT .....                             | 3-1  | 3            |
|             | 0104 - PISTONS AND CONNECTING RODS .....     | 4-1  |              |
|             | PISTONS AND CONNECTING RODS .....            | 4-1  | 4            |
|             | 0107 - ENGINE STARTING SYSTEMS .....         | 5-1  |              |
|             | ENGINE STARTING SYSTEM .....                 | 5-1  | 5            |
| GROUP 03    | FUEL SYSTEM                                  |      |              |
|             | 0301 - CARBURETOR, FUEL INJECTOR .....       | 6-1  |              |
|             | CARBURETOR .....                             | 6-1  | 6            |

**\*This manual supersedes TM 5-3895-360-24P, dated 14 June 1985; and, this manual and TM 5-3895-360-14 supersede TM 5-3895-345-14&P, dated 30 January 1981, and all changes.**

Approved for public release; distribution is unlimited.

## TABLE OF CONTENTS (Con't)

|          |                                                               | Page   | Illus<br>Fig |
|----------|---------------------------------------------------------------|--------|--------------|
| 0304 -   | AIR CLEANER .....                                             | 7-1    |              |
|          | AIR CLEANER (VR11C) .....                                     | 7-1    | 7            |
|          | AIR CLEANER (VR11) .....                                      | 8-1    | 8            |
| 0306 -   | TANKS, LINES, FITTINGS, HEADERS .....                         | 9-1    |              |
|          | TANKS, LINES, FITTINGS .....                                  | 9-1    | 9            |
| 0312 -   | ACCELERATOR, THROTTLE, OR CHOKE CONTROLS .....                | 10-1   |              |
|          | THROTTLE CONTROL (VR11C) .....                                | 10-1   | 10           |
|          | THROTTLE CONTROL (VR11) .....                                 | 11-1   | 11           |
| GROUP 04 | EXHAUST SYSTEM                                                |        |              |
| 0401 -   | MUFFLER AND PIPES .....                                       | 12-1   |              |
|          | MUFFLER .....                                                 | 12-1   | 12           |
| GROUP 06 | ELECTRICAL SYSTEM                                             |        |              |
| 0605 -   | IGNITION COMPONENTS .....                                     | 13-1   |              |
|          | IGNITION COMPONENTS .....                                     | 13-1   | 13           |
| GROUP 07 | TRANSMISSION                                                  |        |              |
| 0700 -   | TRANSMISSION ASSEMBLY .....                                   | 14-1   |              |
|          | TRANSMISSION ASSEMBLY .....                                   | 14-1   | 14           |
| 0703 -   | TRANSMISSION CLUTCH AND CLUTCH CONTROLS .....                 | 15-1   |              |
|          | TRANSMISSION CLUTCH AND CLUTCH CONTROLS .....                 | 15-1   | 15           |
| 0719 -   | REDUCTION OR TRANSFER GEARS, SHAFTS, AND BEARINGS .....       | 16-1   |              |
|          | TRANSFER GEARS, SHAFTS, AND BEARINGS .....                    | 16-1   | 16           |
| GROUP 15 | FRAME. TOWING ATTACHMENTS, DRAWBARS, AND ARTICULATION SYSTEMS |        |              |
| 1501 -   | FRAME ASSEMBLY .....                                          | 17-1   |              |
|          | FRAME ASSEMBLY (VR11C) .....                                  | 17-1   | 17           |
|          | FRAME ASSEMBLY (VR11) .....                                   | 18-1   | 18           |
| GROUP 22 | BODY, CHASSIS, AND HULL ACCESSORY ITEMS                       |        |              |
| 2202 -   | ACCESSORY ITEMS .....                                         | 19-1   |              |
|          | ACCESSORY ITEMS (VR11C) .....                                 | 19-1   | 19           |
| 2210 -   | DATA PLATES AND INSTRUCTION HOLDERS .....                     | 20-1   |              |
|          | DATA PLATE AND DECALS .....                                   | 20-1   | 20           |
| GROUP 74 | CRANES, SHOVELS, AND EARTHMOVING EQUIPMENT COMPONENTS         |        |              |
| 7474 -   | DRIVE MECHANISM .....                                         | 21-1   |              |
|          | LOWER UNIT DRIVE MECHANISM (VR11C) .....                      | 21-1   | 21           |
|          | LOWER UNIT DRIVE MECHANISM (VR11) .....                       | 22-1   | 22           |
|          | SHOE DRIVE MECHANISM .....                                    | 23-1   | 23           |
| GROUP 94 | REPAIR KITS                                                   |        |              |
| 9401 -   | REPAIR KITS .....                                             | KITS-1 |              |
|          | REPAIR KITS .....                                             | KITS-1 |              |

## TABLE OF CONTENTS (Con't)

|              |                                    | Page   | Illus<br>Fig |
|--------------|------------------------------------|--------|--------------|
| GROUP 95     | GENERAL USE STANDARDIZED PARTS     |        |              |
|              | 9501 - BULK MATERIEL .....         | BULK-1 |              |
|              | BULK MATERIEL .....                | BULK-1 |              |
| SECTION III. | SPECIAL TOOLS                      |        |              |
| GROUP 26     | TOOLS AND TEST EQUIPMENT           |        |              |
|              | 2604 - SPECIAL TOOLS .....         | 24-1   |              |
|              | SPECIAL TOOLS .....                | 24-1   | 24           |
| SECTION IV.  | CROSS-REFERENCE INDEXES            |        |              |
|              | NATIONAL STOCK NUMBER INDEX .....  | I-1    |              |
|              | PART NUMBER INDEX .....            | I-4    |              |
|              | FIGURE AND ITEM NUMBER INDEX ..... | I-10   |              |

iii(iv Blank)

## UNIT, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS

### SECTION I. INTRODUCTION

#### 1. Scope.

This RPSTL lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of Unit, Direct Support, and General Support Maintenance of the Back fill Tamper. It authorizes the requisitioning, issue, and disposition of spares, repair parts and special tools as indicated by the source, maintenance and recoverability (SMR) codes.

#### 2. General.

In addition to Section I. Introduction, this Repair Parts and, Special Tools List is divided into the following sections:

a. *Section II. Repair Parts List.* A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence. Bulk materials are listed in item name sequence. Repair kits are listed separately in their own functional group within Section II. Repair parts for reparable special tools are also listed in the section. Items listed are shown on the associated illustration(s)/figure(s).

b. *Section III. Special Tools List.* A list of special tools, special TMDE, and other special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in DESCRIPTION AND USABLE ON CODE column) for the performance of maintenance.


c. *Section IV Cross-reference Indexes.* A list, in National Item Identification Number (NIIN) sequence, of all National stock numbered items appearing in the listing, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration/figure and item number appearance. The

figure and item number index lists figure and item numbers in alphanumeric sequence and cross-references NSN, CAGE, and part numbers.

#### 3. Explanation of Columns (Sections II and III).


a. *ITEM NO. (Column (1)).* Indicates the number used to identify items called out in the illustration.

b. *SMR CODE (Column (2)).* The Source, Maintenance, and Recoverability (SMR) code is a 5 position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instructions, as shown in the following breakout:



\*Complete Repair: Maintenance capacity, capability, and authority to perform all corrective maintenance tasks of the "Repair" function in a use/user environment in order to restore serviceability to a failed item.


(1) **Source Code.** The source code tells you how to get an item needed for maintenance, repair, or overhaul of an end item/equipment. Explanations of source codes follows:



TA705259

FIGURE 1. ENGINE ASSEMBLY.

| (1)                        | (2)   | (3)   | (4)        | (5)                                  | (6) |
|----------------------------|-------|-------|------------|--------------------------------------|-----|
| ITEM                       | SMR   |       | PART       |                                      |     |
| NO                         | CODE  | CAGEC | NUMBER     | DESCRIPTION AND USABLE ON CODES(UOC) | QTY |
| GROUP 01 ENGINE            |       |       |            |                                      |     |
| GROUP 0100 ENGINE ASSEMBLY |       |       |            |                                      |     |
| FIG. 1 ENGINE ASSEMBLY     |       |       |            |                                      |     |
| 1                          | PAFZZ | 33413 | 24394      | GASKET.....                          | 1   |
| 2                          | PAFZZ | 96906 | MS90728-40 | BOLT1MACHINE .....                   | 4   |
| 3                          | PFFZZ | 33413 | 24376      | ADAPTER, ENGINE .....                | 1   |
| 4                          | PAFZZ | 33413 | 24325      | GASKET.....                          | 1   |
| 5                          | PBFFF | 65254 | 58037      | ENGINE GASOLINE MODEL 58037 .....    | 1   |
| 6                          | PAFZZ | 96906 | MS90728-66 | SCREW, CAPIHEXAGON H.....            | 4   |
| 7                          | PAFZZ | 96906 | MS45904-76 | WASHER LOCK .....                    | 4   |
| 8                          | PAFZZ | 96906 | M535338-44 | WASHER LOCK .....                    | 4   |
| 9                          | PAFZZ | 96906 | MS90725-10 | SCREW CAP, HEXAGON H.....            | 4   |
| 10                         | XDFZZ | 33413 | 26935      | BRACKETIENGINE .....                 | 2   |
| END OF FIGURE              |       |       |            |                                      |     |



TA705260


FIGURE 2. CRANKCASE, BLOCK, CYLINDER HEAD.

## SECTION II

TM 5-3895-360-24P

| (1)     | (2)      | (3)   | (4)         | (5)                                                      | (6) |
|---------|----------|-------|-------------|----------------------------------------------------------|-----|
| ITEM NO | SMR CODE | CAGEC | PART NUMBER | DESCRIPTION AND USABLE ON CODES(UOC)                     | QTY |
|         |          |       |             | GROUP 0101 CRANKCASE, BLOCK<br>CYLINDER HEAD             |     |
|         |          |       |             | FIG. 2 CRANK CASE BLOCK CYLINDER<br>HEAD                 |     |
| 1       | PFFZZ    | 93334 | A237010     | CYLINDER,ENGINE1GAS.....                                 | 1   |
| 2       | PFFZZ    | 93334 | 31146       | •SEAL .....                                              | 1   |
| 3       | PAFZZ    | 93334 | 1459        | SCREW;MACHINE .....                                      | 4   |
| 4       | KFFZZ    | 93334 | 249277-1    | GASKET, BEARING CAGE PART OF KIT P/N.....<br>35173 ..... | 1   |
| 5       | PFFZZ    | 93334 | A249038     | SUPPORT; CRANKSHAFT .....                                | 1   |
| 6       | PFFZZ    | 93334 | 31013       | •BEARING;TROLLER ;NEED.....                              | 1   |
| 7       | PFFZZ    | 93334 | 2788004     | •STUD; PLAIN . .....                                     | 4   |
| 8       | PFFZZ    | 93334 | 30146       | •SEAL .....                                              | 1   |
| 9       | PAFZZ    | 93334 | 2003        | SCREW, ASSEMBLED WAS .....                               | 6   |
| 10      | KFFZZ    | 93334 | 2770159-2   | GASKET, REED PLATE PART OF KIT P/N.....<br>35173 .....   | 1   |
| 11      | PFFZZ    | 93334 | A2775158    | PLATE ASSEMBLY; REED.....                                | 1   |
| 12      | PFFZZ    | 93334 | 1755        | •SCREW; ASSEMBLED WAS .....                              | 1   |
| 13      | PFFZZ    | 93334 | 27161       | •STOP, REED ENG.EXHAU .....                              | 1   |
| 14      | PFFZZ    | 93334 | 27160       | •REED, ENGINE EXHAUST .....                              | 1   |
| 15      | PFFZZ    | 93334 | 19209-2     | •STUD.....                                               | 2   |
| 16      | PAFZZ    | 93334 | 1490        | NUT; PLAIN;HEXAGON .....                                 | 2   |
| 17      | PAFZZ    | 93334 | 1472        | SCREW, ASSEMBLED WAS .....                               | 4   |

END OF FIGURE



TA705261

FIGURE 3. CRANKSHAFT.

## SECTION II

TM 5-3895-360-24P

| (1)                   | (2)   | (3)   | (4)      | (5)                                  | (6) |
|-----------------------|-------|-------|----------|--------------------------------------|-----|
| ITEM                  | SMR   |       | PART     |                                      |     |
| NO                    | CODE  | CAGEC | NUMBER   | DESCRIPTION AND USABLE ON CODES(UOC) | QTY |
| GROUP 0102 CRANKSHAFT |       |       |          |                                      |     |
| FIG. 3 CRANKSHAFT     |       |       |          |                                      |     |
| 1                     | PFFZZ | 93334 | A2761018 | CRANKSHAFT; ENGINE.....              | 1   |
| 2                     | PFFZZ | 93334 | 30410    | RING;RETAINING .....                 | 1   |
| 3                     | PFFZZ | 93334 | 127910-2 | BEARING; BALL;ANNULA.....            | 1   |
| 4                     | PFFZZ | 93334 | 2770410  | RING; RETAINING.....                 | 1   |

END OF FIGURE