

LUBRICATION
ORDER

2 JULY 1973 (Supersedes L0 5-2420-221-12-2 dated 22 JANUARY 1971)

TRACTOR, WHEELED INDUSTRIAL; D E D 2 SINGLE FRONT WHEELS,
NON DRIVING STEERABLE; 2 SINGLE REAR WHEELS DRIVING,
NON-STEERABLE, W/15 CU FOOT FRONT END LOADER AND
22 INCH WIDE BACKHOE (J. I. CASE MODEL M480CK)
W/ENGINE J. I. CASE MODEL 188

Reference: L0 5-2420-221-12-1 and FEDERAL SUPPLY CATALOG C9100-IL

Intervals are based on normal hours of operation. Adjust to compensate for abnormal operation and severe conditions. During inactive periods, sufficient lubrication must be performed for adequate preservation.

Clean fittings before lubricating.

Relubricate after washing or fording.

Clean parts with SOLVENT, dry-cleaning, or with OIL, fuel, Diesel. Dry before lubricating.

A dotted circle indicates a drain below.

Lubricate points indicated by dotted arrow shafts on both sides of equipment.

Drain crankcases and gear cases when hot. Fill and check level.

FOLD

FOLD

LUBRICANT ● INTERVAL

INTERVAL ● LUBRICANT

