

LOADER, SCOOP TYPE: DIESEL ENGINE; 4 WHEEL DRIVE
 REAR WHEEL STEERABLE PNEUMATIC TIRES; 2-1/2
 CU. YD.; W/MULTI-SEGMENT BUCKET (FRANK
 G. HOUGH MODEL H-90CM) W/ENGINE
 CUMMINS MODEL JT-6-B1

Reference: LO5 3805-201-12-1 C9100-IL

Intervals are based on normal hours of operations. Adjust to compensate for abnormal operations and severe conditions. During inactive periods, sufficient lubrication must be performed for adequate preservation.

Clean fittings before lubricating,

Relubricate after washing or fording.

Clean parts with SOLVENT, dry-cleaning, or with OIL, Fuel; Diesel. Dry before lubricating.

Lubricate points indicated by dotted arrow shafts on both sides of equipment.

Drain gearcases when hot. Fill and check level.

