

LOADER, SCOOP TYPE, D.E.D., 4 WHEEL DRIVE, PNEUMATIC TIRES,
HINGED FRAME STEER, W/FORKLIFT FRONT MOUNTED,
HYDRAULIC OPERATED, 10,500 LB CAPACITY (EATON
YALE & TOWN, TROJAN MODEL 3000M) W/ENGINE
CUMMINS MODEL C-180-CI

Reference: LO 5-3805-243-12-2 and C9100-IL

Intervals are based on normal hours of operations. Adjust to compensate for abnormal operations and severe conditions. During inactive periods, sufficient lubrication must be performed for adequate preservation.

Clean parts with SOLVENT, dry-cleaning, or with OIL, fuel, Diesel. Dry before lubricating.

Clean fittings before lubricating.

Lubricate points indicated by dotted arrow shafts on both sides of equipment

Relubricate after washing or fording.

Drain crankcase, gearcases when hot. Fill and check level.

A dotted circle indicates a drain below.

FOLD

FOLD

