

GRADER, ROAD MOTORIZED: DIESEL DRIVEN, 12 FT
BLADE (CATERPILLAR MODEL 12) W/CATER-
PILLAR ENGINE MODEL D-333NA

Reference: LO 5-3805-209-20-2, 3 and 4 C9100-IL

Intervals are based on normal hours of operation. Reduce to compensate for abnormal operation and severe conditions. During inactive periods, sufficient lubrication must be performed for adequate preservation.

Clean parts with SOLVENT, dry-cleaning, or with OIL, fuel, Diesel. Dry before lubricating.

Clean fittings before lubricating.

Lubricate points indicated by dotted arrow shafts on both sides of equipment.

Relubricate after washing or fording.

A dotted circle indicates a drain below.

Drain gearcase and crankcase when hot. Fill and check level.

FOLD

FOLD

