

AIR FORCE
ARMY
NAVY PUBLICATION
MARINE CORPS

TO 35C2-3-442-14
TM5-6115-600-24P
NAVFAC P-3-628-24P
SL-4-07464B

TECHNICAL MANUAL

ORGANIZATIONAL, INTERMEDIATE (FIELD)(DIRECT AND GENERAL SUPPORT) AND DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD. 100 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS

BASIC AND ALL CHANGES HAVE BEEN MERGED TO MAKE THIS A COMPLETE PUBLICATION

DOD MODEL
MEP007B

CLASS
PRECISE

HERTZ
50/60

NSN
6115-01-036-6374

INCLUDING OPTIONAL KITS

DOD MODEL
MEP007BWF
MEP007BWE
MEP116AQM

NOMENCLATURE
WINTERIZATION KIT, FUEL BURNING
WINTERIZATION KIT, ELECTRIC
WHEEL MOUNTING KIT

NSN
6115-01-131-7228
6115-01-135-6165
6115-01-135-6165

DISTRIBUTION STATEMENT A - Approved for public release; distribution is unlimited.

Published Under the Authority of the Secretary of the Air Force, Army, Navy, and Marine Corps

4 MAY 1992

CHANGE 4 - 21 DECEMBER 2001

TABLE OF CONTENTS

		Page	Illustration
Section I	Introduction	1-1	
Section II	Repair Parts List	2-1	
Group 01	Housing		
	0101 Housing Doors and Covers	2-1	1
	0102 Identification Plates	2-5	2
	0103 Front Housing Panel and Related Parts	2-7	3
	0104 Rear Housing Panel and Related Parts	2-9	4
	0105 Document Stowage box, Tool Box, and Related Parts	2-11	5
	0106 Generator Set Wrench Assembly and Related Parts	2-13	6
Group 02	DC Electrical and Control System		
	0201 Batteries and Related Parts	2-15	7
	0202 Slave Receptacles	2-17	8
	0203 Alternator Guard, Belt, and Related Parts	2-19	9
	0204 Battery Charging Alternator	2-21	10
	0205 DC Electrical Wiring Harness	2-25	11
	0206 Speed Switch and Magnetic Pickup	2-33	12
	Speed Switch and Magnetic Pickup Alternate P/N 90-4002	2-35	13
	0207 Low Oil Pressure and High Coolant Temperature Switches	2-37	14
	0208 DC Circuit Breaker	2-39	15
	0209 Starter Motor	2-41	16
	0210 Electrical Shutoff	2-45	17
Group 03	Set Control and Instrumentation		
	0301 Fault Indicator Assembly and Related Parts	2-47	18
	0302 Control Cubicle Assembly	2-51	19
	0303 Throttle Cable Assembly	2-59	20
	0304 Coolant Temperature, Oil Pressure, and Fuel Level Transmitters	2-61	21
Group 04	AC Electrical Control System		
	0401 Tactical Relay Box Assembly and Related Parts	2-63	22
	0402 Special Relay Box and Related parts	2-67	23
	0403 Exciter-Regulator and Related Parts	2-73	24
	0404 Voltage Regulator Assembly	2-77	25
	0405 Reconnection Terminal Board Assembly and Related Parts	2-85	26
	0406 Circuit Breaker Assembly	2-89	27
	Alternate Circuit Breaker	2-92	28
	0407 Load Terminal Board and Related Parts	2-93	29
	0408 Convenience Receptacle and Related Parts	2-95	30
	0409 Current Transformer Assembly	2-97	31
	0410 Load Measuring Unit and Related Parts	2-99	32
	0411 AC Electrical Wiring Harness	2-101	33

AIR FORCE	T.O.35C2-3-442.14
ARMY	TM 5-6115-60-24P
NAVY	NAVFAC P-8-628-24P
MARINE CORPS	SL-4-07464B

TABLE OF CONTENTS (Continued)

		Page	Illustration
Group 05	Fuel System		
	0501 Fuel Filter and Pump Assembly and Related Parts	2-109	34
	0502 Fuel Lines and Filter and Related Parts	2-113	35
	0503 Day Tank, Ether Kit, and Related Parts	2-115	36
	0504 Fuel Lines and Related Parts	2-119	37
	0505 Fuel Tank Assembly	2-125	38
	0506 Fuel Priming Pump	2-127	39
	0507 Fuel Injection Pump	2-129	40
	0508 Fuel Injection Valves and Lines	2-135	41
	0509 Filter Neck and Cap	2-137	42
Group 06	Exhaust and Breather System		
	0601 Exhaust and Breather System	2-139	43
Group 07	Cooling System		
	0701 Radiator and Shutter Assembly and Related Parts	2-143	44
	0702 Water Pump	2-147	45
	0703 Water Lines	2-149	46
	0704 Coolant Thermostat	2-151	47
	0705 Fan Belts	2-153	48
Group 08	Lifting and Support System		
	0801 Lifting Frame	2-155	49
	0802 Control Panel Supports	2-157	50
Group 09	Power Generation System		
	0901 Generator Assembly and Related Parts	2-159	51
	0902 Generator Assembly	2-161	52
Group 10	Engine		
	1001 Air Cleaner and Related Parts	2-169	53
	1002 Air Lines	2-171	54
	1003 Turbocharger	2-173	55
	1004 Governor Fastener	2-179	56
	1005 Governor Drive	2-181	57
	1006 Governor	2-191	58
	1007 Engine Fan and Related parts	2-199	59
	1008 Engine Oil Cooler	2-201	60
	1009 Oil Filter	2-203	61
	1010 Damper, Crankshaft Pulley, Trunnion, and Trunnion Support	2-207	62
	1011 Exhaust Manifold	2-209	63
	1012 Valve Mechanism Cover	2-211	64
	1013 Valve Mechanism and Attaching Parts	2-213	65
	1014 Cylinder Head Assembly and Related Parts	2-217	66

AIR FORCE
ARMY
NAVY

T.O.35C2-3-442.14
TM 5-6115-60-24P
NAVFAC P-8-628-24P

Group 10 (Cont)	1015	Oil Pan	2-219	67
	1016	Engine Oil Lines	2-221	68
	1017	Engine Oil Pump	2-223	69
	1018	Connecting Rod and Piston	2-227	70
	1019	Flywheel and Flywheel Housing	2-229	71
	1020	Front Housing Cover	2-231	72
	1021	Battery Charging Alternator Mounting	2-233	73
	1022	Front Housing Fastener	2-235	74
	1023	Front Housing	2-237	75
	1024	Timing Gears	2-239	76
	1025	Camshaft	2-241	77
	1026	Crankshaft and Crankshaft Seal	2-243	78
	1027	Oil Filter and Related Parts	2-245	79
	1028	Cylinder Block	2-247	80
Group 11	Support System			
	1101	Skid Base	2-251	81
Group 12	Fuel Burning Winterization Kit			
	1201	Fuel Burning Winterization Kit	2-255	82
Group 13	Electrical Winterization Kit			
	1301	Electrical Winterization Kit	2-269	83
Group 14	Bulk Materials			
	1401	Bulk Materials List	2-281	
Group 15	1501	Wheel Mounting Kit	2-283	84
		Wheel Assembly – Wheel Mounting Kit	2-285	85
		Rear Axle Assembly – Wheel Mounting Kit	2-287	86
		Front Axle Assembly – Wheel Mounting Kit	2-289	87
		Brake Assembly – Wheel Mounting Kit	2-293	88
		Handbrake and Shaft Assembly	2-295	89
Section III	Special Tools List		3-1	
Section IV	NSN, Reference Number Index		4-1	
Section V	Reference Designator Index		5-1	

LIST OF ILLUSTRATIONS

Figure	Title	Page
1.	Housing Doors and Covers	2-0
2.	Identification Plates	2-6
3.	Front Housing Panel and Related Parts	2-8
4.	Rear Housing Panel and Related Parts	2-10
5.	Document Stowage Box, Tool Box, and Related Parts	2-12
6.	Generator Set Wrench Assembly and Related Parts	2-14
7.	Batteries and Related Parts	2-16
8.	Slave Receptacles	2-18
9.	Alternator Guard, Belt, and Related Parts	2-20
10.	Battery Charging Alternator	2-22
11.	DC Electrical Wiring Harness	2-26
12.	Speed Switch and Magnetic Pickup	2-34
13.	Speed Switch and Magnetic Pickup	2-36
14.	Low Oil Pressure and High Coolant Temperature Switches	2-38
15.	DC Circuit Breaker	2-40
16.	Starter Motor	2-42
17.	Electrical Shutoff	2-46
18.	Fault Indicator Assembly and Related Parts	2-48
19.	Control Cubicle Assembly	2-52
20.	Throttle Cable Assembly	2-58
21.	Coolant Temperature, Oil Pressure, and Fuel Level Transmitters	2-60
22.	Tactical Relay Box Assembly and Related Parts	2-62
23.	Special Relay Box and Related Parts	2-66
24.	Exciter-Regulator and Related Parts	2-72
25.	Voltage Regulator Assembly	2-78
26.	Reconnection Terminal Board Assembly and Related Parts	2-84
27.	Circuit Breaker Assembly	2-88
28.	Alternate Circuit Breaker (Load Contractor Assembly)	2-92
29.	Load Terminal Board and Related Parts	2-94
30.	Convenience Receptacle and Related Parts	2-96
31.	Current Transformer Assembly	2-98
32.	Load Measuring Unit and Related Parts	2-100
33.	AC Electrical Wiring Harness	2-102
34.	Fuel Filter and Pump Assembly and Related Parts	2-110
35.	Fuel Lines and Filter and Related Parts	2-114
36.	Day Tank, Ether Kit, and Related Parts	2-116
37.	Fuel Lines and Related Parts	2-118
38.	Fuel Tank Assembly	2-124
39.	Fuel Priming Pump	2-126
40.	Fuel Injection Pump	2-128
41.	Fuel Injection Valves and Lines	2-136
42.	Filler Neck and Cap	2-138
43.	Exhaust Breather System	2-140
44.	Radiator and Shutter Assembly and Related Parts	2-142
45.	Water Pump	2-146
46.	Water Lines	2-150
47.	Coolant Thermostat	2-152
48.	Fan Belts	2-154

LIST OF ILLUSTRATIONS (Continued)

Figure	Title	Page
49.	Lifting frame	2-156
50.	Control Panel Supports	2-158
51.	Generator Assembly and Related Parts	2-160
52.	Generator Assembly	2-162
53.	Air Cleaner and Related Parts	2-170
54.	Air Lines	2-172
55.	Turbocharger	2-174
56.	Governor Fastener	2-178
57.	Governor Drive	2-182
58.	Governor	2-190
59.	Engine Fan and Related Parts	2-198
60.	Engine Oil Cooler	2-200
61.	Oil Filter	2-202
62.	Damper, Crankshaft Pulley, Trunnion, and Trunnion Support	2-208
63.	Exhaust Manifold	2-210
64.	Valve Mechanism Cover	2-212
65.	Valve Mechanism and Attaching Parts	2-214
66.	Cylinder Head Assembly and Related Parts	2-216
67.	Oil Pan	2-220
68.	Engine Oil Lines	2-222
69.	Engine Oil Pump	2-224
70.	Connecting Rod and Piston	2-226
71.	Flywheel and Flywheel Housing	2-228
72.	Front Housing Cover	2-230
73.	Battery Charging Alternator Mounting	2-232
74.	Front Housing Fastener	2-234
75.	Front Housing	2-236
76.	Timing Gears	2-238
77.	Camshaft	2-240
78.	Crankshaft and Crankshaft Sea	2-242
79.	Oil Filler and Related Parts	2-244
80.	Cylinder Block	2-246
81.	Skid Base	2-250
82.	Fuel Burning Winterization Kit	2-254
83.	Electrical Winterization Kit	2-268
84.	Wheel Mounting Kit	2-282
85.	Wheel Assy - Wheel Mounting Kit	2-286
86.	Rear Axle Assy - Wheel Mounting Kit	2-288
87.	Front Axle Assy - Wheel Mounting Kit	2-290
88.	Brake Assy - Wheel Mounting Kit	2-292
89.	Hand Brake and Shaft Assy	2-294
90.	Special Tools List	3-0

Example 1

SECTION II. REPAIR PARTS FOR ORGANIZATIONAL, INTERMEDIATE (FIELD), (DIRECT AND GENERAL SUPPORT) AND DEPOT MAINTENANCE

(1) ILLUS- TRATION		(2) SMR CODE				(3) USMC		(4)	(5) DESCRIPTION		(6)	(7)	(8)
a	b	a	b	c	d	a	b	NATIONAL	REF NUMBER	USABLE	U/M	QTY	USMC
FIG	ITEM	ARMY	AIR	NAVY	USMC	SSI	REPL	STOCK	& MFR CODE	ON		INC	QTY
NO.	NO.		FORCE				FACTOR	NUMBER		CODE		IN	PER
												UNIT	EQUIP
9									GROUP 02- DC ELECTRICAL AND CONTROL SYSTEM				
9	1	PAOZZ	PAOZZ	PAFZZ	PAFZZ	D	.008	5306-00- 225-8497	SCREW, HEX HEAD MS90725-32	96906	EA	1	28
9	2	PAOZZ	PAOZZ	PAFZZ	PAFZZ	D	.010	5310-00- 407-9566	WASHER, LOCK MS35338-45	96906	EA	2	67
9	3	XBOZZ	XBOZZ	XBFZZ	XBFZZ				GUARD, FAN, ALTERNATOR 76-4139	30554	EA	1	1
9	4	PAOFF	PAOZZ	PAOZZ	PAOZZ	D	.035		BELT, ALTERNATOR DRIVE 71-4938-03	30554	EA	1	1
									5-8113	20796			

EXAMPLE 2

JOINT MILITARY SERVICES UNIFORM SMR CODING MATRIX

SOURCE		MAINTENANCE		RECOVERABILITY	ERRC CODE
1st Position	2nd Position	3rd Position	4th Position	5th Position	6th Position
	A Stocked		Z No Repair	Z Nonreparable Condemn by 3rd Position Level	N Nonrecoverable XB3 Condemn by Any Level
	B Insurance				
	C Deteriorative				
P Procurable	E Support Equipment, Stocked	O Remove/ Replace by Organiza- tional level	B No Repair Recondition	O Repairable Condemn by Organizational (or Field or Depot)	P Recoverable XF3 Condemn by Field
	F Equipment, Nonstocked				
	G Life of System Support				C Recoverable XD1 (SCARS) Condemn by Depot

EXAMPLE 1 -

SMR CODE with line and pointer leading to EXAMPLE 2 (JOINT MILITARY SERVICES UNIFORM SMR CODING MATRIX), indicates Army, Air Force, Navy and Marine Corps multi-service matrix.

EXAMPLE 2 -

Reference the circled item (PAOZZ), the connecting lines, pointers and circles define the SMR CODE: PAOZZ.