

DEMOLITION KIT, MINE CLEARING LINE CHARGE (MICLIC)
Reference TM 9-1375-215-14&P


REPORTING OF ERRORS

You can improve this publication by calling attention to errors and by recommending improvements and by stating your reasons for the recommendations. Your letter or DA Form 2028, Recommended Changes to Publications and Forms, should be mailed directly to Commander, U.S. Army Armament, Munitions and Chemical Command, ATTN: SMCAR-LMB, Picatinny Arsenal, NJ 07806-5000. A reply will be furnished directly to you.

NOTE

The lowest level of maintenance authorized to lubricate a point is Operator/Crew (C).

LUBRICATION POINT	LUBRICANT	INTERVAL	TOTAL MAN-HR	
Launcher Rail Groove	G A A	AQ	INTERVAL	MAN-HR
Hand Knob Assembly	OEA or OE/HDO	AQ	B - Before Use	0.1
Rocket Release Cam	OEA or OE/HDO	AQ	A - After Use	0.2
Rocket Release Mechanism	OEA or OE/HDO	AQ	Q - Quarterly	0.2
Joint	OEA or OE/HDO	AQ		
Hydraulic Hand Pump	OHT	BAQ		



ARD 2694

LAUNCHER ASSEMBLY - TOP VIEW

Approved for public release; distribution unlimited.