

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LIST

FOR
DIGITAL MULTIMETER, TEKTRONIX MODEL DM501A
(NSN 6695-01-075-8583)
Current as of 5 December 1979

Headquarters, Department of the Army, Washington, DC
9 January 1980

REPORTING OF ERRORS

You can help improve this publication by calling attention to errors and by recommending improvements and stating your reasons for the recommendations. Your letter or DA Form 2028, Recommended Changes to Publications, should be mailed directly to Commander, US Army Missile Command, ATTN: DRSMI-MFM, Redstone Arsenal, AL 35809. A reply will be furnished directly to you.

			Paragraph	Page
SECTION I.	INTRODUCTION			
	Scope		1	1
	General.....		2	1
	Explanation of columns		3	1
	Special information.....		4	5
	How to locate repair parts		5	5
	Abbreviations.....		6	6
II.	REPAIR PARTS LIST			9
	Functional group title	Group No.	Model No.	Part No.
	6695	Digital Multimeter	DM501A	MIS30526/4
III.	NATIONAL STOCK NUMBER AND PART NUMBER INDEX-----			11

Section I INTRODUCTION

1. Scope. This manual lists spares and repair parts that are required for maintenance of the Digital Multimeter, Tektronix Model DM501A. It authorizes requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General. This repair parts and special tools list (RPSTL) is divided into the following sections:

a. Section I. Introduction.

b. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence. Bulk materials are listed in National Stock Number (NSN) sequence.

c. Section III. NSN and Part Number be coded Index. A list, in National Item Identification Number (NIIN) sequence, of all NSN's appearing in the listings, followed equipment, procured for initial by a list in alphameric sequence of all part numbers appearing in the listings. part numbers appearing in the listings. NSN's and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) Figure Number. Indicates the figure number of the illustration on which the item is shown.

(2) Item Number. The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) Source Code. Source codes indicate the manner of acquiring support items for maintenance, repair, overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows

Code	Definition
PA -	Item procured and stocked for anticipated or known usage.
PB -	Item procured and stocked for insurance purpose because essentially dictates that a minimum quantity be available in the supply system.
PC -	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
PD -	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent of additional initial issues or outfitting. Not subject to automatic replenishment.
PE -	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF -	Support equipment which will not be stocked but which will be centrally procured on demand.