

TECHNICAL MANUAL

**DIRECT SUPPORT AND GENERAL SUPPORT
MAINTENANCE MANUAL
(Including Repair Parts and Special Tools List)**

DEMOLITION MATERIALS

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited.

HEADQUARTERS, DEPARTMENT OF THE ARMY

FEBRUARY 1996

Technical Manual)
)
 No. 9-1375-213-34&P)

HEADQUARTERS
 DEPARTMENT OF THE ARMY
 Washington DC, 29 February 1996

**DIRECT SUPPORT AND GENERAL SUPPORT
 MAINTENANCE MANUAL
 (Including Repair Parts and Special Tools List)
 DEMOLITION MATERIALS**

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. You may mail, e-mail, or FAX your response. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, U.S. Army TACOM, Armament Research, Development and Engineering Center, ATTN: AMSTA-AR-LSB, Picatinny Arsenal, NJ 07806-5000. E-mail address is LSB@PICA.ARMY.MIL. FAX number is Commercial (201) 724-4633, DSN 880-4633. A reply will be furnished to you.

	Page
CHAPTER 1. INTRODUCTION	
Section I. General	
1-1. Scope	1-1
1-2. Forms, Records, and Reports	1-1
Section II. Description and Data	
1-3. General	1-1
Section III. Safety, Care, and Handling	
1-4. General	1-1
CHAPTER 2. TOOLS AND EQUIPMENT	
2-1. General	2-1
2-2. Tools and Equipment	2-1
2-3. Repair Parts	2-1
CHAPTER 3. INSPECTION REQUIREMENTS	
3-1. General	3-1
3-2. Visual Inspection of Incoming Ammunition	3-1
CHAPTER 4. MAINTENANCE PROCEDURES	
4-1. General	4-1
4-2. Direct Support Maintenance	4-1
4-3. General Support Maintenance	4-1

*This manual supersedes TM 9-1375-213-34, 30 March 1973, including all changes.

CHAPTER 4.	MAINTENANCE PROCEDURES - Continued	Page
4-4.	Rust Removal and Touchup	4-1
4-5.	Repainting	4-3
4-6.	Re-marking	4-4
4-7.	Inspecting and Reconditioning Packing Box	4-17
4-8.	Inspecting Barrier Bag	4-17
4-9.	Repacking	4-17
4-10.	Palletizing	4-18
4-11.	Special Procedure for Cleaning and Repacking of 15-pound Shaped Charges	4-20
4-12.	Color Coding Boxes With Light Loads	4-21
4-13.	Blasting Machine Maintenance	4-21
 APPENDIX	 A. REFERENCES	 A-1
	B. DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST	B-1
	C. EXPENDABLE AND DURABLE ITEMS LIST	C-1
	D. PACKING MATERIALS, ACCESSORIES, AND TOOLS	D-1

CHAPTER 1 INTRODUCTION

Section I. GENERAL

1-1. Scope

a. This technical manual describes general and technical information, and inspection and maintenance procedures for demolition materials. Information in this manual covers the responsibilities of direct and general support maintenance personnel (i.e., maintenance which is beyond the scope of the tools, equipment, or supplies normally available to operator and unit personnel).

b. Information for operator and unit maintenance personnel is covered in TM 9-1375-213-12, which includes the Maintenance Allocation Chart (Appendix C). Direct support and general support maintenance responsibilities are specified in the Maintenance Allocation Chart. This manual should be used in conjunction with TM 9-1375-213-12.

c. Field service stocks including basic load will be checked for serviceability as directed by USA Industrial Operations Command (IOC), Rock Island, IL using the inspection and function test procedures of SB 742-1 and the specific supply bulletins and supporting supply bulletins listed in Appendix A under the direction of the cognizant QASAS. The field-expedient methods and equipment detailed in previous editions of this TM are no longer authorized.

1-2. Maintenance Forms, Records, and Reports

Forms generally applicable to units maintaining subject materiel are listed in Appendix A. For a current listing of all forms, refer to DA Pam 25-30. Refer to DA Pam 738-750 for instructions on use and completion of all forms required for maintaining demolition materials.

Section II. DESCRIPTION AND DATA

1-3. General

For detailed description and data of demolition items and accessories, refer to TM 9-1375 213-12.

Section III. SAFETY, CARE, AND HANDLING

1-4. General

For detailed information on safety, care, and handling of demolition items and accessories, refer to TM 9-1375-213-12 and TM 9-1300-206.