TM 11-6625-540-40P

TECHNICAL MANUAL

GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)

OSCILLOSCOPE AN/USM-32

(FSN 6625-519-1954)

HEADQUARTERS, DEPARTMENT OF THE ARMY

JANUARY 1975

TECHNICAL MANUAL
No. 11-6625-540-40P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C. *31 January 1975*

General Support Maintenance Repair Parts and Special Tools Lists (Including Depot Maintenance Repair Parts and Special Tools)

OSCILLOSCOPE AN/USM-32 (FSN 6625-519-1954)

Current as of 20 November 1974

			Paragraph	Page
SECTION	I.	INTRODUCTION		
		Scope	1-1	2
		General	1-2	2
		Explanation of columns	1-3	2
		Special information	1-4	4
		Location of repair parts	1-5	4
		Abbreviations (Not applicable)	1-6	5
		Reporting of equipment publication improvements	1-7	5
	II.	REPAIR PARTS LIST		6
	III.	SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable)		
	IV.	INDEX—FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS-REFERENCE TO FIGURE AND ITEM NUMBER		31

*This manual, together with TM 11-6625-540-20P, 31 January 1975, supersedes SIG 7 & 8 AN/USM-32, 21 April 1958, including all changes.

SECTION I.

INTRODUCTION

1-1. Scope

This manual lists repair parts and special tools required for the performance of general support and depot maintenance of the AN/USM-32. The PCCN for the AN/USM-32 is GTEACG for all models.

NOTE

No parts authorized for stockage at direct support.

1-2. General

This repair parts and special tools list is divided into the following sections:

a. Repair Parts List-Section II. A list of repair parts authorized for the Performance of maintenance at the general support and depot level. This repair parts list is arranged in alphabetical order.

b. Special Tools, Test and Support Equipment-Section III. Not applicable.

c. Index--Federal Stock Number and Reference Number Cross-Reference to Figure and ***Item Number—Section IV*. A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphanumeric sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure figure and item number or reference designation appearance.**

1-3. Explanation of columns

The following provides an explanation of columns found in the tabular list.

a. Source, Maintenance, and Recoverability Codes (SMR).

(1) *Source code*. Indicates the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are:

Code	*Explanation*
PA—	**Item procured and stocked for anticipated or known usage.**
PB--	Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply systems.
PC--	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
PD--	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic re- plenishment.
PE--	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF--	Support equipment which will not be stocked but which will be centrally procured on demand.
PG--	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which because of probable discontinuance or shutdown of production facilities would prove uneconomical to reproduce at a later time.
KD--	An item of depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
KF—	**An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or direct support or general support levels of maintenance.**
KB--	**Item included in both a depot overhaul/repair kit and a maintenance kit.**
MO—	**Item to be manufactured or fabricated at organizational level.**
MF—	**Item to be manufactured or fabricated at direct support maintenance level.**