LUBRICATION ORDER

LO10-4320-202-12

10 JUNE 1977

(Supersedes LO10-4320-202-15 dated 28 April 1967)

PUMPING ASSEMBLY, FLAMMABLE LIQUID, BULK TRANSFER, 50 GPM (BARNES MODEL 9117CA) ARMY MODEL SPE 16 (BARNES MODEL 15671CA) ARMY MODEL SPE 16A (BARNES MODEL 4074CA) W/WISCONSIN ENGINE MODEL AKND

Reference: C9100-IL

Intervals and related task-hour times are based on normal hours of operation. The task-hour time specified is the time you need to do all the services prescribed for a particular interval. Change the interval if your lubricants are contaminated or if you are operating the equipment under adverse operating conditions, including longer-than-usual operating hours. You may extend the interval during periods of low activity, but you must take adequate preservation precautions.

*The time specified is the time required to perform all services at the particular interval.

Clean fittings before lubricating. Relubricate all areas exposed to water after amphibious operation. Lubricate points indicated by dotted arrow shaft on both sides of equipment. Clean parts with SOLVENT, dry cleaning, or with OIL, fuel, diesel. Dry before lubricated. Drain crankcase when HOT. Fill and check level. The lowest level of maintenance authorized to lubricate a point is indicated by one of the following: (C) operator/crew, or (O) organizational maintenance.

You can improve this publication by calling attention to errors and by recommending improvements and by stating your reasons for the recommendations. Your letter or DA Form 2028 (Recommended Changes to Publications and Forms) should be mailed directly to Commander, U. S. Army Troop Support Command, ATTN: DRSTS-MPP, 4300 Goodfellow Blvd., St. Louis, MO 63120. A reply will be furnished directly to you.

FOLD FOLD

LUBRICANT • INTERVAL

INTERVAL • LUBRICANT

Air Cleaner (Refill oil reservoir to level mark; every 25 hours, 250 miles, or weekly, disassembly entire unit, clean, re-oil and reassemble.) (See Note 2) — OE D



W — Crankcase Drain Plug (Drain and refill)

D OE — Crankcase Fill and Level Plug (Check level) (See Key)

*TOTAL TASK HOURS	
INTERVAL	TASK-HOURS
D	0.5

*TOTAL TASK HOURS	
INTERVAL	TASK-HOURS
W	1.5