

TECHNICAL MANUAL

**DIRECT SUPPORT AND GENERAL SUPPORT
MAINTENANCE MANUAL**

**RADAR SET ANITPS-25
(NSN 5840-00-082-4128)**

HEADQUARTERS, DEPARTMENT OF THE ARMY

29 OCTOBER 1982

TECHNICAL MANUAL

No. 11-5840-217-34-1

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, DC, 29 October 1982DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE MANUAL
RADAR SET AN/TPS-25
(NSN 5840-00-082-4128)

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, US Army Communications-Electronics Command and Fort Monmouth, ATTN: DRSEL-ME-MP, Fort Monmouth, New Jersey 07703.

In either case, a reply will be furnished direct to you.

TABLE OF CONTENTS

		<u>Paragraph</u>	<u>Page</u>
Chapter	1.	SYMBOLS AND COLOR CODES	
		Conventional symbols	1-1 1
		Color coding for capacitors and resistors	1-2 7
		Fuses and their functions	1-3 11
		Continuity checks	1-4 11
Chapter	2.	PREOPERATIONAL ADJUSTMENTS AND START-STOP PROCEDURES	
		General	2-1 12
		Preoperational adjustments	2-2 12
		Starting procedure	2-3 13
		Stopping procedure	2-4 13

* This manual supersedes TM 11-5840-217-34-1, dated 18 January 1982.

TABLE OF CONTENTS - Continued Page

	<u>Paragraph</u>	<u>Page</u>
Chapter 3.	SYMPTOMS COLLECTION PROCEDURES	
	Troubleshooting the AN/TPS-25A	
	radar set	3-1 15
	Symptoms collection example	3-2 15
	Overall systems checks	3-3 17
	AC distribution checks	3-4 21
	Low-voltage power supply checks	3-5 23
	Antenna positioning system checks	3-6 25
	Computer system checks	3-7 27
	Transmitter and RF systems checks	3-8 29
	Transmitter control circuit checks	3-9 31
	Receiver-transmitter power supply checks	3-10 32
	Receiver system checks	3-11 34
	Scope timing and range sweep checks	3-12 35
	Video, audio, vertical deflection, and high-voltage checks	3-13 36
Chapter 4.	DIAGRAMS	
	AN/TPS-25A radar block diagram	37-38
	Equipment shelter AC power distribution box	39

	<u>Paragraph</u>	<u>Page</u>
Chapter 4.	DIAGRAMS--Continued	
	Level lights control circuit	40
	AC distribution circuit diagram	41-46
	27-volt DC distribution	47-49
	Low-voltage power supply PP-2166/TPS-25	51-52
	Transmitter and RF systems block diagram	53-54
	Transmitter control circuits, simplified	55-56
	High-voltage, trigger generator, and modulator channels	57-58
	Transmitter and RF systems circuit diagram	59-60
	Feedhorn switching circuits	61-62
	Receiver system block diagram	63-64
	Transmitter, RF, and frequency converter circuits	65-66
	IF channel circuit diagram	67-68
	AFC channel circuit diagram	69-70
	Receiver-transmitter power supply circuit diagram	71-72
	28-VAC distribution and receiver filaments	73-74
	Range and scope timing block diagram	75-76
	Video, audio, vertical deflection, and high-voltage block diagram	77-78
	Range gate channel circuit diagram	79-80
	Scope timing channel circuit diagram	81-82
	Scope sweep channel circuit diagram	83
	Video and vertical deflection channels circuit diagram	85-86
	Audio and AGC channel I circuit diagram	87-88
	Audio and AGC channel II circuit diagram	89-90
	Indicator high-voltage channel circuit diagram	91-92
	Antenna positioning system block diagram	93
	Azimuth servoamplifier block diagram	95-96

	<u>Paragraph</u>	<u>Page</u>
Chapter 4.	DIAGRAMS--Continued	
	Sector scan circuits	97
	Azimuth synchros	99-100
	Azimuth servoamplifier circuit diagram	101-102
	Elevation servoamplifier block diagram	103
	Elevation servo circuit diagram	105-106
	Elevation servoamplifier circuit diagram	107-108
	Computer system block diagram	109-110
	Computer power supply	111-112
	Elevation isolation amplifier circuit diagram	113-114
	Range servoamplifier circuit diagram	115-116
	Azimuth isolation amplifier and null circuits	117-118
	X (easting) servoamplifier circuit diagram	119-120
	Y (northing) servoamplifier circuit diagram	121-122
	Computer data flow chart I	123-124
	Computer data flow chart II	125-126
Chapter 5.	CABLE DIAGRAMS	
	Intercabling diagram	127-128
	Servo data coordinator interwiring diagram	129-130
	Receiver-transmitter interwiring diagram	131-132
	Antenna interwiring diagram	133-134
	Generator schenmatic diagram	135-136
	Transmitting system interwiring diagram	137-139
	Range and scope timing circuits	141-142
	Sweep and audio circuits	143-144
	Radar set control I	145-146
	Radar set control II	147-148

	<u>Paragraph</u>	<u>Page</u>
Chapter 6.	FIELD ADJUSTMENTS	
	+250 VDC adjustment	149
	Rep-rate adjustment	149
	Magnetron current adjustment	149
	Receiver tuning	149
	Sweep width and linearity adjustment	150
	Gate position adjustment	150
	Range calibration	150
	Auto range sweep and range adjustment	150
Chapter 7.	COMPUTER SYSTEM ADJUSTMENTS	
	General	151
	Sequence	151
	Range servoamplifier gain and balance adjustments	151
	X servoamplifier gain and balance adjustments	152
	Y servoamplifier gain and balance adjustments	152
	Computing voltage phase and amplitude balance adjustments	153
	Range pot alinement	153
	RHO pot alinement	153
	Elevation resolver and counter alinement	154
	Elevation resolver driver amplifier adjustments	155
	Map scale alinement	155
	Azimuth resolver and counter alinement	155
	Azimuth resolver amplifier alinement	156
	X and Y counters alinement	156
	Plotting board indicator light focus adjustment	157

NOTES

viii

CHAPTER 1 SYMBOLS AND COLOR CODES

1-1. CONVENTIONAL SYMBOLS

