

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

Organizational Maintenance Repair Parts List
RADIO SET AN/GRC-19Headquarters, Department of the Army, Washington, D.C.
7 May 1969

Current as of February 1969

	Paragraph	Page
SECTION I. INTRODUCTION		
Scope	1	1
General	2	1
Explanation of columns	3	1
Reference publications	4	2
Location of repair parts	5	2
Federal supply codes	6	2
Indexes of publications	7	2
Reporting of equipment publication improvements	8	2
II. PRESCRIBED LOAD ALLOWANCE LIST		3
III. REPAIR PARTS, ORGANIZATIONAL MAINTENANCE		4

SECTION I

INTRODUCTION

1. Scope

This manual contains a list of repair parts required for the performance of organizational maintenance for Radio Set AN/GRC-19.

Note.

No special Tools, Test, and support equipment required.

2. General

This repair parts and special tools list is divided into sections.

a. Prescribed Load Allowance List (PLA), Section II. The PLA is a consolidated listing of repair parts allocated for initial stockage at organizational maintenance category. This is a mandatory minimum stockage allowance.

b. Repair Parts for Organizational Maintenance, Section III. Repair parts authorized for organizational maintenance is included in this section.

3. Explanation of Columns

An explanation of the columns in sections II and III is given below.

a. Source, Maintenance, and Recoverability Codes, Column 1, Section III.

(1) Source code, column 1a. The selection status and source for the listed item is noted here.

Source codes and their explanations are as follows:

Code	Explanation
------	-------------

P..... Applies to repair parts that are stocked in or supplied from the GSA/DSA, or Army supply

system, and authorized for use at indicated maintenance categories.

(2) Maintenance code, column 1b. The lowest category of maintenance authorized to install the listed item is noted here.

Code	Explanation
------	-------------

O..... Organizational Maintenance

(3) Recoverability code, column 1c. The information in this column indicates whether unserviceable items should be returned for recovery or salvage. Recoverability codes and their explanations are as follows:

Note.

When no code is indicated in the recoverability column, the part will be considered expendable.

Code	Explanation
------	-------------

R..... Applies to repair parts and assemblies which are economically repairable at DSU and GSU activities and normally are furnished by supply on an exchange basis.

b. Federal Stock Number, Column 1, Section II, Column 2, Section III. The Federal stock number for the item is indicated in this column.

c. Description, Column 2, Section II, Column 3, Section III. The Federal item name, a five-digit manufacturer's code and a part number are included in this column.

*This manual supersedes 11-5820-295-20P, 15 December 1961.