TM 11-5820-672-35P

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

DS, GS, AND DEPOT MAINTENANCE REPAIR PARTS

AND SPECIAL TOOLS LIST

RADIO SETS AN/GRC-158 and AN/MRC-117

HEADQUARTERS, DEPARTMENT OF THE ARMY

JUNE 1970

TECHNICAL MANUAL)
)
)
)
TM 11-5820-672-35P)

HEADQUARTERS

DEPARTMENT OF THE ARMY

WASHINGTON D. C., 4 June 1970

RADIO SETS AN/GRC-l58 and AN/MRC-ll7

Current as of 3 April 1970

	Paragraph	Page
SECTION I. INTRODUCTION		
Scope	1	I-1
General	2	I-1
Explanation of Columns	3	I-1
Special Infomation	4	I-6
Locating repair parts	5	I-9
Federal supply codes for manufacturers	6	I-10
Recommendations for publication improvements	7	I-13
SECTION II. REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT AND DEPOT MAINTENANCE		II-1

*This manual supersedes TM ll-5820-672-35P, 12 September 1967.

			Page
SECTION II. (cont'd.)	RADIO SET, AN/GRC-158	1	II-1
	INSTALLATION KIT, 775-0367-001	1A1	II-1
	EXTENDED CABLE SET, 775-0361-001	1A2	II-15
	RCVR.-XXMTR. GROUP, 522-4839-001	1A3	II-26
	CABINET, ELECT. EQUIP. CY-6177/GRC	1A3A1	II-26
	ACCESSORY KIT, 553-9878-011	1A3A2	II-74
	ANTENNA KIT, 553-6725-000	1A3A2A1	II-74
	COUPLER ANTENNA, CU-1669-/GRC	1A3A5	II-75
	FILTER, F-1138/GRC	1A3A6	II-75
	POWER SUPPLY, PP-4720/GRC	1A3A7	II-138
	RCVR.-XMTR., RAADIO, RT-98/ARC-102	1A3A8	II-138
		1A3A9	II-138
	CONTROL, 522-4851-001	1 A 4	II-138
	CONTROL, MONITOR GROUP, C-7196/GRC	1A4A1	II-142
	POWER SUPPLY, PP-4721/GRC	1A5	II-182
	CASE, 767-5122-001	1A5A1	II-182
	CABLE ASSEMBLY, CX-10359/G	1A5W1	II-189
	POWER SUPPLY, PP-4526/GRC154	1A5A2	II-191

SECTION III. SPECIAL TOOL, TEST AND SUPPORT EQUIPMENT FOR DIRECT SUPPORT, GENERAL SUPPORT AND DEPOT MAINTENANCE NA

SECTION IV. INDEX-FEDERAL STOCK NUMBER CROSS REFERENCE TO FIGURE AND ITEM NUMBER OR REFERENCE DESIGNATION INDEX IV-1

SECTION I

INTRODUCTION

1. Scope.

This manual lists repair parts and special tools required for the performance of direct support, general support, and depot maintenance of the AN/GRC-158 and AN/MRC-117.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Repair Parts - Section II. A list of repair parts authorized for the performance of maintenance at the direct support, general support and depot level.

b. Special Tools, Test and Support Equipment - Section III. Not applicable.

c. Index-Federal Stock Number Cross Reference to Figure and Item Number or Reference Designation Index - Section IV. A list of all Federal stock numbers in ascending numerical sequence followed by a list of reference numbers in ascending alpha-numeric sequence, cross-referenced to the illustration figure number and item number or reference designation.

3. Explanation of Columns.

The following provides an explanation of columns in the tabular list.

a. Source, Maintenance and Recoverability Codes (SMR), Column 1:

(1) Source code, indicates the selection status and source for the listed item. Source codes used are:

Code	Explanation
P	Repair parts which are stocked in or supplied from the GSA/DSA, or Army supply system and authorized for use at indicated maintenance categories.