TECHNICAL MANUAL

ORGANIZATIONAL, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)

FOR

RADIO REPEATER SET AN/TRC-138

(NSN 5820-00-133-8841)

HEADQUARTERS, DEPARTMENT OF THE ARMY
11 MAY 1984

TECHNICAL MANUAL
No. 11-5820-773-24P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, *11 May 1984*

ORGANIZATIONAL, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)

FOR

RADIO REPEATER SET AN/TRC-138

(NSN 5820-00-133-8841)

Current as of 3 April 84

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, US Army Communications-Electronics Command and Fort Monmouth, ATTN: DR-SEL-ME-MP, Fort Monmouth, NJ 07703.

In either case, a reply will be furnished direct to you.

Table of Contents

			Page	Illus Figure
SECTION	I.	Introduction	1	
	II.	Repair Parts List	5	
GROUP	00	Radio Repeater Set AN/TRC-138	5	1
	01	Shelter Electrical Equipment S-393 ( )/TRC-138	13	2
		0101 Cable Assembly CX-7705( )/U, 15 ft	17	3
		0102 Power Cable, 6 1/2 ft	19	4
		0103 Patch Panel Assembly	21	5
		0104 Order Wire Patch Cable, 1 1/2 ft	23	6
		0105 Patch Cable, Cable/Repeater, 1 l/2 ft	25	7
		0106 Control Indicator Assembly	29	8
		0107 Bracket Installation	35	9
		010701 Utilities Installation Electrical	41	10
		01070101 Audio Cable Assembly GRI thru GRV	45	11
		01070102 Wire Assembly	45	11
		01070103 Repeater Interconnect GRI thru GRIV	45	11
		01070104 Video Cable GRI thru GRVI	47	12
		01070105 Cable, RF Test Out	47	12
		01070106 Sighting Cable GRI, GRII, GRIII	49	13

***This manual supersedes TM 11-5820-773-24P, 4 January 1980.**

Table of Contents-Continued

			Page	Illus Figure
GROUP	01	01070107 Traffic Cable	49	13
		01070108 Equipment Interconnect Harness GRI, GRII, GRIII	61	14
		01070109 Cable Assembly Video (XMTR to PATCH) GRI, GRII, GRIII, (SCD632609)	53	15
		01070110 Cable Assembly Video (XMTR to PATCH) GRI, GRII, GRIII, (SCD632610)	53	15
		01070111 Thru Order Wire Cable GRI, GRII, GRIII	55	16
		01070112 Utilities Installation Raceway	61	17
		0107011201 Blower Assembly	65	18
		0107011202 Power Distribution Assembly	69	19
		0107011203 Power Entrance Assembly	73	20
		0107011204 Video Entrance Assembly	75	21
		0107011205 Antenna Entrance Assembly (Roadside)	81	23
		0107011206 Antenna Entrance Assembly (Curbside)	83	24
		0107011207 Shelter, Modified	85	25
	02	Antenna AS-1425/GRC (See TM 11-5985-335-23P for parts)		
	03	Mast AB-621/G (See TM 11-5985-334-34P for parts)		
	04	Radio Set AN/GRC-144 (See TM 5820-695-34P for parts)		
	05	Intercommunication Station LS-147C/FI (See TM 11-5830-221-24P for parts)		
	06	Converter, Telegraph-Telephone Signal CV-425/U (See TM 11-5805-356-34P-2 for parts)		
	07	Telephone Set TA-312/PT (See TM 11-5805-201-20P and TM 11-5805-201-34P for parts)		
SECTION	III.	Special Tools List (Not applicable)		
	IV.	National Stock Number and Part Number Index	86	

SECTION I
INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational, direct support, and general support maintenance of the AN/TRC-138. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. Not applicable.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) *Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	*Definition*
PA-	Item procured and stocked for anticipated or known usage.
PB-	Item procured and stocked for insurance purpose because essentiality dictates that a minimum quantity be available in the supply system.
PC-	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
PD-	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE-	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF-	Support equipment which will not be stocked but which will be centrally procured on demand.
PG-	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which, because of probable discontinuance or shutdown of production facilities, would prove uneconomical to reproduce at a later time.
KD-	An item of a depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
KF-	An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or intermediate levels of maintenance.
KB-	Item included in both a depot overhaul/repair kit and a maintenance kit.
MO-	Item to be manufactured or fabricated at the organizational level.
MF-	Item to be manufactured or fabricated at the direct support maintenance level.
MH-	Item to be manufactured or fabricated at the general support maintenance level.
MD-	Item to be manufactured or fabricated at the depot maintenance level.
AO-	Item to be assembled at organization level.
AF-	Item to be assembled at direct support maintenance level.
AH-	Item to be assembled at general support maintenance level.
AD-	Item to be assembled at depot maintenance