

TM 11-5820-820-12-LD
Headquarters,
Department of the Army
11 August 1980

TECHNICAL MANUAL

PLASTIC-LAMINATED CONDENSED OPERATING INSTRUCTIONS

FOR

RADIO SET AN/URC-80(V) 1/3

(NSN 5820-00-097-0082)

The condensed operating instructions should be kept at the radio at all times for ready use.

You can submit comments on this publication by using DA Form 2028 (Recommended Changes To Publications and Blank Forms). Send to: Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, NJ 07703.

CONDENSED OPERATING PROCEDURES AN/URC-80(V)1/3

CAUTION

SELECT ONLY CHANNELS YOU ARE AUTHORIZED

POWER ON: On RT unit, set power switch to ON

TUNING CHANNELS

CHANNEL SELECTOR switch: SELECT

CHANNEL SELECTOR frequency: to desired operating
channel

MAIN RCVR VOLUME: to desired signal level

MAIN RCVR SQUELCH: to desired condition of noise-no noise

USING AUXILIARY RECEIVER - Auxiliary receiver is preset to
channel 13 and cannot be changed
by the operator.

AUX RCVR VOLUME: to desired signal level

AUX RCVR SQUELCH: to desired condition of noise-no noise

TRANSMITTING POWER - POWER-HIGH-LOW: to LOW. When you cannot communicate on LOW,
set to HIGH.

COMMUNICATING - Operate handset push-to-talk switch to talk;
release switch to hear.

POWER OFF: On RT unit, set power switch to OFF