

TECHNICAL MANUAL

**ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT
MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS)**

FOR

SATELLITE COMMUNICATIONS TERMINAL AN/TSC-93

**ALARM-MONITOR BZ-236/TSC
(NSN 5895-01-056-1038)**

AND

**WIRED SHELTER ASSEMBLY
(SM-D-777045)**

**HEADQUARTERS, DEPARTMENT OF THE ARMY
OCTOBER 1979**

Technical Manual
No. 11-5820-878-24P

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, DC, 17 October 1979

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT
MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)
FOR
SATELLITE COMMUNICATIONS TERMINAL AN/TSC-93,
ALARM-MONITOR BZ-236/TSC
(NSN 5895-01-056-1038),
AND
WIRED SHELTER ASSEMBLY
(SM-D-777045)

Current as of 12 October 1979

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in back of this manual direct to: Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSELME-MQ, Fort Monmouth, New Jersey 07703.

In either case, a reply will be furnished direct to you.

Table of Contents

		Page	Illus Figure
Section	I. Introduction	1	
	II. Repair Parts List	5	
Group	00 Satellite Communications Terminal AN/TSC-93.....	5	1
	11 Alarm-Monitor BZ-236/TSC	16	2
	1101 Fault/Safety Gate	20	3
	1102 Power Supply	26	4
	14 Wired Shelter Assembly	91	5
	1401 Signal Entry Panel	110	6
	140101 Surge Arrestor (No parts authorized)		
	1402 Baseband Patch Panel	113	7

Table of Contents - Continued

		Page	Illus Figure
Group	140201 Single Channel Level Converter	115	8
	1403 Power Entry Panel	117	9
	1404 VF Entry Panel.....	119	10
	140401 Surge Arrestor (No parts authorized)		
	1405 Antenna Entry Panel.....	121	11
	1406 Voice Data Mode Panel.....	123	12
	1407 Waveguide Switch (No parts authorized)		
	1408 Power Distribution Panel.....	128	13
	1409 Air Conditioner, Modified (See TM 5-4120-239-20P and TM 5-4120-239-34P for parts)		
	1410 Intercommunications Set LS-147/FI (See TM 11-5830'221-24P for parts)		
	1411 Telephone Set TA-312/PT (See TM 11-5805-201-20P and TM 11-5805-201-34P for parts)		
	1412 Handset H-189/GR (See TM 11-5965-280-15 for parts)		
	1413 Telephone Signal Converter CV-1548()/G (See TM 11-5805-367-20P-5 and TM 11-5805-367-34P-5 for parts)		
	1414 Echo Suppressor MX-9635/TSC (See TM 11-5895-843-24P for parts)		
	1415 Multiplexer TD-660()/G (See TM 11-5805-382-20P and TM 11-5805-382-34P for parts)		
	1416 Communications Security Equipment TSEC/KY-27 (See TM 11-5810-232-12P and TM 11-5810-232-34P for parts)		
	1417 Multiplexer TD-754/G (See TM 11-5805-383-20P and TM 11-5805-383-34P for parts)		
	1418 High Speed Serial Data Buffer TD-1065(EX-1)/G (No parts authorized)		
	1419 Transformer 230/115 Volt (No parts authorized)		
	1420 Arctic Kit (See TM 5-4520-239-24P for parts)	133	14

iii/(iv blank)

SECTION I INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational, direct support, and general support maintenance of the AN/TSC-93, BZ-236/TSC, and Wired Shelter Assembly (SM-D-777045). It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. Refer to paragraph 4c for special tools.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-reference to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) Figure number. Indicates the figure number of the illustration on which the item is shown.

(2) Item number. The number used to identify item called out in the illustration.