TECHNICAL MANUAL

UNIT AND DIRECT SUPPORT
REPAIR PARTS AND SPECIAL TOOLS LISTS

FOR

SHELTER, ELECTRICAL EQUIPMENT
S-250/G UNSHIELDED
(NSN 5411-00-999-4935)
S-250/G SHIELDED
(NSN 5411-00-489-6076)

Approved for public release; distribution is unlimited.

*This manual supersedes S–250/G data of TM 11–5410-214-12P and TM 11–5410-214-34P, both dated 27 December 1978.

HEADQUARTERS, DEPARTMENT OF THE ARMY

24 JUNE 1991

TECHICAL MANUAL

NO. 10-5411-205-23P

HEADQUARTERS,
DEPARTMENT OF THE ARMY
WASHINGTON, D. C., 24 JUNE 1991

UNIT AND DIRECT SUPPORT REPAIR PARTS AND SPECIAL TOOLS LISTS FOR SHELTER, ELECTRICAL EQUIPMENT S-250/G UNSHIELDED (NSN 5411-00-999-4935) S-250/G SHIELDED (NSN 5411-00-489-6076)

Current as of 16 May 1991

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms) or DA Form 2028-2 located in the back of this manual directly to: Commander, U.S. Army Troop Support Command, ATTN: AMSTR-MMTS, 4300 Goodfellow Boulevard, St. Louis, MO 63120-1798. A reply will be furnished directly to you.

Approved for public release; distribution is unlimited

		Page	ILLUS/ Figure
SECTION I.	INTRODUCTION	1	
SECTION II.	REPAIR PARTS LIST	1-1	
GROUP 00	Shelter, Electrical Equipment S-250/G	1-1	1
01	Outer DooR Assembly	2-1	2
02	Inner Door Assembly	3-1	3
03	Door Stay Assembly	4-1	4
04	Skid Assembly	5-1	5
05	Towing Bracket Assembly	6-1	6
06	Lifting Bracket Assembly	7-1	7
SECTION III.	Special Tools List (Not Applicable)		
SECTION IV.	Cross Reference Indexes	I-1	
	National Stock Number Index	I-1	
	Part Number Index	I-3	
	Figure and Item Number index	I-8	

*This manual supersedes TM 11-5410-214-12P and TM 11-5410-214-34P, both dated 27 December 1978.

UNIT AND DIRECT SUPPORT
REPAIR PARTS AND SPECIAL TOOLS LIST

SECTION I. INTRODUCTION

1. **SCOPE.** This RPSTL lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of unit, direct support, and general support maintenance of the S-250/G Unshielded and S-250/G Shielded shelters. It authorizes the requisitioning, issue, and disposition of spares, repair parts and special tools as indicated by the source, maintenance and recoverability (SMR) codes.

2. **GENERAL.** In addition to this section, Introduction, this Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence. Bulk materials are listed in item name sequence. Repair parts kits are listed separately in their own functional group within Section II. Repair parts for repairable special tools are also listed in this section. Items listed are shown on the associated illustration(s)/figure(s).

b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in DESCRIPTION AND USABLE ON CODE column) for the performance of maintenance.

c. Section IV. Cross-references Indexes. A list, in National Item Identification Number (NIIN) sequence, of all National stock numbered items appearing in the listing, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross referenced to each illustration figure and item number appearance. The figure and item number index lists figure and item number in alphanumeric sequence and cross references NSN, CAGEC and part number.

3. EXPLANATION OF COLUMNS (SECTIONS II AND III).

a. ITEM NO. (Column (l)). Indicates the number used to identify items called out in the illustration.

b. SMR Code (Column (2)). The Source, Maintenance, and Recoverability (SMR) code is a 5–position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instruction, as shown in the following breakout:



*Complete Repair: Maintenance capacity, capability, and authority to perform all corrective maintenance tasks of the "Repair' function in a use/user environment in order to restore serviceability to a failed item.

(1) Source Code. The source code tells you how to get an item needed for maintenance, repair, or overhaul of an end item/equipment. Explanations of source codes follows:



Figure 1. Shelter, Electrical Equipment S-250/G (Sheet 1 of 4)