OPERATOR'S, UNIT, AND DIRECT SUPPORT

MAINTENANCE MANUAL

INCLUDING

REPAIR PARTS AND SPECIAL TOOLS LIST

FOR

SOLDIER CREW TENT

TYPE I, NSN: 8340-01-359-0084

TYPE II, NSN: 8340-01-359-1481





OPERATOR PMCS

ASSEMBLY AND INSTALLATION INSTRUCTIONS

OPERATOR TROUBLESHOOTING

OPERATOR'S MAINTENANCE PROCEDURES

UNIT MAINTENANCE PROCEDURES

DIRECT SUPPORT MAINTENANCE PROCEDURES

MAINTENANCE ALLOCATION CHART

EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST

REPAIR PARTS AND SPECIAL TOOLS LIST

ALPHABETICAL INDEX

Distribution Statement A: Approved for public release; distribution is unlimited.

HEADQUARTERS, DEPARTMENT OF THE ARMY
28 FEBRUARY 1994

Operator's, Unit, and Direct Support
Maintenance Manual
Including
Repair Parts and Special Tools List
SOLDIER CREW TENT
Type I, NSN 8340-01-359-0084
Type II, NSN 8340-01-359-1481

Reporting Equipment Improvement Recommendations

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 (located in the back of this manual) direct to: Commander, U.S. Army Aviation and Troop Command, ATTN: AMSAT-I-MP, 4300 Goodfellow Blvd., St. Louis, MO 63210-1798. A reply will be furnished to you.

Distribution Statement A; Approved for public release; distribution is unlimited

TABLE OF CONTENTS

Chapter/Section		Page
CHAPTER 1	INTRODUCTION	1-1
Section I	General Information	1-1
Section II	Equipment Description	1-2
Section III	Technical Principles of Operation	1-5
CHAPTER 2	OPERATING INSTRUCTIONS	2-1
Section I	Description and Use of Operator's Controls and Indicators	2-1
Section II	Operator's Preventive Maintenance Checks and Services	2-1
Section III	Operation Under Usual Conditions	2-24
Section IV	Operation Under Unusual Conditions	2-45

TABLE OF CONTENTS - Continued

Chapter/Section		Page
CHAPTER 3	OPERATOR'S MAINTENANCE INSTRUCTIONS	3-1
Section I	Lubrication Instructions	3-1
Section II	Operator's Troubleshooting Procedures	3-1
Section III	Operator's Maintenance Procedures	3-4
CHAPTER 4	UNIT MAINTENANCE INSTRUCTIONS	4-1
Section I	Lubrication Instructions	4-1
Section II	Repair Parts, Special Tools, TMDE, and Support Equipment	4-1
Section III	Service Upon Receipt	4-1
Section IV	Unit Preventive Maintenance Checks and Services (PMCS)	4-2
Section V	Unit Troubleshooting Procedures	4-2
Section VI	Unit Maintenance Procedures	4-2
Section VII	Preparation for Storage and Shipment..	4-11
CHAPTER 5	DIRECT SUPPORT MAINTENANCE INSTRUCTIONS	5-1
Section I	Repair Parts, Special Tools, Test Measurement Diagnostic Equipment (TMDE) and Support Equipment	5-1
Section II	Direct Support Maintenance Procedures	5-1
APPENDIX A	REFERENCES	A-1
APPENDIX B	MAINTENANCE ALLOCATION CHART	B-1
APPENDIX C	COMPONENTS OF END ITEM AND BASIC ISSUE ITEM LIST	C-1

TABLE OF CONTENTS - Continued

Chapter/Section		Page
APPENDIX D	ADDITIONAL AUTHORIZATION LIST	D-1
APPENDIX E	EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST	E-1
APPENDIX F	REPAIR PARTS AND SPECIAL TOOLS LIST	F-1
	ALPHABETICAL INDEX	INDEX-1

HOW TO USE THIS MANUAL

This manual (TM 10-8340-227-13&P) contains general information, operating instructions, PMCS instructions, troubleshooting steps, and maintenance instructions for the Soldier Crew Tent. Use the front cover index and thumb bleeds at the edge of the pages to quickly find the sections of the manual shown on the cover.



The manual has been divided into chapters, sections and paragraphs that are numbered in sequence. Pages, paragraphs, and illustrations are numbered by chapter. For example, chapter 2, page 3 is marked 2-3; chapter 3, paragraph 5 is marked 3-5; Figure 2-3 is the third illustration in chapter 2. To quickly find specific information, use the Table of Contents. For example, the front cover index states that Chapter 1 begins on page 1-1. The Table of Contents on page 1 tells you the exact page where the section you want is located.



Figure 1-1. Soldier Crew Tent

CHAPTER 1

INTRODUCTION

Section I. GENERAL INFORMATION

1-1. SCOPE.

a. Type of Manual. Operator's, Unit, and Direct Support Maintenance Manual that provides instructions for the set-up, operation, take down, maintenance, repair parts and procedures for all components of the Soldier Crew Tent.

b. Purpose of Equipment. Provide environmental protection and shelter to crew member personnel.

c. Special Features. Lightweight tent and frame assembly can be easily set up by one or two soldiers.

d. Model Number and Equipment Name. There is no model number for the Soldier Crew Tent. Table 1-1 lists the various tent configurations and nomenclatures.

1-2. MAINTENANCE FORMS AND RECORDS. Department of the Army forms and procedures used for equipment maintenance will be those prescribed by DA PAM 738-750, The Army Maintenance Management System (TAMMS).

1-3. DESTRUCTION OF ARMY MATERIEL TO PREVENT ENEMY USE. Destruction procedures for Soldier Crew Tent components covered in this manual are described in TM 750-244-3.

1-4. PREPARATION FOR STORAGE OR SHIPMENT. Refer to paragraph 2-7 to prepare the Soldier Crew Tent for storage or shipment.

1-5. QUALITY ASSURANCE (QA). All maintenance actions will be inspected to assure that all applicable quality assurance standards are met. Refer to FM 10-16 for fabric repair standards.

1-6. NOMENCLATURE CROSS-REFERENCE.

COMMON NAME	OFFICIAL NAME
Frame	Frame Assembly
Tent	Soldier Crew Tent

1-7. REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIR). If your Soldier Crew Tent components need improvement, let us know. Send us an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design or performance. Put it on an SF 368 (Quality Deficiency Report). Mail it to us at: Commander, U.S. Army Aviation and Troop Command, ATTN: AMSAT-I-MDO, 4300 Goodfellow Blvd., St. Louis, MO 63120-1798. We'll send you a reply.