DEPARTMENT OF THE ARMY TECHNICAL MANUAL

ORGANIZATIONAL, DIRECT AND GENERAL SUPPORT, AND DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

CLEANING MACHINE, FUEL CAN AND DRUM

BARNES MODEL 4310CA, ARMY MODEL SPE 19,

(FSN 4940-268-9771)

BARNES MODEL 15801CA, ARMY MODEL SPE 19A,

(FSN 4940-658-2889)

HEADQUARTERS, DEPARTMENT OF THE ARMY
FEBRUARY 1967

TECHNICAL MANUAL
No. 10-4940-201-25P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., *7 February 1967*

Organizational, Direct and General Support, and Depot Maintenance Repair Parts and Special Tools List

CLEANING MACHINE, FUEL CAN AND DRUM BARNES MODEL 4310CA, ARMY MODEL SPE 19, (FSN 4940-268-9771) BARNES MODEL 15801CA, ARMY MODEL SPE 19A, (FSN 4940658-2889)

		Paragraph	Page
SECTION I.	INTRODUCTION		
	Scope	1	ii
	General	2	ii
	Explanation of columns	3	ii
	Special information	4	iii
	Instructions for locating repair parts	5	iii
	Abbreviations	6	iv
	Index of Federal Supply Codes	7	iv
	Reporting of equipment publication improvements	8	iv
II.	PRESCRIBED LOAD ALLOWANCE		v
III.	REPAIR PARTS FOR ORGANIZATIONAL MAINTENANCE		
Group 72.	Dispensing and Servicing Equipment Components		
	7203 Valves, fittings, lines		1
	7203 Valves, fittings, lines		1
	7206 Steam cleaning units		4
76.	Fire Fighting Equipment Components		
	7603 Fire extinguisher		5
	7603 Fire extinguisher		5
SECTION IV.	REPAIR PARTS FOR DS, GS, AND DEPOT MAINTENANCE		
Group 72.	Dispensing and Servicing Equipment Components		
	7203 Valves, fittings, lines		6
	7203 Valves, fittings, lines		6
76.	Fire Fighting Equipment Components		
	7603 Fire extinguisher		11
SECTION V.	FEDERAL STOCK NUMBER AND MANUFACTURES PART NUMBER INDEX		18

☆**This manual supersedes TM 10-4940-201-20P, 3 April 1963, and TM 10-4940-201-35P, 16 April 1963.**

SECTION I
INTRODUCTION

1. Scope

This manual contains a list of repair parts required for the performance of organizational, direct support, general support, and depot maintenance of the cleaning machine.

2. General

This repair parts list is divided into four principal sections and a Federal stock number index.

a. Section II, Prescribed Load Allowance List (PLA), is a consolidated listing of repair parts quantitatively allocated for initial stockage at the organizational level. *This is a mandatory minimum stockage allowance*.

b. Section III, Repair Parts List, is a list of repair parts authorized for the performance of maintenance at the organizational level.

c. Section IV, Repair Parts List, is a list of repair parts authorized for the performance of maintenance at the direct support, general support, and depot maintenance level.

d. Section IV, Federal Stock Number and Manufacturer's Part Number Index is an index of Federal stock numbers and manufacturer's part numbers to page and manufacturer's codes.

3. Explanation of Columns

The following provides an explanation of columns in the tabular lists.

a. Source, Maintenance, and Recoverability Codes.

(1) Source Code indicates the selection status and source for the listed item. Source codes used are:

Code	*Explanation*
P.....	Applied to repair parts which are stocked in or supplied from DSA/GSA or Army supply system, and authorized for use at indicated maintenance categories.
X1.....	Applied to repair parts which are not procured or stocked, the requirement for which will be supplied by use of the next higher assembly or components.
X2.....	Applied to repair parts which are not stocked. The indicated maintenance category requiring such repair parts will attempt to obtain them through cannibalization; if not obtainable through cannibalization, such repair parts will be requisitioned with supporting justification through normal supply channels.

Note

Source code is not shown on common hardware items known to be readily available in Army supply channels and through local procurement.

(2) Maintenance Code indicates the lowest category of maintenance authorized to maintain the listed item. The maintenance level codes are:

Code	*Explanation*
O	Organizational maintenance
F.....	Direct support maintenance

(3) Recoverability Code indicates whether unserviceable items should be returned for recovery or salvage. Items not coded are expendable. The recoverability code is:

Code	*Explanation*
R.....	Applied to repair parts and assemblies which are economically repairable at DSU and GSU activities and normally are furnished by supply on an exchange basis.

b. Federal Stock Number indicates the Federal stock number for the item.

c. Description column indicates the Federal item name and a brief description of the item. A five-digit manufacturer's or other service code is shown followed by the manufacturer's part number. Repair parts quantities included