
DEPARTMENT OF THE ARMY TECHNICAL MANUAL

OPERATOR, ORGANIZATIONAL, FIELD AND DEPOT MAINTENANCE REPAIR PARTS AND
SPECIAL TOOLS LIST AND MAINTENANCE ALLOCATION CHART
DEGREASER MK-1760/G

Headquarters, Department of the Army, Washington 25, D. C.
22 March 1960

SECTION		Paragraph	Page
I.	INTRODUCTION		
	Scope.....	1	1
	Parts for maintenance	2	3
	Requisitioning information.	3	3
	Additional repair parts	4	4
	Stockage	5	3
	Comments or suggestions	6	3
II.	FIRST ECHELON FUNCTIONAL PARTS LIST		
III.	SECOND ECHELON FUNCTIONAL PARTS LIST		
IV.	THIRD, FOURTH, AND FIFTH ECHELON FUNCTIONAL PARTS LIST		
V.	MAINTENANCE ALLOCATION		
	General	7	7
	Maintenance by using organizations	8	7
	Mounting hardware.....	9	8
	MAINTENANCE ALLOCATION CHART		
	ALLOCATION OF TOOLS FOR MAINTENANCE FUNCTIONS		

SECTION I

INTRODUCTION

1. Scope

a. *General.* This manual contains an operator, organizational, field, and depot maintenance re-pair parts and special tools list for Degreaser MK-1760/G.

(1) Section II lists items supplied for initial operation and for running spares and accessories. The list includes tools, accessories, parts, and material issued as part of the major end item. The list includes all items authorized for basic operator

* This manual supersedes Department of the Army Supply Manual SIG 7 & 8 MX-1760/G, 19 October 1956.

maintenance of the equipment. End items of equipment are issued on the basis of allowances prescribed in equipment authorization tables and other documents which are a basis for requisitioning.

(2) Section III lists the quantities of repair parts authorized for organizational maintenance and is a basis for requisitioning by organizations which are authorized the major item of equipment.

(3) Section IV lists the quantities of repair parts for third and fourth echelon field. maintenance and is a basis for requisitioning authorized parts. It is also a guide for fifth echelon in establishing initial levels of spare parts.

b. *Columns.*

(1) *Source, maintenance, and recoverability code.* Source, maintenance and recoverability codes indicates the technical service responsible for supply, the echelons where an item is stocked, echelons where an item is installed or repaired, and whether an item is repairable or salvageable. The source code column is divided into four parts.

- (a) *Column A.* The numbers in this column in these columns indicate the technical service responsible for supply. AR 310-2 defines the basic numbers used to identify the technical services. If the part is supplied by the Signal Corps, the column is blank.
- (b) *Column B.* Not used.
- (c) *Column C.* This column indicates the lowest maintenance echelon authorized to install the part.
- (d) *Column D.* Not used.

(2) *Federal stock number.* The "Stock number" column lists the 11-digit Federal stock number. In the absence of a Federal stock Number, an interim number, for example ttL5Ra41c-12, in the description column indicates that a Federal stock number is being processed for assignment. The L number may be used in emergencies to identify items.

(3) *Designation by model.* Not used.

(4) *Description.* Nomenclature or the standard item name and brief identifying data for each item is listed in this column. When requisitioning, enter the' nomenclature and description on the requisition.

(5) *Unit of issue.* The unit of issue is the supply term applied to the smallest quantity by which the individual item is counted for procurement, allowances, and issue purposes. storage, requisitioning,

(6) *Expendability.* Expendable items are indicated by the letter X; nonexpendable items are indicated by NX.

(7) *Quantity authorized.* Under "Items comprising an Operable Equipment" the column lists the quantity of items supplied for the initial operation of the equipment. Under "Running Spares and Accessory Items" the quantities listed are those issued initially with the equipment as spare parts. The quantities are authorized to be kept on hand by the operator for maintenance of the equipment.

(8) *Quantity incorporated in unit.* This column lists the quantity of each part found in a given assembly, component, or equipment.

(9) *Organizational.* The quantities indicated in these columns are maximum levels of repair parts authorized to be kept on hand by units performing organizational maintenance. The quantities are based on 100 equipments to be maintained for a 15-day period.

(10) *Field (third echelon).* The numbers in these columns indicate quantities of repair parts authorized for initial stockage for use in the third echelon maintenance and in supply support to second echelon. The quantities are based on 100 equipments to be maintained for a 15-day period.

(11) *Field (fourth echelon).* The numbers in this column indicate quantities of repair parts authorized for initial stockage for use in fourth echelon maintenance. The quantities are based on 100 equipments to be maintained for a 15-day period.

(12) *Depot (fifth. echelon).* The numbers in this column indicate quantities of repair parts authorized for depot maintenance and for initial stockage for maintenance,