

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

ORGANIZATIONAL MAINTENANCE MANUAL
LATHE, ENGINE, BENCH MOUNTED, SOLID BED TYPE,
10 INCH SWING, NO. 2 MORSE TAPER CENTER,
1-3/8 SPINDLE HOLE, 110-VOLTS, 60 CYCLE,
SINGLE PHASE 3/4-HORSEPOWER, W/ARMY
DWG NO. 7550151 BENCH
(STANDARD-MODERN TOOL
SERIES 2,000 MODEL 11 INCH)
(3416-517-0955)

This reprint includes all changes in effect at the time of publication - Changes 1 and 2.
--

HEADQUARTERS, DEPARTMENT OF THE ARMY

NOVEMBER 1965

TECHNICAL MANUAL }
No. 9-3416-225-12 }

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D. C., 8 November 1965

ORGANIZATIONAL MAINTENANCE MANUAL
LATHE, ENGINE, BENCH MOUNTED, SOLID BED TYPE,
10-INCH SWING, NO. 2 MORSE TAPER CENTER,
1 $\frac{3}{8}$ SPINDLE HOLE, 110-VOLTS, 60-CYCLE,
SINGLE PHASE $\frac{3}{4}$ -HORSEPOWER, W/ARMY
DWG NO. 7550151 BENCH
(STANDARD-MODERN TOOL SERIES 2,000 MODEL 11 INCH)
(3416-517-0955)

Lifting and installation instructions	1
Electrical diagram	3
Lubrication.....	4
Operating instructions	6
Taper attachment.....	10
Headstock.....	11
End gear train (shift).....	12
End gear train (change).....	13
End gear train chart.....	14
Feed box assy.	15
Apron.....	17
Saddle	18
Tailstock	19
Appendix I. Basic Issue items.....	AI-1
II. Maintenance allocation.....	AII-1
III. Repair parts and special tool lists.....	AIII-1

COMPONENTS OF THE END ITEM:

Parts included with the end item and considered as components of the end item configuration are listed in the following table.

TABLE 1. COMPONENT OF END ITEM

<i>Component</i>	<i>Part No.</i>	<i>Component</i>	<i>Part No.</i>
BELT, V:	25472:5L330	GEAR, SPUR:	36195:B-40386
CENTER, LATHE:	41672:295	GEAR, SPUR:	36195:B-40379
CENTER, LATHE:	36195:BD 3"	GEAR, SPUR:	36195:B-40380
CHUCK, COLLET:	75078.91-C-3	GEAR, SPUR:	36195:B-40381
CHUCK, DRILL:	75078:34-3406	GEAR, SPUR:	36195:B-40382
CHUCK, LATHE:	55130:9608-D3	GEAR SPUR:	36195:B-40387
CHUCK, LATHE:	55130:5606-D3	GEAR, SPUR:	36195:B-40384
COLLET SET:	75078:J-900-8	GEAR, SPUR:	36195:B-40385
COLLET, MACHINE:	75078:J-910	GEAR, SPUR:	36195:B-40377
COLLET, MACHINE:	75078:J-911	HOLDER, LATHE TOOL:	65814:8
COLLET, MACHINE:	75078:J-912	HOLDER, LATHE TOOL:	65814:30L
COLLET, MACHINE:	75078:J-913	HOLDER, LATHE TOOL:	65814:30R
COLLET, MACHINE:	75078:J-914	HOLDER, LATHE TOOL:	65814:20
COLLET, MACHINE:	75078:J-915	HOLDER, LATHE TOOL:	65814:0-L
COLLET, MACHINE:	75078:J-916	HOLDER, LATHE TOOL:	65814:0-R
COLLET, MACHINE:	75078:J-917	HOLDER, LATHE TOOL:	65814:0-S
DOG, LATHE:	03914:2-H	KNURLING TOOL:	65814:3-K-0
DOG, LATHE:	03914:3-H	KNURLING TOOL:	65814:0-K
DOG, LATHE:	03914:4-H	PIN, SHEAR:	36195:A30398
DOG, LATHE:	03914:5-H	PIN, SHEAR:	36195:A30750
DOG, LATHE:	03914:6-H	REST, FOLLOW:	36195:C-32223
DOG, LATHE:	03914:4	REST, STEADY:	36195:C-30339
FACE PLATE:	36195:50159	SLEEVE, SPINDLE:	36195:A32063
FACE PLATE:	36195:50161	STOP, CARRIAGE:	36195:B-32290
GEAR SET: C/O		WRENCH, COMPOUND:	65814:3
GEAR, SPUR:	36195:B-40378	WRENCH, TAILSTOCK:	65814:805
		WRENCH, TOOL POST:	65814:583

APPENDIX I

BASIC ISSUE ITEMS
AND
ITEMS TROOP INSTALLED OR AUTHORIZED LIST

Section I. INTRODUCTION

1. Scope

This appendix lists basic issue items and items troops installed or authorized.

- a. *Basic Issue Items List* - Not applicable.
- b. *Items Troop Installed or Authorized List* - Not applicable.

2. Reporting of Equipment Publication Improvements

The reporting of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Changes to Publications) and forwarded direct to: Commander, US Army Weapons Command, ATTN: AMSWE-MAS, Rock Island, IL 61201. A reply will be furnished directly to you.