TECHNICAL MANUAL
NO. 9-4910-261-14P

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, D. C., 20025 *14 October 1971*

OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT,

AND

GENERAL SUPPORT MAINTENANCE

REPAIR PARTS AND SPECIAL TOOLS LISTS

(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)

FOR

JACK, DOLLY-TYPE, HYDRAULIC: 10-TON CAPACITY

(WALKER MFG. CO. MODEL-780) (4910-289-7233)

This manual is current to 1 October 1971

			Paragraph	Page
Section	I.	Introduction	1	2
	II.	Repair Parts List	2a	2
	III.	Special Tools List	2b	2
	IV.	Repair Parts List	2c	2
		Repair Parts for:		
		Frame and wheel assembly		
		Bell crank assembly		
		Hydraulic unit assembly		
		Handle and quadrant assembly		
	V.	Special Tools List	2d	2
	VI.	Federal Stock Number and Reference Number Index	2e	2

* This manual supersedes SM ORD 7-8 SNL J-520, 22 March 1955, and TM 9-4910-261-50, 18 June 1958.

OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)

Section I. INTRODUCTION

1. Scope. This manual lists repair parts required by the crew / operator for operation and required for the performance of organizational, direct support, and general support maintenance of the hydraulic dolly-type jack.

2. General. The Repair Parts List is divided into the following sections:

a. *Repair Parts List-Section II. A* list of repair parts authorized at the organizational level for the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending numerical sequence, with the parts in each group listed in figure and item number sequence.

b. Special Tools List-Section III. Not applicable.

c. *Repair Parts List-Section IV. A* list of repair parts authorized for the performance of maintenance at the direct support and general support levels in figure and item number sequence.

d. Special Tools List-section V. Not applicable.

e. Federal Stock Number and Reference Number Index-Section VI. A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphameric sequence, of all reference numbers appearing in the listings. Federal stock numbers and reference numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns. The following provides an explanation of columns found in the tabular listings.

a. Source, Maintenance, and Recoverability Codes (SMR).

(1) *Source code.* Indicates the source for the listed items. Source codes are:

(Code	*Explanation*
P	Repair parts. special tools. and test equipment supplied from the GSA / DSA or Army supply system and auphorizad for use at indicated maintenance categories.
P2	Repair parts, special tools. and test equipment which are proncured nd stocked for insurance purposes, because the combat or military essentiality of the end item dictates that a minimum quantity be available in the supply system.
P 9	Assigned to items which are NSA design controlled: unique repair parts, special tools, test, measuring and diagnostic equipment, which are stocked and supplied by the Army COMSEC Logistic System and which are not subject to the provisions of AR 380-41.
P 10	Assigned to items which are NSA design controlled: special tools, test, measuring, and diagnostic equipment for COMSEC support which are accountable under the provisions of AR 380-41 and which are stocked and supplied by the Army COMSEC Logistic System.
M	Repair parts, special tools and test equipment which are not procured or stocked as such in the supply system but are to be manufactured at indicated maintenance levels.
A	Assemblies which are not procured or stocked as such but are made up of two or more units. Such component units carry individual stock numbers and descriptions, are procured and stocked separately, and can be assembled to form the required assembly at indicated maintenance categories.
X	Parts and assemblies that are not Procured or stocked because the failure rate is normally below that of the applicable end item or component. The failure of such part or assembly should result in retirement of the end item from the supply system.
X1	Repair parts which are not procured or stocked. The requirement for such itemts will be filled by the next higher assembly or component.
X 2	Repair parts, special tools and test equipment which are not stocked and have no foreseen mortality. The indicated maintenance category requiring such repair parts will attempt to obtain the parts through cannibalization or salvage. The item may be requisitioned, with exception data, from the end item manager for immediate use.
G	Major assemblies that are procured with PEMA funds for initial issue only as exchange assemblies at DM and GS level. These assemblies will not be stocked above DS and GS level or returned to depot supply level.

Note. Cannibalization or salvage may be used as a source of supply for any item's source coded above except those coded X1 and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Indicates the lowest category of maintenance authorized to install the repair part and / or use the special tool or test equipment for each application. Capabilities of higher maintenance categories are considered equal or better. Maintenance codes. are: