DEPARTMENT
OF THE ARMY TECHNICAL MANUAL

OPERATOR, ORGANIZATIONAL, DIRECT SUPPORT

AND GENERAL SUPPORT MAINTENANCE

MANUAL INCLUDING REPAIR PARTS LIST

FOR

CLEANER & TESTER, SPARK PLUG

MODEL 82

(BANNER METALS) (4910-00-261-5868)

HEADQUARTERS,
DEPARTMENT OF THE ARMY

JANUARY 1981

Technical Manual
No. 9-4910-631-14&P

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, DC, 26 *January 1981*

OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE MANUAL INCLUDING REPAIR PARTS LIST

FOR

CLEANER AND TESTER, SPARK PLUG MODEL 82 (NSN 4910-00-261-5868)

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you fired any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2, located in the back of this manual direct to: Commander, US Army Armament Materiel Readiness Command, ATTN: DRSAR-MAS, Rock Island, IL 61299. A reply will be furnished directly to you.

NOTE

This manual is published for the purpose of identifying an authorized commercial manual for the use of the personnel to whom this spark plug cleaner and tester is issued.

Manufactured by: Banner Metals
Div. of Intercole Automation, Inc.
Stroudsburg, PA 18360

Procured under Contract No. DAAA09-76-C-6058

This technical manual is an authentication of the manufacturer's commercial literature and does not conform with the format and content specified in AR 310-3, Military Publications. This technical manual does, however, contain available information that is essential to the operation and maintenance of the equipment.

INDEX

	FIG. #	PAGE #
SPECIFICATIONS & INSTALLATION		3
OPERATING THE CLEANER	1	4
OPERATING THE TESTER	2	5
MAINTENANCE		6
TROUBLE SHOOTING		7
MAJOR COMPONENTS	3	8
CLEANING CHAMBER ASSEMBLY	4	9
AIR-ABRASIVE VALVE ASSEMBLY	5	10
COMPRESSION CHAMBER ASSEMBLY	6	11
REPLACEMENT PARTS LIST		12 - 13

SHIPPING LIST

ITEM NO	DESCRIPTION	QUANTITY
82E000	CLEANER-TESTER	1
6	DUST HOPPER DRAIN PLUG	1*
7	CLEANING CHAMBER DRAIN PLUG	1*
8	ABRASIVE RUBBER NOZZLE	1*
16	RUBBER CLEANING ADAPTER 10mm	1
16	RUBBER CLEANING ADAPTER 18mm	1
16	RUBBER CLEANING ADAPTER 7/8"	1
38	2-WIRE GROUND ADAPTER	1
40	TESTER GAGE	1
50	STEEL TESTING ADAPTER 10mm	1
50	STEEL TESTING ADAPTER 18mm	1
57	SHIELDED PLUG ADAPTER	1
58	SPARK PLUG TRAY	1
59	ABRASIVE (1 BAG CHARGE) (1 FOR INSTALLATION) (1 * FOR RECHARGE)	2
60	OPERATION & MAINTENANCE INSTRUCTION MANUAL	2

*Spare parts to be retained for use when unit is recharged.