

**TECHNICAL MANUAL
ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT
MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST
FOR**

**TEST STAND,
AUTOMOTIVE GENERATOR,
ALTERNATOR, STARTER, AND
ASSOCIATED EQUIPMENT
MODEL GASR-500**

PART NUMBER

NSN

7458-2

4910-01-041-8161

7458-4

4910-00-767-0218

Approved for public release; distribution is unlimited.

HEADQUARTERS, DEPARTMENT OF THE ARMY

29 MAY 1987

TECHNICAL MANUAL

NO. 9-4910-663-24P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON D.C. 29 May 1987

ORGANIZATIONAL, DIRECT SUPPORT, AND

GENERAL SUPPORT MAINTENANCE

REPAIR PARTS AND SPECIAL TOOLS LIST

FOR

TEST STAND, AUTOMOTIVE GENERATOR, ALTERNATOR,
STARTER, AND GENERATOR EQUIPMENT,

MODEL GASR-500

PART NUMBER 7458-2 (NSN 4910-01-041-8161)

PART NUMBER 7458-4 (NSN 4910-00-767-0218)

Current as of

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistake or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publication and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, US Army Armament, Munitions, and Chemical Command, ATTN: AMSMC-MAS, Rock Island, IL 61299-6000. A reply will be furnished to you.

		Page	Figure
SECTION I.	INTRODUCTION	1	
II.	REPAIR PARTS LIST	1-1	
Group 00	Test stand	1-1	1
01	Panel assembly, binding post	2-1	2
02	Rectifier chamber assembly	3-1	3
03	Battery compartment assembly	4-1	4
04	Instrument panel assembly	5-1	5
	0401 PC board assembly	6-1	6
05	Control panel assembly	7-1	7
06	Rheostat assembly	8-1	8
07	Link board assembly	9-1	9
08	Panel drive control assembly	10-1	10

Approved for public release; distribution is unlimited.

This manual supersedes TM 9-4910-663-24P, dated 10 November 1980.

		Page	Figure
SECTION II.	REPAIR PARTS LIST - Continued		
09	Load bank assembly	11-1	11
	0901 Load bank	12-1	12
10	Panel assembly - resistor and shunt	13-1	13
11	Diode assembly	14-1	14
12	Varidrive assembly	15-1	15
13	Drive bracket assembly.	16-1	16
14	Starter	17-1	17
15	Blower assembly	18-1	18
16	Accessories	19-1	19
SECTION III.	SPECIAL TOOLS LIST (not applicable)		
IV.	NSN, PART NO. INDEX	I-1	

Section I.

INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools; and other special support equipment required for the performance of organizational, direct support, and general support maintenance of the Automotive Generator, Alternator, and Starter Test Stand, Model GASR-500. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence. Bulk materials are listed in national stock number (NSN) sequence.

b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized for the performance of maintenance. Not applicable.

Section IV. National Stock Number and Part Number Index. A list in national item identification number (NIIN, the last nine figures of the NSN) sequence, of all national stock numbers (NSNs) appearing in the listings, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) Figure numbers. Indicates the figure number of the illustration of which the item is shown.

(2) Item number. The number used to identify item called out in the illustration.