


TECHNICAL MANUAL

**UNIT, DIRECT SUPPORT, AND
GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LIST**

FOR

**CLEANER, STEAM, HIGH PRESSURE,
HOT AND COLD WATER JET,
TRAILER MOUNTED
(4940-01-025-9856)(EIC: 2BC)**



DISTRIBUTION STATEMENT C. Distribution authorized to US Government agencies and their contractors. This publication is required for administrative and operational purposes, as determined 6 January 1993. Other requests for this document shall be referred to Director, Armament and Chemical Acquisition and Logistics Activity (ACALA), ATTN: AMSTA-AC-NML, Rock Island, IL 61299-7630. (E-mail: amsta-ac-nml@ria.army.mil).

DESTRUCTION NOTICE. Destroy by any method that will prevent disclosure of contents or reconstruction of the document.

**HEADQUARTERS, DEPARTMENT OF THE ARMY
1 AUGUST 1994**

**UNIT, DIRECT SUPPORT, AND GENERAL
SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LIST
FOR
CLEANER, STEAM HIGH PRESSURE,
HOT AND COLD WATER JET,
TRAILER MOUNTED
(4940-01-025-9856)(EIC: 2BC)**

Current as of 9 May 1994

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes, or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Director, Armament and Chemical Acquisition and Logistics Activity (ACALA), ATTN: AMSTA-AC-NML, Rock Island, IL 61299-7630. (E-mail: amsta-ac-nml@ria.army.mil). A reply will be furnished to you.

DISTRIBUTION STATEMENT C. Distribution authorized to US Government agencies and their contractors. This publication is required for administrative and operational purposes as determined on 7 March 1994. Other requests for this document shall be referred to Director, Armament and Chemical Acquisition and Logistics Activity (ACALA), ATTN: AMSTA-AC-NML, Rock Island, IL 61299-7630. (E-mail: amsta-ac-nml@ria.army.mil).

DESTRUCTION NOTICE. Destroy by any method that will prevent disclosure of contents or reconstruction of the document.

TABLE OF CONTENTS

			Page	Illus/ Figure
Section	I.	Introduction	1	—
Section	II.	Repair Parts List	1-1	—
Group	00	Steam Cleaner, Trailer Mounted 11024645	1-1	1
Group	01	Cleaner, Steam, Pressure Jet, 200 GPH 11024000 (Labels and Data Plates)	2-1	2

TABLE OF CONTENTS (cont)

		Page	Illus/ Figure
Group	01		
	Cleaner, Steam, Pressure Jet, 200 GPH 11024000 and 0122 Pressure Gage Assembly 11024985	3-1	3
	Cleaner, Steam, Pressure Jet, 200 GPH 11024000 (Control Box and Panel)	4-1	4
	Cleaner, Steam, Pressure Jet, 200 GPH 11024000 (Switches)	5-1	5
	Cleaner, Steam, Pressure Jet, 200 GPH 11024000 (Tank and Platform)	6-1	6
	0101 Inlet Assembly, Coil 11024109	7-1	7
	0102 Outlet Assembly, Coil 11024170	8-1	8
	010201 Blowdown Assembly 11024956 and 01020101 Valve and Switch Assembly 11024941	9-1	9
	0103 Burner Assembly, Oil 11024215	10-1	10
	010301 Burner, Oil, Vaporizing, Atomizing 11024220	11-1	11
	0104 Tank Assembly, Fuel 11024222 (Motor, Control, and Pump Assemblies)	12-1	12
	0104 Tank Assembly, Fuel 11024222 (Saddle and Fuel Tank Components)	13-1	13
	010401 Inlet Assembly, Suction 11024018	14-1	14
	010402 Tank Assembly, Water 11024130	15-1	15
	010403 Pump Assembly 11024146	16-1	16
	010404 Inlet Assembly, Water 11024185	17-1	17
	010405 Inlet Assembly, Pump 11024195	18-1	18
	010406 Motor Assembly 11024208	19-1	19
	010407 Control Assembly, Coil Inlet 11024584	20-1	20
	010408 Drain Assembly, Oil 11024872	21-1	21
	0105 Lower Control Panel Assembly 11024303	22-1	22
	010501 Valve Assembly, Metering 11024304	23-1	23
	0106 Control Box Assembly 11024370	24-1	24
	010601 Control Panel Assembly 11024322	25-1	25
	010602 Electrical Components Assembly 11024363	26-1	26
	0107 Hose Assembly, Wash 11024408	27-1	27
	0108 Enclosure and Lift Assembly 11024520	28-1	28
	0108 Enclosure and Lift Assembly 11024520 (Frame)	29-1	29
	010801 Door, Access (Hose Rack) 11024412	30-1	30
	010802 Lift Assembly, Steam Cleaner 11024481	31-1	31
	0109 Cable Assembly, Special Purpose, Electrical (Facility Power) 11024763	32-1	32
	0110 Tubing Assembly (Coil Outlet to Pressure Switch) 11024820-1 and 0115 Tubing Assembly (Pressure Switch to Pressure Switch) 11024820-6	33-1	33

		Page	Illus/ Figure
	0111 Tubing Assembly (Coil Outlet to Differential Pressure Switch) 11024820-2		
	and		
	0113 Tubing Assembly (Coil Inlet to Differential Pressure Switch) 11024820-4	34-1	34
	0112 Tubing Assembly (Coil Inlet to Inlet Pressure Gage) 11024820-3		
	and		
	0114 Tubing Assembly (Coil Outlet to Outlet Pressure Gage) 11024820-5		
	and		
	0116 Tubing Assembly (Fuel Pump to Fuel Pressure Gage) 11024820-7	35-1	35
	0117 Outlet and Water Drain Assembly 11024848	36-1	36
	0118 Strainer Assembly, Fuel 11024870	37-1	37
	0119 Shutoff Assembly, Fuel 11024886	38-1	38
	0120 Coil Unit Assembly 11024903 (Heating Coil)	39-1	39
	0120 Coil Unit Assembly 11024903 (Shell and Internal Components)	40-1	40
	0121 Diagram, Connection (Electrical Components) 11024915	41-1	41
	012101 Wire Assembly 11024261		
	and		
	012103 Wire Assembly 11025004	42-1	42
	012102 Conduit Assembly 11024913	43-1	43
Group	02 Hose Assembly, Suction 11024270	44-1	44
Group	03 Cable Assembly, Power, Special Purpose, Electrical (Generator Power) 11024764	45-1	45
Group	04 Trailer, Flat Bed 11024780	46-1	46
	0401 Modification Assembly, M116A2 Trailer Chassis 11024765	47-1	47
	0402 Jack, Leveling-Support 11024771	48-1	48
	0403 Tube Assembly, Brake Line 11024822-1		
	and		
	0404 Tube Assembly, Brake Line 11024822-2		
	and		
	0405 Tube Assembly, Brake Line 11024822-3	49-1	49
Group	9999 Bulk Items	Bulk-1	-
SECTION	III Special Tools List	50-1	50
Group	9500 Special Tools	50-1	50
Section	IV. Cross-Reference Indexes	I-1	
	National Stock Number Index	I-1	
	Part Number Index	I-7	
	Figure and Item Number Index	I-22	

UNIT, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

SECTION I. INTRODUCTION

1. SCOPE

This RPSTL lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of unit, direct support, and general support maintenance of the trailer-mounted steam cleaner. It authorizes the requisitioning, issue, and disposition of spares, repair parts, and special tools as indicated by the source, maintenance, and recoverability (SMR) codes.

2. GENERAL

In addition to Section I, Introduction, this Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence. Bulk materials are listed in item name sequence. Repair parts kits are listed separately in their own functional group within Section II. Repair parts for repairable special tools are also listed in this section. Items listed are shown on the associated illustration(s)/figure(s).

b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized by this RPSTL (as indicated by Basis Of Issue (BOI) information in DESCRIPTION AND USABLE ON CODE column) for the performance of maintenance.

c. Section IV. Cross-Reference Indexes. A list, in National Item Identification Number (NIIN) sequence, of all National Stock Numbered items appearing in the listing, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. National Stock Numbers and part numbers are cross-referenced to each illustration figure and item number appearance. The figure and item number index lists figure and item numbers in alphanumeric sequence and cross-references NSN, CAGEC, and part number.

3. EXPLANATION OF COLUMNS (SECTIONS II AND III)

a. ITEM NO. (Column (1)). Indicates the number used to identify items called out in the illustration.