

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LIST
FOR

SWEEP SIGNAL GENERATOR, WAVETEK, MODEL 2001SP35

NSN 4931-00-165-3954

Current as of 17 October 1986

Approved for public release; distribution is unlimited.

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms) to: Commander, U.S. Army TMDE Support Group, ATTN: AMXTM-LML, Redstone Arsenal, AL 35898-5400. A reply will be furnished directly to you.

TABLE OF CONTENTS

	Page
Section I.	INTRODUCTION 1
Section II.	REPAIR PARTS LIST
Group 0010	Generator, signal-sweep 2-1
0020	Circuit card assembly 2-2
0030	Circuit card assembly 2-2
0040	Circuit card assembly 2-3
0050	Circuit card assembly 2-4
0060	Circuit card assembly 2-4
0070	Circuit card assembly 2-5
0080	Circuit card assembly 2-5
0090	Circuit card assembly 2-6
0100	Circuit card assembly 2-6
0110	Circuit card assembly 2-7
0120	Power supply 2-8
Section III.	SPECIAL TOOLS LIST (Not applicable)
Section IV.	NATIONAL STOCK NUMBER AND PART NUMBER INDEX..... I-1

*This manual supersedes TM 9-4931-491-34P, 16 October 1975.

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

REPAIR PARTS AND SPECIAL TOOLS LIST

SECTION I. INTRODUCTION

1. Scope. This RPSTL lists and authorizes spares and repair parts required for performance of direct and general support maintenance of Signal Sweep Generator Wavetek, Model 2001SP35. It authorizes the requisitioning, issue, and disposition of spares and repair parts as indicated by the Source, Maintenance and Recoverability (SMR) codes.

2. General. In addition to this section I, Introduction, this Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. Parts lists are composed of functional groups in ascending numeric sequence. Parts are listed in alphabetical sequence within each figure number.

b. Section III. Special Tools List. Not applicable.

c. Section IV. National Stock Number and Part Number Index. A list, in National Item Identification Number (NIIN) sequence, of all National Stock Numbered (NSN) items appearing in the listing, followed by a list in alphanumeric sequence of all part numbers appearing in the listing. NSN's and part numbers are cross-referenced to the figure and item number appearance.

3. Explanation of Columns (Section II)

a. Item No. (Column (1)). Indicates the number used to identify each item appearing in the listing.

b. SMR CODE (Column (2)). The Source, Maintenance, and Recoverability (SMR) code is a 5-position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instructions as shown in the following breakdown: