

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

---

DS, GS, AND DEPOT MAINTENANCE MANUAL  
INCLUDING REPAIR PARTS AND SPECIAL TOOLS LISTS

RIFLE CALIBER .30, AUTOMATIC:

BROWNING, M1918A2, W/E  
(1005-674-1309)

---

HEADQUARTERS, DEPARTMENT OF THE ARMY

MARCH 1970

**DS, GS, DEPOT MAINTENANCE MANUAL**  
**INCLUDING REPAIR PARTS AND**  
**SPECIAL TOOLS LISTS**

**RIFLE CALIBER .30, AUTOMATIC:**

**BROWNING, M1918A2, W/E**

**(1005-674-1309)**

*This manual is current as of 26 June 1969*

|          |      |                                                                                                      | Paragraphs | Pages |
|----------|------|------------------------------------------------------------------------------------------------------|------------|-------|
| CHAPTER  | 1.   | INTRODUCTION                                                                                         |            |       |
| Section  | I.   | General .....                                                                                        |            |       |
| Section  | II.  | Description and data.....                                                                            |            |       |
| CHAPTER  | 2.   | DIRECT SUPPORT, GENERAL SUPPORT AND<br>DEPOT MAINTENANCE INSTRUCTIONS                                |            |       |
| Section  | I.   | Repair parts, special tools and equipment                                                            |            |       |
| Section  | II.  | Troubleshooting                                                                                      |            |       |
| Section  | III. | Preembarkation inspection of materiel in units alerted for<br>overseas movement .....                |            |       |
| Section  | IV.  | General maintenance .....                                                                            |            |       |
| Section  | V.   | Removal and installation of major components .....                                                   |            |       |
| Section  | VI.  | Depot maintenance instructions .....                                                                 |            |       |
| CHAPTER  | 3.   | REPAIR INSTRUCTIONS                                                                                  |            |       |
| CHAPTER  | 4.   | MAINTENANCE OF MATERIEL USED IN CONJUNCTION<br>WITH MAJOR ITEM                                       |            |       |
| CHAPTER  | 5.   | FINAL INSPECTION                                                                                     |            |       |
| APPENDIX | A.   | REFERENCES                                                                                           |            |       |
| APPENDIX | B.   | DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE<br>REPAIR PARTS AND SPECIAL TOOLS LISTS       |            |       |
| Section  | I.   | Introduction .....                                                                                   |            |       |
| Section  | II.  | Repair parts list .....                                                                              |            |       |
|          |      | Major assemblies, groups and components (fig B-1) .....                                              |            |       |
|          |      | Trigger guard assembly (fig B-2) .....                                                               |            |       |
|          |      | Bolt group (fig B-3) .....                                                                           |            |       |
|          |      | Gas cylinder and fore end group (fig B-4) .....                                                      |            |       |
|          |      | Slide and piston group (fig B-5) .....                                                               |            |       |
|          |      | Butt stock, buffer and actuator group (fig B-6) .....                                                |            |       |
|          |      | Bipod assembly (fig B-7) .....                                                                       |            |       |
|          |      | Rear sight assembly (fig B-8).....                                                                   |            |       |
|          |      | Barrel and receiver group (fig B-9).....                                                             |            |       |
|          |      | Winter trigger kit (fig B-10) .....                                                                  |            |       |
| Section  | III. | Special tools list (figs B-11 - B-14) .....                                                          |            |       |
| Section  | IV.  | Index - Federal stock-number and reference number cross-reference<br>to figure and item number ..... |            |       |

\* This manual supersedes TM 9-1005-208-35, 22 September 1964, in its entirety; and TM 9-1005-208-35P, 13 February 1964 in its entirety, including changes.

## CHAPTER 1


## INTRODUCTION

## Section I. GENERAL

**1-1. Scope**

These instructions are in accordance with the MAC (refer to TM 9-1005-208-12) and are published for the use of direct support, general support, and depot maintenance of the Caliber .30 Browning Automatic Rifle

M1918A2 (fig 1-1). They provide information on the maintenance of the equipment which is beyond the scope of the tools, equipment, or supplies normally available to operator's or organizational maintenance.



*Figure 1-1. Caliber .30 Browning Automatic Rifle M1918A2.*

**1-2. Forms and Records**

Maintenance forms, records, and reports which are to be used by maintenance personnel at all maintenance levels are listed in and prescribed by TM 38-750.

dations for improving this publication by the individual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended changes to DA Publications) and forwarded direct to:

**1-3. Recommendations for Equipment Publications Improvements**

Report of errors, omissions, and recommen-

Commanding General  
U.S. Army Weapons Command  
ATTN: AMSWE-SMM-P  
Rock Island, Illinois 61201

## Section II. DESCRIPTION AND DATA

**1-4. Description and Tabulated Data**

Refer to TM 9-1005-208-12.