

**\*ARMY TM 9-2815-255-24P  
AIR FORCE TO 38G1-95-4  
MARINE CORPS TM 2815-24P/2**

---

**TECHNICAL MANUAL**

**UNIT, DIRECT SUPPORT AND  
GENERAL SUPPORT MAINTENANCE  
REPAIR PARTS AND SPECIAL TOOLS LIST**

**DIESEL ENGINE**

**2815-01-350-2208 MODEL 4039TF002**

**FOUR-CYLINDER, FOUR CYCLE, TURBOCHARGED**

\*This manual supersedes TM 9-2815-255-24P/TO 38G1-95-4/TM 2815-24P/2. dated 30 July 1993, Including all changes

Distribution Statement A. Approved for public release; distribution is unlimited

---

**HEADQUARTERS, DEPARTMENTS OF THE ARMY,  
AIR FORCE, AND HEADQUARTERS U.S. MARINE CORPS**

**30 OCTOBER 1996**

TECHNICAL MANUAL  
NO. 9-2815-255-24P

HEADQUARTERS DEPARTMENTS OF THE ARMY,  
AIR FORCE, AND HEADQUARTERS U.S. MARINE CORPS  
WASHINGTON D.C., 30 OCTOBER 1996

UNIT, DIRECT SUPPORT AND  
GENERAL SUPPORT MAINTENANCE  
REPAIR PARTS AND SPECIAL TOOLS LIST

DIESEL ENGINE  
2815-01-350-2208 MODEL 4039TF002  
FOUR-CYLINDER, FOUR CYCLE, TURBOCHARGED

Current as of 1 October 1996

\*This manual supersedes TM 9-2815-255-24P/TO 38G1-95-4/TM 2815-24P/2, dated 30 July 1993, including all changes.

#### REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve these procedures, please let us know.

(A) Mail your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual directly to: Commander, US Army Aviation and Troop Command, ATTN: AMSAT-I-MP, 4300 Goodfellow Blvd., St. Louis, MO 63120-1798. You may also submit your recommended changes by E-mail directly to <mpmt%avma28@st-louis-emh7.army.mil>. Instructions for sending an electronic 2028 may be found at the back of this publication immediately preceding the hard copy 2028.

(F) Air Force - AFTO Form 22 Directly to: Commander, Sacramento Air Logistics Center, ATTN: TILBA, McClellan AFB, CA 95652-5990 (AFMC).

(MC) Marine Corps - NAVMC Form 10772 Directly to: Commander, Marine Corps Logistics Bases (Code 850), Albany, GA 31704-5000.

A reply will be furnished directly to you.

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited.

# TABLE OF CONTENTS

|             |                                                   | Page | Illus/<br>Figure |
|-------------|---------------------------------------------------|------|------------------|
| Section I.  | INTRODUCTION .....                                | 1    |                  |
| Section II. | REPAIR PARTS LIST .....                           |      |                  |
| Group 01    | Cooling System .....                              |      |                  |
|             | Alternator Drive Pulley .....                     | 1-1  | 1                |
|             | Thermostat and Housing .....                      | 2-1  | 2                |
|             | Water Pump Assembly .....                         | 3-1  | 3                |
| Group 02    | Electrical System .....                           |      |                  |
|             | Alternator Attaching Hardware .....               | 4-1  | 4                |
|             | Alternator Assembly .....                         | 5-1  | 5                |
|             | Alternator Bracket .....                          | 6-1  | 6                |
|             | Starting Motor Assembly .....                     | 7-1  | 7                |
| Group 03    | Intake and Exhaust .....                          |      |                  |
|             | Turbocharger .....                                | 8-1  | 8                |
|             | Exhaust Manifold .....                            | 9-1  | 9                |
|             | Intake Manifold .....                             | 10-1 | 10               |
| Group 04    | Lubrication System .....                          |      |                  |
|             | Oil Filter and Cooler .....                       | 11-1 | 11               |
|             | Dipstick .....                                    | 12-1 | 12               |
|             | Oil Filler and Regulating Valve<br>Assembly ..... | 13-1 | 13               |
|             | Oil Pan .....                                     | 14-1 | 14               |
|             | Oil Pump Assembly .....                           | 15-1 | 15               |
| Group 05    | Fuel System .....                                 |      |                  |
|             | Fuel Filter and Pump .....                        | 16-1 | 16               |
|             | Fuel Lines .....                                  | 17-1 | 17               |
|             | Fuel Injection Pump .....                         | 18-1 | 18               |
|             | Fuel Injector .....                               | 19-1 | 19               |
| Group 06    | Cylinder Head Assembly .....                      |      |                  |
|             | Valve Cover .....                                 | 20-1 | 20               |
|             | Rocker Arm Assembly .....                         | 21-1 | 21               |
|             | Head Assembly .....                               | 22-1 | 22               |
| Group 07    | Flywheel .....                                    |      |                  |
|             | Engine Flywheel .....                             | 23-1 | 23               |
| Group 08    | Crankshaft Pulley .....                           |      |                  |
|             | Crankshaft Pulley .....                           | 24-1 | 24               |
| Group 09    | Timing Gear Cover .....                           |      |                  |
|             | Timing Gear Cover .....                           | 25-1 | 25               |
| Group 10    | Short Block Assembly .....                        |      |                  |
|             | Short Block Assembly .....                        | 26-1 | 26               |
|             | Camshaft and Balancer Shafts .....                | 27-1 | 27               |
|             | Timing Gears .....                                | 28-1 | 28               |
|             | Front Cover .....                                 | 29-1 | 29               |
|             | Crankshaft .....                                  | 30-1 | 30               |
|             | Connecting Rods and Pistons .....                 | 31-1 | 31               |

TABLE OF CONTENTS - Continued

|              |                                   | Page   | Illus/<br>Figure |
|--------------|-----------------------------------|--------|------------------|
| Group 10     | Short Block Assembly - Continued  |        |                  |
| Group 11     | Engine Block .....                | 32-1   | 32               |
|              | Bulk Items .....                  | Bulk-1 |                  |
| Section III. | SPECIAL TOOLS LIST.....           | 33-1   | 33               |
| Section IV.  | CROSS REFERENCE INDEXES .....     | I-1    |                  |
|              | National Stock Number Index ..... | I-1    |                  |
|              | Part Number Index .....           | I-4    |                  |
|              | Figure and Item Number Index..... | I-18   |                  |

UNIT, DIRECT SUPPORT, AND  
GENERAL SUPPORT MAINTENANCE  
REPAIR PARTS AND SPECIAL TOOLS LIST  
SECTION I. INTRODUCTION

1. Scope.

This RPSTL lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of unit, direct support, and general support maintenance of the Diesel Engine. It authorizes the requisitioning, issue and disposition of spares, repair parts and special tools as indicated by the source, maintenance and recoverability (SMR) codes.

2. General.

In addition to Section I, Introduction, this Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending figure and item number sequence. Bulk materials are listed in item name sequence. Repair parts kits are listed separately in their own functional group within Section II. Repair parts for repairable special tools are also listed in this section. Items listed are shown on the associated illustration(s)/figure(s).

b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in DESCRIPTION AND USABLE ON CODE column) for the performance of maintenance.