

***ARMY TM 9-2815-256-24P
AIR FORCE TO 38G1-96-4
MARINE CORPS TM 2815-24P/3**

TECHNICAL MANUAL

**UNIT, DIRECT SUPPORT AND
GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LIST**

DIESEL ENGINE

**2815-01-350-2209 MODEL 6059TF002
SIX CYLINDER, FOUR CYCLE, TURBOCHARGED**

***This manual supersedes TM 9-2815-256-24P/TO 38G1-96-4/TM 2815-24P/3, dated 30 July 1993, including all changes.**

Distribution Statement A. Approved for public release; distribution is unlimited.

**HEADQUARTERS, DEPARTMENTS OF THE ARMY,
AIR FORCE, AND HEADQUARTERS U.S. MARINE CORPS**

30 OCTOBER 1996

TECHNICAL MANUAL

NO. 9-2815-256-24P

HEADQUARTERS DEPARTMENTS OF THE ARMY,
AIR FORCE, AND HEADQUARTERS U.S. MARINE CORPS
WASHINGTON D.C., 30 OCTOBER 1996

UNIT, DIRECT SUPPORT AND
GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LIST

DIESEL ENGINE
2815-01-350-2209 MODEL 6059TF002
SIX CYLINDER, FOUR CYCLE, TURBOCHARGED

Current as of 1 October 1996

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve these procedures, please let us know.

(A) Mail your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual directly to: Commander, US Army Aviation and Troop Command, ATTN: AMSAT-I-MP, 4300 Goodfellow Blvd., St. Louis, MO 63120-1798. You may also submit your recommended changes by E-mail directly to <mpmt%avma28@st-louis-emh7.army.mil>. Instructions for sending an electronic 2028 may be found at the back of this publication immediately preceding the hard copy 2028.

(F) Air Force - AFTO Form 22 Directly to: Commander, Sacramento Air Logistics Center, ATTN: TILBA, McClellan AFB, CA 95652-5990 (AFMC).

(MC) Marine Corps - NAVMC Form 10772 Directly to: Commander, Marine Corps Logistics Bases (Code 850), Albany, GA 31704-5000.

A reply will be furnished directly to you.

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited.

*This manual supersedes TM 9-2815-256-24P/TO 38G1-96-4/TM 2815-24P/3, dated 30 July 1993, including all changes.

TABLE OF CONTENTS

		Page	Illus/ Figure
Section I.	INTRODUCTION	1	
Section II.	REPAIR PARTS LIST		
Group 01	Cooling System		
	Alternator Drive Pulley	1-1	1
	Thermostat and Housing	2-1	2
	Water Pump Assembly	3-1	3
Group 02	Electrical System		
	Alternator Attaching Hardware . . .	4-1	4
	Alternator Assembly	5-1	5
	Alternator Bracket	6-1	6
	Starting Motor Assembly	7-1	7
Group 03	Intake an Exhaust		
	Turbocharger	8-1	8
	Exhaust Manifold	9-1	9
	Intake Manifold	10-1	10
Group 04	Lubrication System		
	Oil Filter and Cooler	11-1	11
	Dipstick	12-1	12
	Oil Filler and Regulation Valve Assembly	13-1	13
	Oil Pan Assembly	14-1	14
	Oil Pump Assembly	15-1	15
Group 05	Fuel System		
	Fuel Filter and Pump	16-1	16
	Fuel Lines	17-1	17
	Fuel Injection Pump	18-1	18
	Fuel Injector	19-1	19
Group 06	Cylinder Head Assembly		
	Rocker Cover	20-1	20
	Rocker Arm Assembly	21-1	21
	Cylinder Head Assembly	22-1	22
Group 07	Flywheel		
	Flywheel and Housing	23-1	23
Group 08	Crankshaft Pulley		
	Crankshaft Pulley	24-1	24
Group 09	Timing Gear Cover		
	Timing Gear Cover	25-1	25
Group 10	Short Block Assembly		
	Short Block Assembly	26-1	26
	Timing Gear and Camshaft	27-1	27
	Front Cover	28-1	28
	Crankshaft	29-1	29
	Connecting Rods and Pistons	30-1	30
	Engine Block Assembly	31-1	31
Group 11	Bulk Items	Bulk-1	

TABLE OF CONTENTS - Continued

		Page	IllUS/ Figure
Section III.	SPECIAL TOOLS LIST	32-1	32
Section IV.	CROSS REFERENCE INDEXES	I-1	
	National Stock Number Index . . .	I-1	
	Part Number Index	I-7	
	Figure and Item Number Index . . .	I-21	

UNIT, DIRECT SUPPORT, AND
GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LIST
SECTION I. INTRODUCTION

1. Scope.

This RPSTL lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of unit, direct support, and general support maintenance of the Diesel Engine. It authorizes the requisitioning, issue and disposition of spares, repair parts and special tools as indicated by the source, maintenance and recoverability (SMR) codes.

2. General.

In addition to Section I, Introduction, this Repair Parts and Special Tools List is divided into the following sections:

a. Section II, Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending figure and item number sequence. Bulk materials are listed in item name sequence. Repair parts kits are listed separately in their own functional group within Section II. Repair parts for repairable special tools are also listed in this section. Items listed are shown on the associated illustration(s)/figure(s).

b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in DESCRIPTION AND USABLE ON CODE column) for the performance of maintenance.