

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL
TOOL LISTS, SIGNAL GENERATOR SET
AN/URM-25D

Headquarters, Department of the Army, Washington, D. C 20315
12 November 1964

	Paragraph	Page
SECTION I. INTRODUCTION		
Scope	1	1
Parts for maintenance	2	2
Reference	3	2
Reporting of equipment manual improvements	4	2
II. FUNCTIONAL PARTS LIST		3

SECTION I
INTRODUCTION

1. Scope

a. This manual lists the repair parts authorized for organizational maintenance and constitutes a basis of requisitioning when the major item of equipment is authorized to the organization. These equipments are issued on the basis of allowances prescribed in equipment authorization tables and other documents which are a basis of requisitioning.

b. Columns are as follows:

- (1) *Federal stock number.* This column lists the 11-digit Federal stock number.
- (2) *Designation by model.* The dagger (†) indicates serial No. in which the part is used.

(3) *Description.* Nomenclature or the standard item name and brief identifying data for each item are listed in this column. When requisitioning, enter the nomenclature and description.

(4) *Unit of issue.* The unit of issue is each unless otherwise indicated and is the supply term by which the individual item is counted for procurement, storage, requisitioning, allowances, and issue purposes.

(5) *Expendability.* Nonexpendable items are indicated by NX. Expendable items are not annotated.

(6) *Quantity incorporated in unit.* This column lists the quantity of each part

* This manual, together with C4, 12 November 1964 of TM 11-5551D, 1 March 1956, C4, 12 November 1964 of TM 11-5551E, 4 September 1956, and TM 11-6625-603-20P, 23 October 1964, supersedes TM 11-6225-278-20P, 24 November 1956, including C1, 15 July 1960.

found in a given assembly, component, or equipment.

- (7) *Organizational.* An asterisk (*) indicates that an item is not authorized for stockage but, if required, may be requisitioned for immediate use only.
- (8) *Illustration.* The "Item No." column lists the reference designations that appear on the part in the equipment. These same designations are also used on any illustrations of the equipment. The numbers in the "Figure No." column refer to the illustrations where the part is shown in TM 11-5551D.

2. Parts for Maintenance

When this equipment is used by signal service organizations organic to the theater headquarters or communication zones to provide theater communications, those repair parts authorized up to and

including general support are authorized for stockage by the organization operating this equipment.

3. References

A maintenance allocation chart and basic issue items list are contained in TM 11-5551D.

4. Reporting of Equipment Manual Improvements

The direct reporting by the individual user of errors, omissions, and recommendations for improving this equipment manual is authorized and encouraged. DA Form 2028 will be used for reporting these improvements. This form may be completed using pencil, pen, or typewriter. DA Form 2028 will be completed in triplicate and forwarded by the individual using the manual. The original and one copy will be forwarded direct to: Commanding General, U. S. Army Electronics Command, ATTN: AMSE-MR-MA, Fort Monmouth, New Jersey 07703. One information copy will be furnished to the individual's immediate supervisor (officer, noncommissioned officer, supervisor, etc).