

TECHNICAL MANUAL

**GENERAL SUPPORT MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS LISTS (INCLUDING DEPOT
MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)**

SIGNAL GENERATORS

TS-452 B/U (FSN 6625-643-1706),

TS-452 C/U (FSN 6625-643-1521),

AND

TS-452 D/U (FSN 6625-828-6410)

THIS PUBLICATION IS A COURTESY QUICK COPY FROM THE UNITED STATES ARMY PUBLICATIONS DISTRIBUTION CENTER, ST. LOUIS MO TO MEET YOUR NEEDS WHILE WE REPLENISH OUR STOCK.

TECHNICAL MANUAL }
No. 11-6625-283-40P }

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 31 August 1973

**General Support Maintenance Repair Parts and Special Tools Lists
(Including Depot Maintenance Repair Parts and Special Tools)**

**SIGNAL GENERATORS TS-452B/U (FSN 6625-643-1706), TS-452C/U
(FSN 6625-643-1521), AND TS-452D/U (FSN 6625-828-6410)**

Current as of February 1973

SECTION		Paragraph	Page
I.	INTRODUCTION		
	Scope -----	1-1	2
	General -----	1-2	2
	Explanation of columns -----	1-3	2
	Special information -----	1-4	4
	Location of repair parts-----	1-5	5
	Abbreviations (Not applicable) -----	1-6	5
	Reporting of equipment publication improvements -----	1-7	5
II.	REPAIR PARTS LIST -----		6
III.	SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable)		
IV.	INDEX-FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS- REFERENCE TO FIGURE AND ITEM NUMBER-----		29

*This manual supersedes TM 11-6625-283-45P, 27 September 1963.

SECTION I

INTRODUCTION

1-1. Scope

This manual lists repair parts and special tools required for the performance of general support and depot maintenance of the TS-452B/U, TS-452C/U, and TS-452D/U. The PCCN for the equipment is GTEAAX for all models.

NOTE

No parts authorized for stockage at direct support.

1-2. General

This repair parts and special tools list is divided into the following sections:

a. Repair Parts List—Section II. A list of repair parts authorized for the performance of maintenance at the general support and depot level. This repair parts list is arranged in alphabetical order.

b. Special Tools, Test and Support Equipment—Section III. Not applicable.

c. Index-Federal Stock Number and Reference Number Cross-Reference to Figure and Item Number—Section IV. A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphameric sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure and item number or reference designation appearance.

1-3. Explanation of Columns

The following provides an explanation of columns found in the tabular list.

a. Source, Maintenance, and Recoverability Codes (SMR).

(1) *Source code.* Indicates the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are—

<i>Code</i>	<i>Explanation</i>
-------------	--------------------

PA—Item procured and stocked for anticipated or known usage.	
--	--

PB—Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply systems.	
---	--

*Code**Explanation*

PC—Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.	
---	--

PD—Support item, excluding support equipment, procured for initial issue or out-fitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.	
--	--

PE—Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.	
---	--

PF—Support equipment which will not be stocked but which will be centrally procured on demand.	
--	--

PG—Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which because of probable discontinuance or shutdown of production facilities would prove uneconomical to reproduce at a later time.	
--	--

KD—An item of depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.	
--	--

KF—An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or direct support or general support levels of maintenance.	
---	--

KB—Item included in both a depot overhaul/repair kit and a maintenance kit.	
---	--

MO—Item to be manufactured or fabricated at organizational level.	
---	--

MF—Item to be manufactured or fabricated at direct support maintenance level.	
---	--

MH—Item to be manufactured or fabricated at general support maintenance level.	
--	--