

TECHNICAL MANUAL

**ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL
SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL
TOOLS LISTS (INCLUDING DEPOT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOL)
SIGNAL GENERATORS SG-71/FCC, SG-71A/FCC,
SG-71B/FCC AND SG-71C/FCC,
FSN 6625-669-0255**

H E A D Q U A R T E R S , D E P A R T M E N T O F T H E A R M Y

SEPTEMBER 1973

Technical Manual }
No. 11-6625-358-24P }

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, D. C., 28 September 1973

**Organizational, Direct Support, and General
Support Maintenance Repair Parts and Special
Tools Lists (Including Depot Maintenance
Repair Parts and Special Tools)
SIGNAL GENERATORS SG-71/FCC, SG-71A/FCC,
SG-71B/FCC, AND SG-71C/FCC
FSN 6625-669-0255**

Current as o February 1973

	Paragraph	Page
Section I.	INTRODUCTION	
	Scope.....	1-1 1
	General.....	1-2 1
	Explanation of columns	1-3 1
	Special information	1-4 3
	Location of repair parts.....	1-5 3
	Abbreviations(Not applicable).....	1-6 3
	Reporting of equipment publication improvements	1-7 3
II.	PREScribed LOAD ALLOWANCE (Not applicable)	
III.	REPAIR PARTS LIST.....	6
IV.	SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable)	
V.	REPAIR PARTS LIST.....	7-24
VI.	SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable)	
VII.	INDEX -FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS-REFERENCE TO FIGURE AND ITEM NUMBER	25-28

*This manual Supersedes TM 11-6625-325P, 22 August 1966.

Code	Explanation
G	Major assemblies that are procured with PEMA funds for initial issue only as exchange assemblies at DS and GS lever. These assemblies will not be stocked above DS and GS level or returned to depot supply level.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded X1 and aircraft support items as restricted by AR 70042.

(2) *Maintenance code.* Indicates the lowest category of maintenance authorized to install the listed item. Capabilities of higher maintenance categories are considered equal or better. Maintenance codes are-

Code	Explanation
C.....	Crew/operator
O.....	Organizational maintenance
F.....	Direct support maintenance
H.....	General support maintenance
D.....	Depot maintenance

(3) *Recoverability code.* Indicates whether un-serviceable items should be returned for recovery or salvage. Items not coded are nonrecoverable. Recoverability codes are-

Code	Explanation
R-	Repair parts (assemblies and components), special tools and test equipment which are considered economically repairable at direct and general support maintenance levels. When the item is no longer economically repairable, it is normally disposed of at the GS level. When supply considerations dictate, some of these repair parts may be listed for automatic return to supply for depot level repair as set forth in AR 710-50. When so listed, they will be replaced by supply on an exchange basis.
S-	Repair parts, special tools and test equipment, and assemblies which are economically repairable at DS and GS activities and which normally are furnished by supply on an exchange basis. When items are determined by a GSU to be uneconomically repairable, they will be evacuated to a depot for evaluation and analysis before final disposition.
T-	High dollar value recoverable repair parts, special tools and test equipment which are subject to special handling and are issued on an exchange basis. Such items will be repaired or overhauled at depot maintenance activities only. No repair may be accomplished at lower levels.

Code	Explanation
U-	Repair parts, special tools and test equipment specifically selected for salvage by reclamation

units because of precious metal content, critical materials, high dollar value, of reusable casings or castings.

b. Federal Stock Number. Indicates the Federal stock number assigned to the item and will be used for requisitioning purposes.

c. Description. Indicates the Federal item name and a minimum description required to identify the item. The last line indicates the reference number followed by the applicable Federal Supply Code for Manufacturer (FSCM) in parentheses. The FSCM is used as an element in item identification to designate manufacturer or distributor or Government agency, etc, and is identified in SB 708-42.

d. Unit of Measure (U/M). Indicates the standard or basic quantity by which the listed item is used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation; e.g., ea, in, pr, etc., and is the basis used to indicate quantities and allowances in subsequent columns. When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

e. Quantity Incorporated in Unit. This column indicates the quantity of the item used in the equipment. Subsequent appearances of the same item in the same assembly are indicated by the letters "REF".

f. 15-Day Organizational Maintenance Allowances.

(1) The repair parts indicated by an asterisk in the allowance column represent those authorized for use at the organizational category, and will be requisitioned on an "as required" basis, until stockage is based on demand in accordance with AR 710-2.

(2) Major Army commanders are authorized to approve reduction in the range of support items authorized for use in units within their commands. Recommendations for increase in range of items authorized for use will be forwarded to Commander, US Army Electronics Command, ATTN: AMSEL-MA-CRA, Fort Monmouth, N.J., 07703.

(3) Allowance quantities are indicated in the special tools list section for special tools, TMDE, an other support equipment.

g. 30-Day DS/GS Maintenance Allowances.

NOTE

Allowances in GS column are for GS maintenance only.