

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

REPAIR PARTS AND SPECIAL TOOLS LIST

FOR

RECEIVER, RADIO FREQUENCY, WEINSCHEL, MODEL VM-4A

NSN 4931-01-041-1564

AND

TRACKING OSCILLATOR, WEINSCHEL, MODEL VM-4A/H-2

NSN 6695-01-102-4342

Current as of 4 September 1984

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms) to: Commander, US Army TMDE Support Group, ATTN: AMXTM-LML, Redstone Arsenal, AL 35898-5400. A reply will be furnished directly to you

TABLE OF CONTENTS

	Page
Section I. INTRODUCTION	1
Section II. REPAIR PARTS LIST	2-1
Group 0010 Receiver, radio frequency	2-1
0020 Power supply module assembly	2-2
0030 Power supply assembly.....	2-2
0040 Regulator board assembly.....	2-2
0050 Switching board assembly.....	2-3
0060 Switching board assembly.....	2-3
0070 Control board assembly	2-4
0080 Control board assembly	2-5
0090 Tracking oscillator	2-5

*This manual supersedes TM 9-4931-526-34P, 1 June 1983.

TABLE OF CONTENTS - Continued

	Page
Group 0100 Power supply	2-6
0110 Regulator board assembly	2-6
0120 Switching board assembly.....	2-7
0130 Switching board assembly.....	2-7
0140 Control board assembly	2-7
0150 Control board assembly	2-8
0160 Power supply assembly.....	2-9
Section III SPECIAL TOOLS LIST (Not applicable)	
Section IV. NATIONAL STOCK NUMBER AND PART NUMBER INDEX	I-1

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

REPAIR PARTS AND SPECIAL TOOLS LIST

SECTION I. INTRODUCTION

1. Scope. This RPSTL lists and authorizes spares and repair parts required for performance of direct and general support maintenance of Receiver, Radio Frequency, Weinschel, Model VM-4A, and Tracking Oscillator, Weinschel, Model VM-4A/H02. It authorizes the requisitioning, issue, and disposition of spares and repair parts as indicated by the Source, Maintenance and Recoverability (SMR) codes.

2. General. In addition to this section I, Introduction, this Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. Parts lists are composed of functional groups in ascending numeric sequence. Parts are listed in alphabetical sequence within each figure number.


b. Section III. Special Tools List. Not applicable.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbered items (NSN) appearing in the listing, followed by a list in alphanumeric sequence of all part numbers appearing in the listing. NSN's and part numbers are cross-referenced to the figure and item number appearance.

3. Explanation of Columns (Section II)

a. Item No. (Column (1)). Indicates the number used to identify each item appearing in the listing.

b. SMR CODE (Column (2)). The Source, Maintenance, and Recoverability (SMR) code is a 5- position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instructions as shown in the following breakdown:



*Complete Repair: Maintenance capacity, capability, and authority to perform all the corrective maintenance tasks of the "Repair" function in a use/user environment in order to restore serviceability to a failed item.