

TECHNICAL MANUAL
ORGANIZATIONAL MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS LIST
FOR
LUBRICATING AND SERVICING UNIT,
POWER OPERATED,
TRAILER MOUNTED, 23 CFM,
COMPRESSOR, RECIPROCATING,
GED (ELLIOTT MACHINE MODEL ENG 3)
NSN 4930-00-935-4451

Approved for public release; distribution is unlimited

This manual supersedes TM 5-4930-217-20P, 20 February 1987, including all changes.

HEADQUARTERS, DEPARTMENT OF THE ARMY
10 MAY 1990

**Organizational Maintenance
Repair Parts and Special Tools List
for
LUBRICATING AND SERVICING UNIT
POWER OPERATED, TRAILER MOUNTED
23 CFM, COMPRESSOR, RECIPROCATING,
GED (ELIOTT MACHINE MODEL ENG 3)
NSN 4930-00-935-4451**

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

Current as of 21 December 1989

REPORTING OF ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistake or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms) or DA Form 2028-2 located in the back of this manual direct to Commander, U.S. Army Aviation and Troop Command, ATTN: AMSAT-I-MP, 4300 Goodfellow Blvd, St. Louis, MO 63120-1798. A reply will be furnished directly to you.

TABLE OF CONTENTS

		Page	Illust/ Figure
Section I.	Introduction	1	
Section II.	Repair Parts List.....	1-1	
Group 01	Enclosure	1-1	
Group 02	Pump Transfer		
	Pump Transfer "A"	2-1	
	Pump Valve and Oiler "A"	3-1	3
	Pump Transfer "A" (Not Applicable)		
	Pump Transfer "B"	5-1	5
Group 03	Hose Lines and Fittings	6-1	6
Group 04	Light Assembly and Frame		
	Light	7-1	7
	Frame	8-1	8
Group 05	Alcohol Dispenser		
	Valve Control	9-1	9
	Alcohol Dispenser	10-1	10

*This manual supersedes TM 5-4930-217-20P, 20 February 1987, including all changes.

Group 06	Reel Assembly		
	Reel	11-1	11
Group 07	Air Regulator	12-1	12
Group 08	High and Low Pressure Pumps		
	High and Low Pressure Pump "A"	13-1	13
	High and Low Pressure Pump "A"	14-1	14
	High and Low Pressure Pump "B"	15-1	15
Group 09	Control Panel	16-1	16
Group 10	Reservoir	17-1	17
Group 11	Lubricating Unit	18-1	18
Group 12	Tool Box	19-1	19
Group 13	Air Drain Assembly		
	Air Drain	20-1	20
Group 14	Fittings		
	Accessories	21-1	21
	Fittings.....	22-1	22
	Accessories	23-1	23
Group 15	Drawers.....	24-1	24
Group 16	Batteries and Box.....	25-1	25
Group 17	Frame	26-1	26
Group 18	Control Valves		
	Control Valves, Grease "B"	27-1	27
	Control Valve, Oil1 "A".....	28-1	28
	Control Valve, Grease "A".....	29-1	29
	Control Valve, Oil "B".....	30-1	30
Group 19	Fuel Tank.....	31-1	31
Group 20	Generator		
	Guard Generator.....	32-1	32
	Engine Generator.....	33-1	33
Group 21	Starter		
	Starter "A".....	34-1	34
	Starter "B".....	35-1	35
Group 22	Diverters	36-1	36
Group 23	Engine Sheave.....	37-1	37
Group 24	Engine and Components	38-1	38
Group 25	Compressor and Guards	39-1	39
	Air Cleaner.....	40-1	40
	Cylinder Head	41-1	41
	Pistons (Not Applicable).....		
	Crankcase.....	43-1	43
Group 26	Compressor Tank and Lines.....	44-1	44
	Valve	45-1	45
Group 27	Valve Relay.....	46-1	46
Group 28	Master Cylinder	47-1	47
Group 29	Air Chamber.....	48-1	48
Group 30	Air Filter	49-1	49
Group 31	Air Tank	50-1	50
Group 32	Brake Lines	51-1	51

Group 33	Clearance Lights, Stoplight and Reflector		
	Clearances Lights	52-1	52
	Stoplight, Blackout	53-1	53
	Stoplight	54-1	54
	Reflector	55-1	55
Group 34	Cable Assembly		
	Cable	5-1	56
Group 35	Lunette, Safety Chain	57-1	57
Group 36	Chock Blocks	58-1	58
Group 37	Fenders	59-1	59
Section III	Special Tools List (Not Applicable)		
Section IV	Cross Reference Indexes		
	National Stock Number Index	I-1	
	Part Number Index	I-5	
	Figure and Item Number Index	I-22	

iii/iv(blank)

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

SECTION I. INTRODUCTION

1. SCOPE. This RPSTL lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of Organizational Maintenance of the Lubricating and Servicing Unit. It authorizes the requisitioning, issue, and disposition of spares, repair parts and special tools as indicated by the source, maintenance and recoverability (SMR) codes.

2. GENERAL. In addition to this section, Introduction, this Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. This list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence. Bulk materials are listed in item name sequence. Repair parts kits are listed separately in functional groups in Section II. Repair parts for repairable special tools are also listed in this section. Items listed are shown in the associated illustration(s)/figure(s).

b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in DESCRIPTION AND USABLE ON CODE column) for the performance of maintenance.

c. Section IV. Cross-Reference Index. A list, in National Item Identification Number (NIIN) sequence, of all national stock numbered items appearing in the listing, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross referenced to each illustration figure and item number appearance. The figure and item number index lists figure and item numbers in alphanumeric sequence and cross references NSN, FSCM and part number.

3. EXPLANATION OF COLUMNS (SECTIONS II AND III).

a. ITEM NO. (Column (1)). Indicates the number used to identify items called out in the illustration.

b. SMR Code (Column (2)). The Source, Maintenance, and Recoverability (SMR) code is a 5-position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instruction, as shown in the following breakout:

