

**ORGANIZATIONAL AND FIELD MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LIST**

FOR

**SEMITRAILER, TANK: FUEL SERVICING,
5000 GALLON, 4-WHEEL, M131A3C (2330-533-3380)
SEMITRAILER, TANK: GASOLINE, 12-TON, 4-WHEEL
M131 (2330-835-8565)
M131A1 (2330-508-1484)
AND
M131A2 (2330-574-7964)**

This copy is a reprint which includes current pages from changes 1 and 2.

DEPARTMENTS OF THE ARMY AND THE AIR FORCE

FEBRUARY 1961

Change 1

CHANGES 2
No. 1

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON 25, D.C., 12 June 1962


SEMITRAILER, TANK: FUEL SERVICING,
5000 GALLON, 4-WHEEL, M131A3C
SEMITRAILER, TANK: GASOLINE, 12-TON, 4-WHEEL
M131, M131A1, and M131A2

TM 9-2330-208-24P, 17 FEBRUARY 1961 IS CHANGED AS FOLLOWS:
CHANGE THE TITLE TO READ AS SHOWN ABOVE:


		<u>Figure</u>	<u>Page</u>
	Visual Table of Contents V - Electrical System, M131A3C		ix
	Visual Table of Contents VI - Air-Hydraulic Brake Svstem,M131A3C		x
	Visual Table of Contents VII - Piping Installation, M131A3C		xi
Section I.	INTRODUCTION		
	PREFACE		92
	Maintenance Tools for Ordnance Personnel		92
	Vehicle Views		
	Semitrailer, Tank: Fuel Servicing, 4-wheel, M131A3C - Right		
	Rear View	72	93
	Semitrailer, Tank: Fuel Servicing, 4-wheel, M131A3C - Left		
	Front View.....	73	93
Section II.	Organizational and Field Maintenance Repair Parts		
	Electrical System		
	Wiring Harness, Connectors, and Receptacles (M131A3C) ...	74	94
	Clearance Lights (M131A3C)	75	95
	Taillight Assembly.....	76	96
	Taillight Assembly.....	77	97
	Axle and Air-Hydraulic Brakes (M131A3C)		
	Axle and Service Brake	78	98
	Service Brake	79	100
	Brake Spider with Gear Assembly	80	102
	Hub and Drum Assembly.....	81	103
	Air-Hydraulic Lines, Couplings, Fittings, and valves (M131A3C).....	82	104
	Hydraulic Brake Wheel Cylinder Assembly	83	105
	Hydraulic Brake Master Cylinder	84	106
	Air Chamber.....	85	107
	Air Filter.....	86	108
	Air Hose Coupling.....	87	109
	Emergency Relay Valve Assembly.....	88	110
	Wheels		
	Wheel, Tire and Tube	89	111
	Landing Gear		
	Landing Gear Assembly	90	112
	Landing Gear Leg	91	114
	Left Landing Gear Leg Gear Box.....	92	115
	Right Landing Gear Leg Gear Box	93	116
	Suspension		
	Spring Seat and Bearings.....	94	117
	Spring Assembly.....	95	118
	Torque Rods and Brackets	96	119

	<u>Figure</u>	<u>Page</u>
Section II.	Organizational and Field Maintenance Repair Parts (continued)	
	Gasoline Tank (M131A3C)	
	Piping Assembly	97 120
	Centrifugal Dispensing Pump	98 122
	Emergency Relief Valve.....	99 123
	Emergency Valve Control	100 123
	Manifold and Coupling	101 124
	Gate Valve (Flange and Pipe Stud)	102 124
	Gate Valve (Coupling Stud)	103 125
	Sediment Strainer	104 125
	Manhole Cover, Filler Cover, and Vapor Relief Valve	105 126
	3-Inch Adjustable By-Pass Valve Assembly	106 127
	Fuel and Oil Servicing Nozzle.....	107 127
	3-Inch 4-Way Valve Assembly	108 128
	3-Inch Flow Control Valve.....	109 128
	Hose Reel Assembly	110 129
	Segregator Installation.....	111 130
	Segregator First and Second Stage Element and Plate Assemblies.....	112 131
	Segregator Control and Drain Valve Assembly	113 132
	Miscellaneous Accessories (M131A3C)	
	Data Plates	114 133
	Reflector (Non-Illustrated).....	133
	Auxiliary Engine (M131A3C)	
	Auxiliary Engine	115 134
	Auxiliary Engine Accessories.....	116 135
	Auxiliary Engine Model ACK-S/381D (Variations)	117 136
	Auxiliary Engine Parts (Non-Illustrated).....	
Section III.	Organizational Tools and Equipment	
	Vehicle Tool Kits	
	Organizational Tools	118 143
Section IV.	Indexes	
	Alphabetical Index.....	144
	Federal Stock Number Index	147

ELECTRICAL SYSTEM-M131A3C
VISUAL TABLE OF CONTENTS-V



VISUAL TABLE OF CONTENTS-VI



AIR-HYDRAULIC BRAKE SYSTEM - M131A3C
VISUAL TABLE OF CONTENTS-VI

ORD E36521