TECHNICAL MANUAL

ORGANIZATIONAL, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

FOR

CLOTHING REPAIR SHOP, TRAILER MOUNTED
MODEL: CRS
NSN: 3530-01-133-3494

This copy is a reprint which includes current pages from Changes 1 through 3.

HEADQUARTERS, DEPARTMENT OF THE ARMY
30 JANUARY 1986

TECHNICAL MANUAL

NO. 10-3530-205-24P

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, D.C. 30 January 1986

Organizational, Direct Support and General Support Maintenance Repair Parts and Special Tools List For CLOTHING REPAIR SHOP, TRAILER MOUNTED MODEL: CRS NSN 3530-01-133-3494 Current as of 29 September 1985

REPORTING OF ERRORS AND RECOMMENDING IMPROVEMENTS.

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms) or DA Form 2028-2 located in the back of this manual direct to: Commander, U.S. Army Troop Support Command, ATTN: AMSTR-MCTS, 4300 Goodfellow Blvd., St. Louis, MO 63120-1798. A reply will be furnished to you.

TABLE OF CONTENTS

		Page	Illus. Figure
Section I	INTRODUCTION	1	
Section II	REPAIR PARTS LIST	1-1	
Group 00	Clothing Repair Shop, Trailer Mounted	1-1	
Group 01	Cabinet Assembly	1-1	1
	Lifting Eye Assembly	2-1	2
	Rear Door Assembly	3-1	3
	Side Door Assembly	4-1	4
Group 02	Storage Box Assembly	5-1	5
	Needles, Bobbin and Belting	6-1	6
	Winder, Unwinder, Oil Can and Shears	7-1	7
	Presses, Chucks, Dies and Lights	8-1	8
	Power Cable	9-1	9
Group 03	Table Top, Darning Machine	10-1	10
Group 04	Table Top, Button Sewing Machine	11-1	11
Group 05	Table Top, Clothing Machine	12-1	12
Group 06	Folding Table Assembly	13-1	13
Group 07	Tray Assembly, Clothing, Darning and Button	14-1	14
Group 08	Clothing Machine External Parts	15-1	15
	Lubrication System	16-1	16
	Tension and Feed Mechanism	17-1	17
	Pulley, Shaft, and Needle Bar	18-1	18
	Presser Foot and Bobbin Mechanism	19-1	19
Group 09	Darning Machine Top Arm	20-1	20
	Darning Machine Head Top Arm Shaft and Housing	21-1	21
	Darning Machine Middle and Bottom Base	22-1	22
	Darning Machine Hook Assembly	23-1	23

TABLE OF CONTENTS (Cont)

		Page	Illus. Figure
Group 10	Button Machine Head Assembly	24-1	24
	Needle Bar Drive Assembly	25-1	25
	Clamp Lift and Thread Slack Mechanism	26-1	26
	Stopping Mechanism Assembly	27-1	27
Group 11	Stand Assembly	28-1	28
	Pulley Assembly, Manual	29-1	29
Group 12	Stand and Chair Holddown Assembly	30-1	30
Group 13	Track Assembly, Generator	31-1	31
Group 14	Fire Extinguisher	32-1	32
Group 15	Holddown Clamp Assembly	33-1	33
Section III	SPECIAL TOOLS LIST (Not applicable)		
Section IV	NATIONAL STOCK NUMBER, PART NUMBER INDEX	I-1	

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

Section I. INTRODUCTION

1. SCOPE. This RPSTL lists and authorizes spares and repair parts; special test, measurement, and diagnostic equipment CMDE); and other special support equipment required for performance of organizational, direct support, and general support maintenance of the Clothing Repair Shop. It authorizes the requisitioning, issue, and disposition of spares, repair parts and special tools as indicated by the source, maintenance and recoverability (SMR) codes.

2. GENERAL. In addition to this section, Introduction, this Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence. Bulk materials are listed in item name sequence. Repair parts kits are listed separately in their own functional group within Section II. Repair parts for repairable special tools are also listed in this section. Items listed are shown on the associated illustration(s)/figure(s).

b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in DESCRIPTION AND USABLE ON CODE column) for the performance of maintenance.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbered items appearing in the listing, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. EXPLANATION OF COLUMNS (SECTIONS II AND III).

a. ITEM NO. (Column (1)). Indicates the number used to identify items called out in the illustration.

b. SMR Code (Column (2)). The Source, Maintenance, and Recoverability (SMR) code is a 5position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instruction, as shown in the following breakout: