

TM 55-1730-224-13&P

**TECHNICAL MANUAL
OPERATOR'S, AVIATION UNIT,
AND INTERMEDIATE MAINTENANCE MANUAL
INCLUDING
REPAIR PARTS AND SPECIAL TOOLS LIST**

for

**TRAILER,
AIRCRAFT MAINTENANCE,
AIRMOBILE
PART NUMBER
22142**

NSN 1730-00-435-7818

This copy is a reprint which includes current
pages from Changes 1 through 3.

**HEADQUARTERS, DEPARTMENT OF THE ARMY
15 SEPTEMBER 1982**

TECHNICAL MANUAL

No. 55-1730-224-13&P

Headquarters
Department of the Army
Washington, D.C., 15 September 1982

OPERATOR'S, AVIATION UNIT,
AND INTERMEDIATE MAINTENANCE MANUAL

INCLUDING

REPAIR PARTS AND SPECIAL TOOLS LIST

for

TRAILER, AIRCRAFT MAINTENANCE, AIRMOBILE
PART NUMBER 22142
NSN 1730-00-435-7818

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to Commander, US Army Aviation and Troop Command, ATTN: AMSAT-I-MP, 4300 Goodfellow Blvd., St. Louis, MO 63120-1798. A reply will be furnished directly to you.

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited.

TABLE OF CONTENTS

	Page
CHAPTER 1. INTRODUCTION	
Section I. General Information	1-1
Section II. Equipment Description and Data	1-2
Section III. Principle of Operation	1-4
CHAPTER 2. OPERATION INSTRUCTIONS	
Section I. Description and Use of Operator's Controls	2-1
Section II. Preventive Maintenance checks and Services	2-3
Section III. Operation Under Usual Conditions	2-3
CHAPTER 3. MAINTENANCE INSTRUCTIONS (AVUM AND AVIM)	
Section I. Repair Parts, Special Tools, TMDE and Support Equipment	3-1
Section II. Service Upon Receipt	3-1
Section III. Preventive Maintenance Checks and Services	3-13
Section IV. Troubleshooting	3-15
Section V. Maintenance Procedures	3-16

TABLE OF CONTENTS (cont)

APPENDIX		Page
APPENDIX A	REFERENCES	A-1
APPENDIX B	MAINTENANCE ALLOCATION CHART	B-1
APPENDIX C	REPAIR PARTS AND SPECIAL TOOLS LIST	C-1
ALPHABETICAL INDEX		Index 1

LIST OF TABLES

Number	Title	Page
1-1	Leading Particulars	1-2
2-1	Operator's Controls	2-1
2-2	Operator/Crew Preventive Maintenance Checks and Services	2-3
3-1	Service Upon Receipt	3-1
3-2	Preliminary Servicing of Equipment	3-10
3-3	AVUM PMCS	3-13
3-4	Troubleshooting Procedures	3-15
3-5	Trailer Assemblies	3-16
3-6	Towbar Maintenance Checklist	3-17
3-7	Front Axle and Steering Assembly Maintenance	3-21
3-8	Brake Maintenance Checklist	3-24
3-9	Rear Axle Maintenance Checklist	3-25
3-10	Wheel Assembly Maintenance Checklist	3-27
3-11	Rail Assembly Maintenance Checklist	3-28
3-12	Pallet and Bolster Maintenance Checklist	3-30

LIST OF ILLUSTRATIONS

Number	Title	Page
1-1	Trailer, Aircraft Maintenance, Airmobile	1-1
1-2	Major Components	1-3
2-1	Operator's Controls	2-2
3-1	Assemblies for Maintenance	3-16
3-2	Wiring Diagram	3-31

CHAPTER 1

INTRODUCTION

Section I - General Information

1-1. SCOPE.

a. Type of Manual: Operator's, Aviation Unit and Intermediate Maintenance.

b. Model Number and Equipment Name: Part Number 22142 Trailer, Aircraft Maintenance Airmobile. Refer to figure 1-1.




Figure 1-1. Trailer, Aircraft Maintenance, Airmobile

c. Purpose of Equipment: Transports materiel during aircraft maintenance.

1-2. MAINTENANCE FORMS, RECORDS, AND REPORTS. Department of the Army forms and procedures used for equipment maintenance will be those prescribed by DA PAM 738-751, The Functional Users Manual for Army Maintenance Management System Aviation (TAMMS-A).