

TUG, HARBOR, DIESEL, 1200 H. P. STEEL, 100 FT DESIGN 3006
(HULL NUMBERS LT 1936 THRU LT 1977 AND LT 2202)

Reference: FEDERAL SUPPLY CATALOG C9100-IL and LO55-1925-204-12-2, 3, 4, 5, 6, 7, 8, TM55-1925-204-12 and TM55-1925-204-34

Intervals are based on normal hours of operations. Adjust to compensate for abnormal operations and severe conditions. During inactive periods, sufficient lubrication must be performed for adequate preservation.

Clean fitting before lubricating.

Relubricate after exposure to salt water.

Clean parts with SOLVENT, Dry-cleaning, Type II, (SD-2). Dry before lubricating.

Lubricate points indicated by dotted arrow, on both sides of equipment.

Drain crank and gearcases when hot. Fill and check level.

*The time specified is the time required to perform all services of the prescribed interval.

*TOTAL MAN-HR		*TOTAL MAN-HR	
INTERVAL	MAN-HR	INTERVAL	MAN-HR
10	5.6	600	4.5
50	13.6	1200	12.4
200	16.1	2400	11.0

FOLD

FOLD

LUBRICANT ● INTERVAL

INTERVAL ● LUBRICANT

