

**UNIT AND DIRECT SUPPORT
MAINTENANCE REPAIR PARTS AND
SPECIAL TOOLS LIST
FOR
300K WATER STORAGE
AND
DISTRIBUTION SYSTEM
MODEL WSDS310
NSN: 4610-01-360-1582**

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited.

HEADQUARTERS, DEPARTMENT OF THE ARMY

1 SEPTEMBER 1993

TECHNICAL MANUAL

NO. 10-4610-242-23P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 1 September 1993Unit and Direct Support Maintenance
Repair Parts and Special Tools List
for**300K WATER STORAGE****AND****DISTRIBUTION SYSTEM****MODEL WSDS310 (NSN 4610-01-360-1582)****Current as of 31 July 1993****REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS**

You can help improve this manual. If you find any mistakes, or if you know of a way to improve these procedures, please let us know. Mail your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual directly to: Commander, US Army Aviation and Troop Command, ATTN: AMSAT-I-MP, 4300 Goodfellow Blvd., St. Louis, MO 63120-1798. You may also submit your recommended changes by E-mail directly to <mpmt%oavma28@st-louis-emh7.army.mil>. A reply will be furnished directly to you. Instructions for sending an electronic 2028 may be found at the back of this manual immediately preceding the hard copy 2028.

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

TABLE OF CONTENTS

		PAGE	ILLUS/ FIGURE
Section I.	Introduction	1	
Section II.	Repair Parts List	1-1	
Group 01	Bag Filler Connection Kits		
	Bag Filler/Hose and Nozzle Connection Kits.....	1-1	1
	Hose Assembly, Discharge, Potable Water, 1-1/2 Inch	2-1	2
	Gate Valve Assembly, 2 inch.....	3-1	3
	Hose Assembly, Discharge, Potable Water, 2 Inch.....	4-1	4
	Tee Assembly, 4 Inch	5-1	5
	Hose Assembly, Discharge, Potable Water, 4 Inch.....	6-1	6
	Hose and Nozzle Kit.....	7-1	7
	Nozzle Assembly, 1 Inch	8-1	8
	Hose Assembly, Discharge, Potable Water, 1 Inch.....	9-1	9
	Regulator Assembly, Potable Water	10-1	10
	Stand Assembly, Nozzle.....	11-1	11
Group 02	Hose Nozzle Connection Kit		
	Hose Nozzle Connection Kit, Potable Water	12-1	12
	Nozzle Assembly, 1-1/2 Inch	13-1	13

TABLE OF CONTENTS - continued

	PAGE	ILLUS/ FIGURE
Hose Assembly, Discharge, Potable Water, 1-1/2 Inch	14-1	14
Hose Assembly, Discharge, Potable Water, 2 Inch.....	15-1	15
Gate Valve, 2 Inch	16-1	16
Tee Assembly, 4 Inch	17-1	17
Hose Assembly, Discharge, Potable Water, 4 Inch.....	18-1	18
Stand Assembly, Nozzle.....	19-1	19
Group 03 2-Inch Hose Connection Kit		
Hose Connection Kit, Potable Water	20-1	20
Hose Assembly, Discharge, Potable Water, 2 Inch.....	21-1	21
Gate Valve Assembly, 2 Inch	22-1	22
Tee Assembly, 4 Inch	23-1	23
Hose Assembly, Discharge, Potable Water, 4 Inch.....	24-1	24
Stand Assembly, Nozzle.....	25-1	25
Group 04 Hose Connection Kit, 4-Inch		
Hose Connection Kit, Potable Water, 4 Inch	26-1	26
Butterfly Valve Assembly, 4 Inch	27-1	27
Hose Assembly, Discharge, Potable Water, 4 Inch.....	28-1	28
Quick Acting Valve Assembly, 4 Inch	29-1	29
Tee Assembly, 4 Inch	30-1	30
Stand Nozzle	31-1	31
Group 05 Hypochlorination Unit		
Hypochlorination Unit.....	32-1	32
Group 06 350 GPM Pump Connection Kit		
350 GPM Pump Connection Kit.....	33-1	33
Tee Assembly, 4 Inch	34-1	34
Hose Assembly, Suction, Potable Water, 4 Inch.....	35-1	35
Tee Assembly, 4 Inch	36-1	36
Gate Valve Assembly, 4 Inch	37-1	37
Hose Assembly, Discharge, Potable Water, 4 Inch.....	38-1	38
Tee Assembly, 4 Inch	39-1	39
Water Meter Assembly, Fluid Flow Indicating	40-1	40
Tee Assembly, 4 Inch	41-1	41
Group 07 Pumping Assembly, 350 GPM		
Pumping Assembly, 350 GPM.....	42-1	42
Group 08 125 GPM Pump Connection Kit		
125 GPM Pump Connection Kit.....	43-1	43
Hose Assembly, Discharge, Potable Water, 2 Inch.....	44-1	44
Gate Valve Assembly, 2 Inch	45-1	45
Check Valve Assembly, 2 Inch	46-1	46
Hose Assembly, Suction, Potable Water, 2 Inch.....	47-1	47
Group 09 Pumping Assembly, 125 GPM		
Pumping Assembly, 125 GPM.....	48-1	48
Group 10 Dual Tank Connection Kit		
Dual Tank Connection Kit.....	49-1	49
Hose Assembly, Discharge, Potable Water, 4 Inch.....	50-1	50
Hose Assembly, Discharge, Potable Water, 4 Inch.....	51-1	51
Gate Valve Assembly, 4 Inch	52-1	52
Hose Assembly, Suction, Potable Water, 4 Inch.....	53-1	53
Hose Assembly, Suction, Potable Water, 4 Inch.....	54-1	54
Gate Valve Assembly, 4 Inch	55-1	55

TABLE OF CONTENTS - continued

		PAGE	ILLUS/ FIGURE
	Gate Valve Assembly, 4 Inch	56-1	56
	Gate Valve Assembly, 4 Inch	57-1	57
Group 11	Interconnection Kit, 4-Inch Discharge		
	Discharge Hose Interconnection Kit, 4 Inch	58-1	58
	Tee Assembly, 4 Inch	59-1	59
	Hose Assembly, Discharge, Potable Water, 4 Inch.....	60-1	60
	Tee Assembly, 4 Inch	61-1	61
Group 12	Tank, Fabric, Collapsible, 50, 000 Gallon		
	Collapsible Fabric Tank, 50K Gallon	62-1	62
Group 13	Accessory Kit		
	Accessory Kit.....	63-1	63
Group 14	Water Tank Chest		
	Water Tank Chest	64-1	64
Group 15	Triple Container		
	Triple Container	65-1	65
Group 16	Miscellaneous Government Furnished Items		
	Miscellaneous Government Furnished Items	66-1	66
Group 17	Bulk Material List	Bulk-1	
Section III.	Special Tools List (Not Applicable)		
Section IV.	Cross Reference Index		
	National Stock Number Index.....	I-1	
	Part Number Index	I-7	
	Figure and Item Number Index.....	I-29	

iii/(iv blank)

UNIT AND DIRECT SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

Section I. INTRODUCTION

1. SCOPE. This RPSTL lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of unit and direct support maintenance of the 300K Water Storage and Distribution System, Model WSDS31 0. It authorizes the requisitioning, issue, and disposition of spares, repair parts and special tools as indicated by the source, maintenance and recoverability (SMR) codes.

2. GENERAL. In addition to this section, Introduction, this Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. This list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence. Bulk materials are listed in item name sequence. Items are shown in the associated illustration(s)/figure(s).


b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in DESCRIPTION AND USABLE ON CODE column) for the performance of maintenance.

c. Section IV. Cross-Reference Index. A list, in National Item Identification Number (NIIN) sequence, of all National stock numbered items appearing in the listing, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross referenced to each illustration figure and item number appearance. The figure and item number index lists figure and item numbers in alphanumeric sequence and cross references NSN, CAGEC and part number.

3. EXPLANATION OF COLUMNS (SECTIONS II AND III).

a. ITEM NO. (Column (1)). Indicates the number used to identify items called out in the illustration.

b. SMR Code (Column (2)). The Source, Maintenance, and Recoverability (SMR) code is a 5-position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instruction, as shown in the following breakout:



* Complete Repair: Maintenance capacity, capability, and authority to perform all corrective maintenance tasks of the "Repair" function in a use/user environment in order to restore serviceability to a failed item.