TECHNICAL MANUAL

UNIT AND DIRECT SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST FOR

HYPOCHLORINATION UNIT 350 GPM MODEL WAL001 HYPO NSN 4610-01-410-7179

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited.

HEADQUARTERS, DEPARTMENT OF THE ARMY
20 FEBRUARY 1997

TECHNICAL MANUAL

NO.10-4610-246-23P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 20 February 1997

Unit and Direct Support Maintenance
Repair Parts and Special Tools List
For

HYPOCHLORINATION UNIT
350 GPM
MODEL WAL001 HYPO
NSN 4610-01-410-7179

Current as of 1 October 1996

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes, or if you know of a way to improve these procedures, please let us know. Mail your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual directly to: Commander, US Army Aviation and Troop Command, ATTN: AMSAT-I-MP, 4300 Goodfellow Blvd., St. Louis, MO 63120-1798. You may also submit your recommended changes by E-mail directly to <mpmt/oavma28@st-louis-emh7.army.mil>. A reply will be furnished directly to you. Instructions for sending an electronic 2028 may be found at the back of this manual immediately preceding the hard copy 2028.

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

TABLE OF CONTENTS

		PAGE	ILLUS/ FIGURE
Section I	Introduction	1	
Section II	Repair Part		
Group 00	Hypochlorination Unit, 350 GPM		
Group 01	Inlet Pipe Assembly	1-1	1
Group 02	Outlet Pipe Assembly	2-1	2
Group 03	Manifold Assembly	3-1	3
Group 04	Reservoir Tank Assembly	4-1	4
Group 05	Ratio-Feeder Assembly	5-1	5
	Pumper Assembly	6-1	6
	Upper and Lower Main Case Assembly	7-1	7
	Measuring Chamber	8-1	8
Group 06	Tool Box Assembly	9-1	9
Group 07	Cover Assembly	10-1	10
Group 08	Frame Assembly	11-1	11
Group 09	Color Comparator	12-1	12
Group 10	Accessory Items	13-1	13
Group 11	Bulk Materials List	14-1	
Section III	Special Tools List - Not Applicable		
Section IV	Cross Reference List	I-1	
	National Stock Number Index	I-1	
	Part Number Index	I-2	

UNIT AND DIRECT SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LIST

Section I. INTRODUCTION

1. SCOPE. This RPSTL lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of unit and direct support maintenance of the Hypochlorination Unit, 350 GPM, model WAL001 HYPO. It authorizes the requisitioning, issue, and disposition of spares, repair parts and special tools as indicated by the source, maintenance and recoverability (SMR) codes.

2. GENERAL. In addition to this section, Introduction, this Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. This list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence. Bulk materials are listed by item name sequence. Items are shown in the associated illustration(s)/figure(s).

b. Section III. Special Tools List. A list of special tools, sped al TMDE, and other special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in DESCRIPTION AND USABLE ON CODE column) for the performance of maintenance.

c. Section IV. Cross-Reference Index. A list, in National Item Identification Number (NIIN) sequence, of all National stock numbered items appearing in the listing, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross referenced to each illustration figure and item number appearance.

3. EXPLANATION OF COLUMNS (SECTIONS II AND III).

a. ITEM NO. (Column (1)). Indicates the number used to identify items called out in the illustration.

b. SMR Code (Column (2)). The Source Maintenance, and Recoverability (SMR) code is a5-position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instruction, as shown in the following breakout:



* Complete Repair Maintenance capacity, capability, and authority to perform all corrective maintenance tasks of the "Repair" function in a use/user environment in order to restore serviceability to a failed item.