
TECHNICAL MANUAL

ORGANIZATIONAL MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS LISTS

WATER PURIFICATION UNIT, VAN-TYPE, BODY MOUNTED
ELECTRIC DRIVEN, AC, 115/208 V, SINGLE AND 3 PHASE,
60 HERTZ, 1/20 to 2 HP, 1500 GPH
MODEL EMC-1500S
NSN 4610-01-037-8746

**ORGANIZATIONAL MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS LISTS**
**WATER PURIFICATION UNIT, VAN-TYPE, BODY MOUNTED,
ELECTRIC DRIVEN, AC, 115/208V, SINGLE AND 3 PHASE
60 HERTZ, 1/20 TO 2 HP, 1500 GPH
MODEL EMC-1500S
NSN 4610-01-037-8746**

Current as of 25 February 1980

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistake or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, U.S. Army Troop Support Command, ATTN: AMSTR-MCTS, 4300 Goodfellow Boulevard, St. Louis, MO 63120-1798. A reply will be furnished directly to you.

Table of Contents

	Page	Illus Figure
Section I. INTRODUCTION	1	
II. REPAIR PARTS LIST	7	
Group 01 Electrical system	7	
Clearance Lights	6	1
Clearance Light Installation	8	2
Ceiling Light Fixture	10	3
Group 02 Frame	13	
Ladder Assemblies	12	5
Group 03 Landing Gear	15	
Leveling Jack, Storage Rack	14	6
Lifting Kit	16	7
Group 04 Body, Van Type and Accessories	21	
Storage Box and Frame	20	8
Van Body	22	9
Right Van Body	24	11
Left Van Body	26	12
Front Van Body	28	13
Rear Van Body	30	14

	Page	Illus Figure
Right Side Door.....	32	15
Left Side Door.....	34	16
Counterbalance Assembly.....	36	17
Rear Door.....	38	18
Bonnet Doors.....	40	19
Door Latch.....	42	20
Door Latch Left Side.....	44	21
Blackout Door and Window Stationary.....	46	22
Blackout Door and Window Ventilating.....	48	23
Roof Hatch.....	50	24
Reflector, Level, Cable Cover.....	52	25
Heater.....	54	26
Heater Exhaust Pipe.....	56	27
Fuel Pump and Attaching Parts.....	58	28
Fuel Lines and Fittings.....	60	29
Heater Duct.....	62	30
Data Plates.....	64	31
Group 05 Electric Motors.....	67	
Erdlator Agitator Drive Motor and Related Parts.....	66	32
Slurry Feeder Drive Motor and Related Parts.....	68	33
Chemical Solution Feeder Motor and Related Parts.....	70	34
Erdlator Motor Disassembly.....	72	35
Slurry Feeder Motor Disassembly.....	74	36
Erdlator Agitator Motor Base.....	76	37
Erdlator Bridge Rail Assembly and Speed Reducer Mounting Plate.....	78	38
Erdlator Speed Reducer Mounting Plate.....	80	39
Erdlator Agitator Speed Reducer and Related Parts.....	82	41
Erdlator Gear Assembly.....	84	42
Erdlator Agitator Drive Shaft, Pulley, Bearings and Attaching Parts.....	86	43
Slurry Feed Speed Reducer.....	88	45
Slurry Feeder Chain and Motor Guard.....	90	46
Slurry Feeder Chain, Chain Tightener and Slip Clutch.....	92	47
Slurry Feeder Drive Gear.....	94	48
Chemical Solution Feeder Gear Unit Assembly.....	96	49
Chemical Solution Feeder Gear Unit.....	98	50
Electrical Control Cabinet Assembly.....	100	51
Internal Electrical Wiring.....	102	52
Door Sensitive Switch.....	106	53
Low Water Level Sensitive Switch.....	108	54
Terminal Board Assembly.....	110	55
Receptacles.....	112	56
Group 06 Electrical Equipment.....		
Low Water Level Warning Light.....	116	57
Low Water Level Alarm Buzzer.....	118	58
Group 07 Gages (Non-Electrical Weighing and Measuring Devices).....	121	
Filter Gage.....	120	59
Flow Controller.....	122	61

	Page	Illus Figure
Group 08 Water Purification Unit	125	
Chemical Feed Equipment Frame and Related Parts	124	62
Chemical Solution Feeder	126	63
Chemical Solution Feeder Diaphragm Pump	128	64
Chemical Solution Feeder Lever Arms..	130	65
Chemical Solution Feeder Junction Box, Cover Receptacle, Top Housing, and Lever Arm Shaft...	132	66
Slurry Feeder Housing	134	67
Slurry Feeder Agitators	136	68
Slurry Feeder Shaft..	138	69
Erdlator Tank and Related Parts	140	70
Influent Launder and Chemical Solution Tank	142	71
Dilution Tank Assembly	144	72
Waste Tank, Grating, and Mounting Hardware.	146	73
Raw Water Piping Between Inlet Hose and Top of Erdlator. . . .	148	74
Raw Water Sight Glass	150	75
Raw Water Float Valve By-Pass Piping...	152	76
Raw Water Chemical Lines, Right Side Slurry Feeder...	154	77
Aspirator Manifold Assembly	156	78
Coagulated Water Piping Between Erdlator Weir Box and Sludge Concentrator	158	79
Coagulated Water Piping From Wet Well to Filter Pump	160	80
Coagulated Water Piping From Filter Pump to Filter	162	81
Coagulated Water Piping From Filter Plug Valve to Wet Well .	164	82
Waste Water Piping Wet Well-Erdlator	166	83
Waster Water Piping Erdlator Tank and Outlet...	168	84
Waste Water Piping Between Waste Tank, Sludge Concentrator Tank, and Outlet in Van Body	170	85
Filtered Water Piping From Filter to Plug	172	86
Filtered Water Piping From Plug Valve to Outlet	174	87
Filtered Water Piping to Slurry Feeder	176	88
Filter Gage Lines and Fittings	178	89
Dilution Tank Piping to Erdlator Tank	180	90
Chemical Lines, Slurry Feeder and Chemical Solution Feeder.	182	91
Low Water Level Alarm Float and Linkage	184	92
Sludge Concentrator Valve and Piping	186	93
Float Valve	188	94
Valve Assembly Influent	190	95
Valve Assembly Effluent	192	96
Support Pipe Adjustment..	194	97
Group 09 Pumps	197	
Filter Pump Motor Base	196	98
Filter Pump Assembly and Mounting Hardware.	198	99
Filter Pump	200	100
Group 10 Filters, Separators, Purifiers	203	
Upper Filter Housing	202	101
Lower Filter Housing.....	204	102
Air Release Valve Assembly and Mounting Hardware	206	103
Air Release Valve Three-way Valve	208	104
Filter Element Assembly	210	106

	Page	Illus Figure
Section III. SPECIAL TOOLS LIST (Not applicable)		
IV. NATIONAL STOCK NUMBER AND REFERENCE NUMBER INDEX	213	

Section I. INTRODUCTION

1. Scope. This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational maintenance of the water purification unit. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General. This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized for the performance of maintenance. (Not applicable.)

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list in alphameric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance. This index is followed by a cross-reference list of reference designators to figure and item numbers.

3. Explanation of Columns.

a. Illustration. This column is divided as follows:

(1) Figure Number. Indicates the figure number of the illustration on which the item is shown.

(2) Item Number. The number used to identify item called out in the illustration.

b. Source, Maintenance and Recoverability (SMR) Codes.

(1) Source Code. Source codes indicate the manner of acquiring support items for maintenance, repair or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	Definition
PA	Item procured and stocked for anticipated or known usage.
PB	Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply system.
PC	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
PD	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF	Support equipment which will not be stocked but which will be centrally procured on demand.
PG	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which, because of probable discontinuance or shutdown of production facilities, would prove uneconomical to reproduce at a later time.
KD	An item of a depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
KF	An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or intermediate levels of maintenance.
KB	Item included in both a depot overhaul/repair kit and a maintenance kit.
MO	Item to be manufactured or fabricated at the organizational level.
MF	Item to be manufactured or fabricated at the direct support maintenance level.