

TECHNICAL MANUAL

**ORGANIZATIONAL MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS LIST**

**WATER PURIFICATION UNIT: VAN-TYPE BODY MOUNTED;
ELECTRIC DRIVEN, AC, 115, 208V
SINGLE- AND 3-PHASE, 60 HERTZ
1/2 TO 2 HP, 1500 GPH
(MET-PRO MODEL 1500-2600A)
NSN 4610-00-879-4612
(ETC MODEL S1500)
NSN 4610-01-016-9964**

This copy is a reprint which includes current pages from Change 1

This manual supersedes TM 5-4610-221-20P, 3 March 1971, including all changes.

**HEADQUARTERS, DEPARTMENT OF THE ARMY
3 MAY 1982**

TECHNICAL MANUAL

NO. 5-4610-221-20P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 3 May 1982

ORGANIZATIONAL MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS LIST

WATER PURIFICATION UNIT; VAN-TYPE BODY MOUNTED
ELECTRIC DRIVEN, AC, 115, 208V, SINGLE- AND 3-PHASE
60 HERTZ 1/20 TO 2 HP, 1500 GPH
(MET-PRO MODEL 1500-2600A)
NSN 4610-00-8794612
(ETC MODEL S1500)
NSN 4610-01-016-9964

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistake or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, US Army Troop Support and Aviation Materiel Readiness Command, ATTN: DRSTS-MPSD, 4300 Goodfellow Blvd., St. Louis, MO 63120. A reply will be furnished directly to you.

CURRENT AS OF 1 DECEMBER 1981

TABLE OF CONTENTS

	Page	Illus Figure
Section I. INTRODUCTION.....	1	
II. REPAIR PARTS LIST	7	
Group 01. Fuel System		
Personnel Heater Fuel Lines to Pump	7	1
Fuel Pump.....	9	2
Personnel Heater Fuel Lines to Heater	11	3
02. Electrical System		
Clearance and Blackout Lights	13	4
Ceiling Light Fixture	15	5
External Cable Connectors.....	17	6
Electric Cables, Personnel Heater and Fuel Pump	19	7
Electrical Cables	21	8
03. Frame		
Ladders and Laveling Jack	23	9
Storage Box and Mounting Frame	25	10
04. Body and Door Compartments		
Jack Storage Rack	27	11
Door Assembly, Window and Blackout Panel	29	12
Stationary Window and Blackout Panel	31	13
Door Latch and Ladder Mounting	33	14
Door Latch Assembly.....	35	15
Door Counterbalance Assembly	37	16
Left Side Doors	39	17

TABLE OF CONTENTS (CON'T)

	Page	Illus Figure
05. Body Attaching Parts		
Personnel Heater.....	41	20
Personnel Heater Exhaust	43	21
Red and Amber Reflectors	45	22
06. Electric Motors		
Slurry Feeder Drive Motor	47	23
Erdlator Bridge and Motor Mounting Base	49	24
Erdlator Agitator Drive Motor	51	25
07. Electric Equipment, Transformer and Distributor		
Electrical Control Cabinet, Starter, Transformer and Fuses	53	26
Electrical Control Cabinet, Terminals, Circuit Breaker and Push Switches.....	55	27
Low Water Level Alarm	57	28
Float Valve	29	29
Water Level Alarm Switch	61	30
Indicator Light.....	63	31
Electrical Cables	65	32
08. Gages (Non-Electrical) Weighing-Measuring Devices		
Pressure Gages, Lines and Fittings	67	33
Filter Gages and Bracket.....	69	34
Flow Indicator, Raw Water.....	71	35
09. Water Purification Components		
Flow Control Valves Less Diaphragm Installation	73	36
Influent Valve Assembly	75	38
Filtered Water Piping, to Effluent Water Valve	77	39
Filtered Water Piping, to Recirculating Line	79	40
Filtered Water Piping, to Slurry Feeder	81	41
Coagulated Water, Upper Section Piping	83	42
Coagulated Water, Lower Section Piping to Pump	85	43
Coagulated Water, Lower Section Piping from Pump	87	44
Coagulated Water, Piping Support	89	45
Erdlator Coagulated Water Pipe	91	46
Effluent Valve Assembly	93	47
Filter Assembly	95	48
Filter Element Assembly	97	49
Filter Upper Housing	99	50
Filter Lower Housing.....	101	51
Filter Air Release Valve	103	52
Raw Water Piping to Flow Indicator	105	54
Raw Water Piping from Flow Indicator	107	55
Slurry Feeder Waste Water Piping	109	56
Diatomite Tank to Erdlator Tank Piping	111	57
Chemical Tubing Left Side of Slurry Feeder	113	58
Slurry Feeder Belt and Chain Guard	115	59
Chain Tightener Assembly	117	60
Slurry Feeder Gear Assembly	119	61
Slurry Feeder Gear Drive	121	62
Chemical Solution Feeder Mounting and Scales	123	63
Chemical Solution Feeder Assembly	125	64
Chemical Solution Feeder Gearbox, Controls and Connectors	127	65
Slip Clutch Assembly and Sprocket (MET-PRO Mode 1500-2600A)	129	68

TABLE OF CONTENTS (CON'T)

		Page	Illus Figure
Group 09.	Slip Clutch Assembly (ETC Model S1500)	131	69
(Con't)	Diatomite Dilution Tank	133	70
	Solution Tank	135	75
	Waste Water Tank	137	76
	Waste Water Piping from Filter	139	77
	Waste Water Piping to Waste Water Tank	141	78
	Erdlator Tank and Waste Water Piping from Outlet	143	79
	Erdlator Tank and Waste Water Piping to Tank	145	80
	Erdlator Raw Water Piping to Y Branch	147	81
	Erdlator Raw Water Piping from Y Branch	149	82
	Sludge Concentrator Waste Water Piping	151	83
	Sludge Concentrator Tank Valve	153	84
	Erdlator Agitator Speed Reducer	155	85
	Erdlator Agitator Drive Shaft	157	86
	Erdlator Tank.....	159	88
	Erdlator Tank Mounting	161	89
11.	Precision Leveling Devices		
	Van Body Level Assembly	163	92
12.	Special Purpose Kits		
	Front Vehicle Lifting Kit	165	93
	Rear Vehicle Lifting Kit.....	167	94
13.	Bulk Material	168	
Section III.	SPECIAL TOOLS LIST (Not Applicable)		
IV.	NATIONAL STOCK NUMBER AND PART NUMBER INDEX	169	

iii/(iv blank)

Section I. INTRODUCTION

1. Scope. This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational maintenance of the water purification unit. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General. This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized for the performance of maintenance. (Not Applicable).

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification Number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list in alphameric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance. This index is followed by a cross-reference list of reference designators to figure and item numbers.

3. Explanation of Columns.

a. Illustration. This column is divided as follows:

(1) Figure Number. Indicates the figure number of the illustration on which the item is shown.

(2) Item Number. The number used to identify item called out in the illustration.

b. Source, Maintenance and Recoverability (SMR) Codes.

(1) Source Code. Source codes indicate the manner of acquiring support items for maintenance,

repair or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	Definition
PA	Item procured and stocked for anticipated or known usage.
PB	Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply system.
PC	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
PD	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF	Support equipment which will not be stocked but which will be centrally procured on demand.
PG	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which, because of probable discontinuance or shutdown of production facilities, would prove uneconomical to reproduce at a later time.
KD	An item of a depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
KF	An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or intermediate levels of maintenance.
KB	Item included in both a depot overhaul/repair kit and a maintenance kit.