
TECHNICAL MANUAL

**ORGANIZATIONAL MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS LISTS
FOR
MULTIPLEXER TD 976/G (NSN 7025-01-048-9678)
AND
PULSE FORM RESTORER TD-982/G
(NSN 7025-01-061-1254)**

H E A D Q U A R T E R S , D E P A R T M E N T O F T H E A R M Y

21 JANUARY 1980

TECHNICAL MANUAL
NO. 11-7025-202-20P



HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC 21 January 1980

**ORGANIZATIONAL MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS LISTS
FOR
MULTIPLEXER TD-976/G (NSN 7025-01-048-9678)
AND PULSE FORM RESTORER TD-982/G (NSN 7025-01-061-1254)**

Current as of 6 September 1979

REPORTING ERRORS AND RECOMMENDED IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in back of this manual direct to Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, NJ 07703.

In either case, a reply will be furnished direct to you.

Table of Contents

			Ilus
			Page Figure
SECTION	I.	Introduction	1
	II.	Repair Parts List nor Multiplexer TD-976/G	5
GROUP	00	Multiplexer TD-976/G	5 1
	01	Remote Access Unit 21A15	7 2
		0101 Circuit Card Assembly, Remote Access Unit 21A15A1 (No Parts Authorized)	
	02	Card File Assembly 21A13	9 3
		0201 Backplane Assembly (No Parts Authorized)	
	03	Control Panel Assembly 21A14	11 4
	03	01 Circuit Card Assembly, Control Panel 21A14A1 (No Parts Authorized)	
	04	Power Supply Assembly 21A12	13 5
		0401 Circuit Card Assembly, Power Supply 21A12A1 (No Parts Authorized)	
	05	Circuit Card Assembly, Digital Data Orderwire Encoder 21A3 (No Parts Authorized)	
		0501 Connector Receptacle (No Parts Authorized)	
	06	Circuit Card Assembly, Alarm Detector 21A1 (No Parts Authorized)	
		0601 Connector Receptacle (No Parts Authorized)	
	07	Circuit Card Assembly, Group Traffic Monitor 21A2 (No Parts Authorized)	
		0701 Connector Receptacle (No Parts Authorized)	
	08	Circuit Card Assembly, Master Oscillator/Combiner 21A4 (No Parts Authorized)	
		0801 Connector Receptacle (No Parts Authorized)	
	09	Circuit Card Assembly, Timing and Control 21A5 (No Parts Authorized)	
		0901 Connector Receptacle (No Parts Authorized)	
	10	Circuit Card Assembly, Dual Group Processor 21A6 (No Parts Authorized)	
		1001 Connector Receptacle (No Parts Authorized)	
	11	Circuit Card Assembly, Frame Sync 21A7 (No Parts Authorized)	
		1101 Connector Receptacle (No Parts Authorized)	
	12	Circuit Card Assembly, Digital Data Orderwire Decoder 21A8 (No Parts Authorized)	
		1201 Connector Receptacle (No Parts Authorized)	
	13	Circuit Card Assembly, Super Group Driver/Receiver 21A9 (No Parts Authorized)	
		1301 Connector Receptacle (No Parts Authorized)	
	14	Circuit Card Assembly, Analog Voice Orderwire 21A10 (No Parts Authorized)	
		1401 Connector Receptacle (No Parts Authorized)	

Illus
Page Figure

GROUP	15	Circuit Card Assembly, Digital Voice Orderwire 21A11 (No Parts Authorized)	
		1501 Connector Receptacle (No Parts Authorized)	
	16	Cover Assembly, Card file (No Parts Authorized)	
	17	Case Assembly (No Parts Authorized)	
SECTION	III.	Special Tools List for Multiplexer TD-976/G (Not applicable)	
SECTION	IV.	National Stock Number and Part Number Index for Multiplexer TD 976/1G	14
	V.	Repair Pans List for Pulse Form Restorer TD-982/G	17
GROUP	00	Pulse Form Restorer TD-98VG	17
	01	Circuit Card Assembly (No Parts Authorized)	6
SECTION	VI.	Special Tools List for Pulse Form Restorer TD-982/G	
GROUP	30	Special Tools for Pulse Form Restorer TD-982/G	19
SECTION	VII.	National Stock Number and Pan Number Index for Pulse Form Restorer TD-982/G	20

SECTION I INTRODUCTION

1. Scope

This manual lists spares and repair special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational maintenance of the TD-976/G and TD-982/G. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections

a. *Section II. Repair Parts List for Multiplexer TD-9761G and Section I'. Repair Parts List for Pulse Form Restorer TD-982/G.* A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. *Section III. Special Tools List for Multiplexer TD-976/G (Not applicable) and Section VI. Special Tools List for Pulse Form Restorer TD-982/G.* A list of special tools, special TMDE, and other special support equipment authorized for the performance of maintenance.

c. *Section IV. National Stock Number and Part Number Index for Multiplexer TD-976/G and Section VII. National Stock Number and Part Number Index for Pulse Form Restorer TD-982/G.* A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphanumeric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. *Illustration.* This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* The number used to identify item called out in the illustration.

b. *Source, Maintenance, and Recoverability (SMR) Codes.*

(1) *Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	Definition
PA	—Item procured and stocked for anticipated or known usage.
PE	—Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
XD-A	—Support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code	Application/Explanation
O	—Support item is removed, replaced, used at the organizational level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code	Application/Explanation
F	—The lowest maintenance level capable of complete repair of the support item is the direct support level.
H	—The lowest maintenance level capable of complete repair of the support item is the general support level.
D	—The lowest maintenance level capable of complete repair of the support item is the depot level.
Z	—Nonreparable. No repair is authorized.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

Recoverability

codes

Definition

- Z —Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.
- D —Reparable item. When beyond lower level repair capability, return to depot. Condemnation —and disposal not authorized below depot level.
- L —Reparable item. Repair, condemnation, and disposal not authorized below depot/specialized repair activity level.

c. *National Stock Number.* Indicates the National stock number assigned to the item and will be used for requisitioning purposes.

d. *Part Number.* Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

NOTE

When a stock numbered item is requisitioned, the repair part received may have a different part number than the part being replaced.

e. *Federal Supply Code for Manufacturer (FSCM)* The FSCM is a 5-digit numeric code listed in SB 708-42 which is used to identify the manufacturer, distributor, or Government agency, etc.

f. *Description.* indicates the Federal item name and, if required, a minimum description to identify the item. In the Special Tools List, the initial basis of issue (BOI) appears as the last line in the entry for each special tool, special TMDE, and other special support equipment. When density of equipments supported exceeds density spread indicated in the basis of issue, the total authorization is increased accordingly.

g. *Unit of Measure (U/M).* Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc). When the unit of measure differs from the unit of issue the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

h. *Quantity Incorporated in Unit* Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly.

4. Special Information

a. The following publications pertain to the TD-976/G and TD-982/G and its components:
TM 11-7025-202-12, Multiplexer TD-976/G and Pulse Form Restorer TD-982/G.

b. The illustrations in this manual are identical to those published in TM 11-7025-202-34P. Only those parts assigned the third position SMR maintenance code "C" or "O" are listed in the tabular listing; therefore, there may be a break in the item number sequence. Only illustrations containing organizational authorized items appear in this manual.

c. National stock numbers (NSN's) that are missing from P source coded items have been applied for and will be added to this TM by future change/revision when they are entered in the Army Master Data file (AMDF). Until the NSN's are established and published, submit exception requisitions to Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL-MM, Fort Monmouth, NJ 07703 for the part required to support your equipment.

5. How to Locate Repair Parts

a. When National stock number or part number is unknown.

(1) *First.* Using the table of contents, determine the functional group within which the item belongs. This is necessary since illustrations are prepared for functional groups and listings are divided into the same groups.

(2) *Second.* Find the illustration covering the functional group to which the item belongs.

(3) *Third.* Identify the item on the illustration and note the illustration figure and item number of the item.

(4) *Fourth.* Using the Repair Parts Listing, find the figure and item number noted on the illustration

b. When National Stock number or part number known.

(1) *First* Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. This index is in NIIN sequence followed by a list of part numbers in alphanumeric sequence, cross-referenced to the illustration figure number and item number.

(2) *Second* After finding the figure and item number, locate the figure and item number in the repair parts list.

6. Abbreviations

Not applicable.

(Next printed page is 4)




Figure 1. Multiplexer TD-976/G.

EL5CL002