

TECHNICAL MANUAL

ORGANIZATIONAL MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS LISTS

LANDING CRAFT, MECHANIZED, STEEL; DED; OVERALL
LENGTH 74 FEET; MOD I MARK VIII, NAVY DESIGN

LCM-8

IGUNDERSON BROS. ENGINEERING CORP, MARINETTE
MARINE CORP AND ROHR CORP

FSN 1905-935-6057

This copy is a reprint which includes current pages from Change 1.

Technical Manual
No. 55-1905-217-20P

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, D.C., 12 June 1973

**ORGANIZATIONAL MAINTENANCE REPAIR
PARTS AND SPECIAL TOOLS LIST**

**LANDING CRAFT, MECHANIZED, STEEL; DED; OVERALL
LENGTH, 74 FEET; MOD I MARK VIII, NAVY DESIGN
LCM-8
(GUNDERSON BROS ENGINEERING CORP, MARINETTE
MARINE CORP AND ROHR CORP)
FSN 1905-935-6057**

Current as of 30 March 1973

TABLE OF CONTENTS

		Page	Illus Figure
Section	I. INTRODUCTION		
	II. PRESCRIBED LOAD ALLOWANCE LIST (Not applicable)		
	III. REPAIR PARTS LIST		
Group	01. Air Inlet Silencer	1	1
	02. Exhaust Manifold	2	2
	03. Filter Assembly, Oil	3	3
	04. Oil Filter, Dipstick and Breather	4	4
	05. Oil Cooler (Engine)	5	5
	06. Fuel Filter Assembly	8	6
	07. Fuel Strainer (Engine Mtg)	9	7
	08. Fuel Strainer (Line)	10	8, 9
	09. Fuel Piping	11	10, 11, 12
	10. Fuel Pump	19	13
	11. Rocker Arm Cover	20	14
	12. Fuel Injectors	20	15
	13. Injector Control Tube	21	16
	14. Throttle Controls	21	17
	15. Heat Exchanger (Engine)	22	18
	16. Engine Cooling Piping	23	19, 20
	17. Sea Water Piping	28	21, 22, 23
	18. Muffler and Exhaust Piping	37	24, 25
	19. Fresh Water Pump	40	26
	20. Raw Water Pump	41	27, 28
	21. Water Manifold (Engine)	43	29
	22. Sea Water Strainer Duplex	44	30
	23. Keel Cooler	44	32
	24. Engine Speed Governor	44	33
	26. Transmission Oil Filter	46	36
	27. Transmission Oil Strainer	47	37
	28. Transmission Oil Cooler Core	48	38
	29. Transmission Control Valve and Tubes	49	40
	30. Tachometer Drive Cable, Adapter and Shaft	49	41

***This manual supersedes TM 55-1905-217-20P dated 27 October 1970 and all changes.**

	Page	Illus Figure
31. Transmission Oil Pump	50	42, 43
32. Power Take-Off Assembly	53	45
33. Alternator, Regulator and Voltage Protector	54	46
34. Electric Cranking Motor	56	47, 48
35. Hydraulic Starting Piping System	60	49, 50, 51
36. Starting Engine, Hydraulic	69	52
37. Solenoid Valve, Starting Motor	69	54
38. Pump Hydraulic Starter	70	55, 56
40. Pump, Hand, Hydraulic Starting	71	
41. Filter, Oil, Hydraulic Starter	71	59, 60
42. Transfer Gear Assembly	72	61
43. Gear Assembly	72	
44. Flywheel, Housing	72	63
51. Oil Pan	73	71
55. Cylinder Block	74	75
56. Engine Pilot House Controls	74	
Pilot house levers, sprockets and chain		76
Engine control levers and brackets		78
Engine control unit		79
Pilot house engine controls		80
Pilot house controls		83
Pilot house engine controls		84
57. Fan		88, 89
58. Engine Control and Distribution Panel		
Distribution panel		90, 91
Cables, gages and lights		92
Indicator and lights		93
Ether starting aid		94
Instruments and plate		95
59. Navigational Lights and Horn	79	96
Forward and main mast		97
60. Helm Unit Steering	81	
61. Piping, Steering	82	100, 101, 102
.....		103, 104
62. Pump, Steering	92	105, 106
63. Pump, Drive (Coupling)	93	107
64. Filter, Hydraulic	93	108, 109
65. Valve, Steering	94	
Valve, check steering		110
Valve, by-pass		111
67. Cylinders, Hydraulic Steering	95	113
68. Tank, Hydraulic	95	115, 117
69. Piping, Hydraulic Ramp Hoist	96	118, 119, 120,
.....		121, 122, 123,
.....		124, 125
70. Pump, Hydraulic Ramp	102	
71. Winch Ramp Hoist (Marco)	103	
Winch gear reduction		127
Winch base		128
72. Winch Ramp Hoist, Gearmatic	103	
73. Valve, Ramp Control		139
74. Filter, Strainers	104	
Filter, hydraulic oil		140
Strainer, hydraulic oil		141
75. Relief Valve	106	
76. Check Valve	106	
77. Counterbalance Valve	106	
78. Hand Pump Hydraulic	106	145, 146
79. Tank, Hydraulic Oil Winch	106	147
80. Cylinders Hydraulic (Ramp Latch)	107	
Ramp latches		148
81. Propeller Shaft	107	150
82. Indicator, Rudder Angle and Transmitter	108	152, 153
83. Rudder	110	
Rudder and tiller		154, 155

	Page	Illus Figure
84. Hull	110	
Pilot house canopy		156
Lift lines, bitts, and ladders		157
Miscellaneous hull components		158
85. Piping, Blige	123	159, 160, 161
.....		162, 163
86. Pump, Blige	132	164, 165,
.....		166, 167
87. Pump, Bilge Hand	139	168
88. Compass System	139	
Section IV. SPECIAL TOOLS LIST (Not Applicable)		
V. FEDERAL STOCK NUMBER AND REFERENCE NUMBER INDEX		

Section I. INTRODUCTION

1. Scope

a. This manual lists repair parts, special tools, test and support equipment required for the performance of organizational maintenance of the landing craft.

b. Repair parts listed represent those authorized for use at the organizational level and will be requisitioned on an "as required" basis until stockage is justified by demand in accordance with AR 710-2.

2. General

This repair parts and special tools list is divided into the following sections:

a. *Prescribed Load Allowance List - Section II.* Not applicable.

b. *Repair Parts List - Section III.* A list of repair parts authorized at the organizational level for the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of assembly groups in ascending numerical sequence, with the parts in each group listed in figure. and item number sequence.

c. *Special Tools List - Section IV.* A list of special tools, test and support equipment authorized for the performance of maintenance at the organizational level. (Not applicable).

d. *Federal Stock Number and Reference Number Index - Section V.* A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alpha-numeric sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure and/or item number.

3. Explanation of Columns

The following provides an explanation of columns found in the tabulated listings in Section III.

a. *Source, Maintenance, and Recoverability Codes (SMR).* The SMR code is a five letter code composed of three parts consisting of a two (2) position source code, a two (2) position maintenance code, and a one (1) position recoverability code. Support items listed in this RPSTL assigned maintenance and recoverability codes and no source code can be requisitioned, with justification, through normal supply channels by use of the manufacturers code and part number. Such support items are NOT normally stocked.

(1) *Source Code.* Indicates the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions as follows:

Code	Definition
PA	Item procured and stocked for anticipated or known usage.
PB	Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply system.
PC	Item procured and stocked and which otherwise would be coded PA except that it is deteriorain nature.
PD	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issue or outfittings. NOT subject to automatic replenishment.
PE	Support equipment procured and stocked for initial issue or outfittings to specified maintenance repair activities.
PF	Support equipment which will not be stocked but which will centrally procured on demand.
PG	Item procured and stocked to provide for sustained support for life of the equipment. It is applied to an item peculiar to the equipment which, because of probably discontinuance or shutdown of production facilities, would prove uneconomical to reproduce at a later date.
KD	An item of depot overhaul/repair kit and not purchased separately.
KF	An item of a maintenance kit and not purchased separately.
KB	Item included in both a depot overhaul/repair kit and a maintenance kit.
MO	Item to be manufactured or fabricated at organizational level.
MF	Item to be manufactured or fabricated at direct support maintenance level.
MH	Item to be manufactured or fabricated at general maintenance support level.
MD	Item to be manufactured or fabricated at depot maintenance level.
AO	Item to be assembled at organizational level.
AF	Item to be assembled at direct support maintenance level.

<i>Code</i>	<i>Definition</i>
AH	Item to be assembled at general support maintenance level.
AD	Item to be assembled at depot maintenance level.
XA	Item is NOT procured or stocked because the requirements for the item will result in replacement of the next higher assembly.
XB	Item NOT procured or stocked. If not available through salvage, requisition.
XC	Installation drawing, diagram, instruction sheet, or field service drawing that is identified by manufacturer's part number.
XDA	low mortality item that is not stocked. When required, items will be requested and provided through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items coded above except those coded XA and support items restricted by AR 700-42.

(2) *Maintenance Codes.* The maintenance code entered in the third position indicates the lowest maintenance level authorized to remove, replace, and use the item. The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). When a maintenance code is not used in the fourth position, a dash (-) will be entered.

<i>Code</i>	<i>Application/Explanation</i>
O	Item is removed, replaced, used (third position), or complete repair (fourth position) at the organizational level.
F	Item is removed, replaced, used (third position), or complete repair (fourth position) at the direct support maintenance level.
H	Item is removed, replaced, used (third position) or complete repair (fourth position) at the general support maintenance level.
D	Item is removed, replaced, used (third position) or complete repair (fourth position) at the depot maintenance level.
L	Repair restricted to designated specialized repair activity (fourth position).
Z	Non-repairable. No repairs authorized (fourth position).
B	No repair is authorized. The item may be re-conditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for maintenance of this item (fourth position).

(3) *Recoverability Code.* The recoverability code entered in the fifth position indicates the disposition action on unserviceable items.

<i>Code</i>	<i>Definition</i>
Z	Non-repairable item. When unserviceable, condemn and dispose at the level indicated in position three (3).
C	Repairable item. When uneconomically repairable, condemn and dispose at organizational level.
F	Repairable item. When uneconomically repairable, condemn and dispose at direct support level.
H	Repairable item. When uneconomically repairable, condemn and dispose at general support level.
D	Repairable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
L	Repairable item. Repair, condemnation, and disposal not authorized below depot/specialized repair activity level.
A	Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material, or hazardous material).

b. *Federal Stock Number.* Indicates the Federal stock number assigned to the item and will be used for requisitioning purposes.

c. *Description.* Indicates the Federal item name and a minimum description required to identify the item. The last line indicates the reference number followed by the applicable Federal Supply Code for Manufacturer (FSCM) in parenthesis. The FSCM is used as an element in item identification to designate manufacturer or distributor or Government agency, etc., and is identified in SB 708-42. Items that are included in kits' and sets are listed below the name of the kit or set with quantity of each item in the kit or set indicated in front of the item name.

d. *Unit of Measure (U/M).* Indicates the standard or basic quantity by which the listed item is used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation, e.g., ea, in, pr, etc., and is the basis used to indicate quantities and allowances in subsequent columns.

e. *Quantity Incorporated in Unit.* Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for an assembly group, or an assembly. A "V" appearing in this column in lieu of a quantity indicates that no specific quantity is applicable, e.g., shims, spacers, etc.