

ARMY TM 11-6625-255-14
AIR FORCE TO 33A1-13-170-1

OPERATOR'S, ORGANIZATIONAL, DIRECT
SUPPORT, AND GENERAL SUPPORT
MAINTENANCE MANUAL

SPECTRUM ANALYZERS TS-723A/U,
TS-723B/U, TS-723C/U, AND
TS-723D/U (NSN 6625-00-668-9418)

This copy is a reprint which includes current pages from Change 1. The title was changed to read as shown above by Change 1.

DEPARTMENTS OF THE ARMY AND THE AIR FORCE
JANUARY 1976

TECHNICAL MANUAL
 No. 11-6625-255-14
 TECHNICAL ORDER
 No. 33A1-13-170-1

DEPARTMENTS OF THE ARMY
 AND THE AIR FORCE
 WASHINGTON, DC, 9 January 1976

**Operator's, Organizational,
 Direct Support, and General
 Support Maintenance Manual**

SPECTRUM ANALYZERS

**TS-723A/U, TS-723B/U, TS-723C/U,
 AND TS-723D/U (NSN 6625-00-668-9418)**

		Paragraph	Page
CHAPTER	1. INTRODUCTION		
Section	I. General		
	Scope	1-1	1-1
	Indexes of publications	1-2	1-1
	Forms and records,	1-3	1-1
	Destruction of Army materiel.....	1-4	1-1
	Administrative storage	1-5	1-1
	Reporting of errors	1-6	1-1
	Reporting equipment improvement recommendations (EIR)	1-6.1	1-1
	II. Description and Data		
	Purpose and use	1-7	1-1
	Description	1-8	1-1
	Differences between models	1-9	1-3
	Tabulated data	1-10	1-3
CHAPTER	2. SERVICE UPON RECEIPT AND INSTALLATION		
Section	I. Service Upon Receipt of Materiel		
	Unpacking	2-1	2-1
	Checking unpacked equipment...	2-2	2-1
	II. INSTALLATION		
	Tools, test equipment, and materials required for installation	2-3	2-1
	Installation instructions	2-4	2-1
	Interconnections	2-5	2-2
	Installation of plug-in items	2-6	2-3
CHAPTER	3. OPERATING INSTRUCTIONS		
Section	I. Controls and Instruments		
	Damage from improper settings.	3-1	3-1
	Operator controls	3-2	3-1
	II. Operation Under Usual Conditions		
	Types of operation	3-3	3-4
	Starting procedure	3-4	3-4
	Distortion measurements in percentage	3-5	3-4
	Distortion measurements in decibels	3-6	3-4
	Unknown input signal frequency	3-7	3-5
	Use as vtm for measuring signals in rms values	3-8	3-5
	Use as vtm for measuring signals in dbm values	3-9	3-5
	Use as vtm within creased sensitivity	3-10	3-6
	Use of oscilloscope with spectrum analyzer	3-11	3-7
	Stopping procedure	3-12	3-7
	III. Operation Under Unusual Conditions		
	Operation in arctic climates	3-13	3-7
	Operation tropical climates	3-14	3-7
	Operation in desert climates	3-15	3-7

*This manual supersedes TM 11-5097, 24 January 1957, include all changes.

		Paragraph	Page
C H A P T E R 4 .	OPERATOR MAINTENANCE INSTRUCTIONS		
Section	I. Operator Preventive Maintenance Checks and Services		
	General	4-1	4-1
	Operator tools and equipment	4-2	4-1
	II. Maintenance of the Spectrum Analyzer		
	General	4-3	4-1
	Preventive maintenance checks and services periods	4-4	4-1
	Cleaning	4-5	4-2
C H A P T E R 5 .	ORGANIZATIONAL MAINTENANCE INSTRUCTIONS		
Section	I. Tools and Test Equipment, Repainting and Refinishing		
	General	5-1	5-1
	Rustproofing and painting	5-2	5-1
	II. Lubrication		
	General	5-3	5-1
	Lubrication instructions	5-4	5-1
	III. Organizational Preventive Maintenance Checks and services		
	General	5-5	5-1
	Scope of maintenance	5-6	5-1
	IV. Organizational Troubleshooting		
	General	5-7	5-2
	Physical tests and inspection.	5-8	5-2
C H A P T E R 6 .	FUNCTIONING OF EQUIPMENT		
	Circuitry	6-1	6-1
	Preamplifier circuit	6-2	6-2
	Wienbridge circuit	6-3	6-2
	Bridge as frequency rejection filter	6-4	6-5
	Bridge amplifier circuit	6-5	6-7
	Function switch S4 and dB gain of spectrum analyzer	6-6	6-7
	Voltage divider circuit	6-7	6-8
	Voltage amplifier and meter circuit	6-8	6-9
	Power supply circuit	6-9	6-11
C H A P T E R 7 .	GENERAL SUPPORT MAINTENANCE		
Section	I. General		
	Voltage and resistance measurement	7-1	7-1
	Checking filament and B+ circuits for shorts	7-2	7-1
	Dc resistance of transformers and coils	7-3	7-2
	II. Troubleshooting		
	General instructions	7-4	7-3
	General support tools and equipment required	7-5	7-3
	Organization of troubleshooting procedures	7-6	7-4
	Troubleshooting setup	7-7	7-5
	Localizing trouble	7-8	7-5
	Isolating trouble within stage.	7-9	7-9
	III. MAINTENANCE OF SPECTRUM ANALYZER		
	General parts replacement techniques	7-10	7-10
	Replacement of capacitor drive cables	7-11	7-10
	Disassembly and reassembly of capacitor drive assembly	7-12	7-10
	Adjustment of regulated B + voltage	7-13	7-14
	Zero setting meter M1	7-14	7-14
	Adjustment of HUM BAL control	7-15	7-14
	Alignment of vtm section	7-16	7-16
	Adjustment of preamplifier-bridge amplifier gain	7-17	7-17
	Calibrating wien bridge circuit	7-18	7-18
	Adjustment of FREQUENCY tuning dial	7-19	7-18
	Recalibrating FREQUENCY tuning dial	7-20	7-18
	IV. General Support Testing Procedures		
	General	7-21	7-19
	Modification work orders	7-22	7-20
	Physical tests and inspections	7-23	7-20
	225-volt supply regulation	7-24	7-20
	Internal amplifier gain test	7-25	7-24
	Volt meter calibration test	7-26	7-27
	Noise, set level, and frequency response test	7-27	7-30
	Dial calibration test	7-28	7-33
	Second harmonic attenuation test	7-29	7-37
	Oscilloscope output test	7-30	7-40
	Distortion test	7-31	7-43

APPENDIX	A. REFERENCES	A-1
	B. BASIC ISSUE ITEMS LIST (BIIL) AND ITEMS TROOP INSTALLED OR AUTHORIZED LIST (ITIAL) (Not Applicable)	
APPENDIX	C. MAINTENANCE ALLOCATION	
Section	I. Introduction	C-1
	II. Maintenance Allocation Chart.	C-3

LIST OF ILLUSTRATIONS


Figure	Title	Page
1-1	Spectrum Analyzer TS-723D/U	1-0
1-2	DA Form 2028-2(Test), sample.	1-2
2-1	Packaging of Spectrum Analyzer TS-723(*)/U.	2-2
2-2	Tube locations, Spectrum Analyzer TS-723(*)/U	2-3
3-1	Front panel controls and indicators, Spectrum Analyzer TS-723A/U	3-1
3-2	Front panel controls and indicators, Spectrum Analyzer TS-723B/U, TS-723C/U, and TS-723D/U	3-2
3-3	Rear panels, Spectrum Analyzer TS-7230/U	3-3
3-4	Impedance correction chart	3-6
5-1	Lubrication of Spectrum Analyzer TS-723(*)/U	5-3
6-1	Block diagram, Spectrum Analyzer TS-723(*)/U	6-3
6-2	Preamplifier circuit, simplified schematic diagram	6-4
6-3	Bridge circuit, simplified schematic diagram	6-5
6-4	Frequency rejection characteristics Oxbridge	6-6
6-5	Frequency rejection of bridge when used with feedback amplifier	6-6
6-6	Phase shift characteristics of bridge	6-6
6-7	Bridge amplifier circuit, simplified schematic diagram	6-7
6-8	Voltage divider circuit, simplified diagram, Spectrum Analyzer TS-723A/U	6-8
6-9	Voltage divider circuit, simplified schematic diagram, Spectrum Analyzer TS-723B/U, TS-723C/U, and TS-723D/U	6-9
6-10	Voltage amplifier and meter circuit, simplified schematic diagram	6-10
6-11	Meter rectifier circuit, Spectrum Analyzer TS-723D/U	6-10
6-12	Power supply circuit, simplified schematic diagram	6-12
6-13	115V-230V changeover switch(TS-723C/U and TS-723D/U), partial schematic diagram	6-13
7-1	Spectrum Analyzer TS-723A/U chassis, top view, location of parts	7-2
7-2	Spectrum Analyzer TS-723B/U, TS-723C/U, and TS-723D/U chassis, topview, location of parts	7-3
7-3	Spectrum Analyzer TS-723A/U chassis, bottom view, location of parts	7-4
7-4	Spectrum Analyzer TS-723B/U chassis, bottom view, location of parts	7-5
7-5	Spectrum Analyzer TS-723C/U and TS-723D/U chassis, bottomview, location of parts	7-6
7-6	B+ voltage distribution	7-7
7-7	Tube socket voltage and resistance diagram	7-8
7-8	Terminal board voltage and resistance diagram	7-11
7-9	Replacing capacitor drive cables.	7-12
7-10	Capacitor drive assembly, exploded view	7-15
7-11	225V supply regulation test setup	7-21
7-12	Internal amplifier gain test setup	7-23
7-13	Voltage calibration test setup	7-26
7-14	Noise, set level, and frequency response test setup	7-29
7-15	Dial calibration test setup	7-32
7-16	Second harmonic attenuation test setup	7-36
7-17	Oscilloscope output test setup...	7-39
7-18	Distortion test setup	7-42
FO-1	Color code markings for MIL-STD resistors, capacitors, and inductors	Located in back of Manual.
FO-2	Schematic diagram, Spectrum Analyzer TS-723A/U	Located in back of Manual.
FO-3	Schematic diagram, Spectrum Analyzers TS-723B/U, TS-723C/U, and TS-723D/U	Located in back of Manual.
FO-4	Wiring diagram, Spectrum Analyzer TS-723A/U	Located in back of Manual.
FO-5	Wiring diagram, Spectrum Analyzers TS-723B/U, TS-723C/U, and TS-723D/U	Located in back of Manual.

LIST OF TABLES

Number	Title	Page
1-1	Differences between models	1-3
3-1	Operator controls and indicators	3-2
3-2	Typical dB distortion measurements	3-5

LIST OF TABLES-Cont,

Number	Title	Page
3-3	DB range of meter range switch positions.	3-5
3-4	Examples of meter indications	3-5
3-5	Examples of dBm measurements and applied correction facators	3-5
4-1	Operator preventive maintenance checks and services	4-1
5-1	Organizational preventive maintenance checks and services.	5-1
5-2	Organizational troubleshooting	5-2
7-1	Checkng filament and B+ circuits for shorts	7-1
7-2	Voltage measurements	7-2
7-3	Dc resistance of transformers and coils	7-3
7-4	Troubleshooting chart	7-9
7-5	Values of resistors	7-17
7-6	Physical tests and inspections	7-20
7-7	225-Volt supply regulation test	7-22
7-8	Internal amplfier gain test	7-26
7-9	Voltmeter calibration test	7-28
7-10	Noise, setlevel, and frequency response test	7-31
7-11	Dial calibration test,	7-34
7-12	Second harmonic attenuation test	7-38
7-13	Oscilloscope output test	7-41
7-14	Distortion test	7-44



EL6625-255-14-TM-1

Figure 1-1. Spectrum Analyzer TS-723D/U.

CHAPTER 1

INTRODUCTION

Section I. GENERAL

1-1. Scope

a. This manual describes Spectrum Analyzers TS-723A/U, TS-723B/U, TS-723C/U, and TS-723D/U and covers their installation, operation, functioning, and operator, organizational, and general support maintenance. No direct support maintenance is authorized for this equipment. Figure 1-1 shows TS-723D/U; all other models are similar.

b. Official nomenclature utilizing (*) is used to indicate all models of the equipment. Therefore, Spectrum Analyzer TS-723(*)/U will represent Spectrum Analyzer TS-723A/U, TS-723B/U, TS-723C/U, and TS-723D/U, except where model differences dictate.

1-2. Indexes of Publications

a. *DA Pam 110-4*. Refer to the latest issue of DA Pam 310-4 to determine whether there are new editions, changes, or additional publications pertaining to the equipment.

b. *DA Pam 310-7*. Refer to DA Pam 310-7 to determine whether there are modification work orders (MWO's) pertaining to the equipment.

1-3. Forms and Records

a. *Reports of Maintenance and Unsatisfactory Equipment*. Maintenance forms, records, and reports which are to be used by maintenance personnel at all maintenance levels are listed in and prescribed by TM 38-750 (Army). Air Force personnel will use AFM 66-1 for maintenance reporting and TO-00-35D54 for unsatisfactory equipment reporting.

b. *Report of Packaging and Handling Deficiencies*. Fill out and forward DD Form 6 (Packaging Improvement Report) as prescribed in AR 700-58/NAVSUPINST 4030.29/AFR 71-13/MCO P4030.29A, and DSAR 4145.8.

c. *Discrepancy in Shipment Report (DISREP) (SF 361)*. Fill out and forward Discrepancy in Shipment Report (DISREP) (SF 361) as prescribed in AR 55-3/NAVSUPINST 4610.33A/AFR 75-18/MCO

P4610.10B and DSAR 4500.15.

1-4. Destruction of Army Materiel.

Demolition and destruction of electronic equipment will be under the direction of the commander and in accordance with TM 750-244-2.

1-5. Administrative Storage

For procedures, forms, and records, and inspections required during administrative storage of this equipment, refer to TM 740-90-1.

1-6. Reporting of Errors

a. The reporting of errors, omissions, and recommendations for improving this manual by the individual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Changes to Publications and Blank Forms) or DA Form DA Form 2028-2 (Test) located in the back of the manual, and forwarded direct to Commander, US Army Electronics Command, AT TN: DRSEL-MA-Q, Fort Monmouth, NJ 07703. To use the form in the back of the manual, fill it out as shown on the sample figure 1-2, fold it where shown, and drop it in the mail. A reply will be furnished direct to you.

b. For Air Force, use USAFLC Form 252 (Request for TO Revision or Change). Forward direct to prime ALC/MST.

1-6.1 Reporting Equipment Improvement Recommendations (EIR)

a. *Army*. EIR's will be prepared using DA Form 2407, Maintenance Request. Instructions for preparing EIR's are provided in TM 38-750, the Army Maintenance Management System. EIR's should be mailed directly to Commander, US Army Electronics Command, ATTN: DRSEL-MA-Q, Fort Monmouth, NJ 07703. A reply will be furnished directly to you.

b. *Air Force*. Air Force personnel are encouraged to submit EIR's in accordance with AFM 900-4.